

DISTRICT I

1625 N. French Dr., Hobbs, NM 88240

DISTRICT II

811 South First, Artesia, NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec, NM 87410

DISTRICT IV

1220 South St. Francis Dr., Santa Fe, NM 87505

OIL CONSERVATION DIVISION
1220 South St. Francis Drive
Santa Fe, NM 87505

WELL API NO. 30-025-06377
5. Indicate Type of Lease <input checked="" type="checkbox"/> STATE <input type="checkbox"/> FEE
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name State Sec 2
8. Well No. 11
9. Pool name or Wildcat Wantz Abo

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH
PROPOSALS.)

1. Type of Well: <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER
2. Name of Operator Apache Corporation
3. Address of Operator 2000 Post Oak Blvd., Ste. 100, Houston, Texas 77056-4400
4. Well Location Unit Letter <u>L</u> : <u>3376</u> Feet From The <u>South</u> Line and <u>330</u> Feet From The <u>West</u> Line Section <u>2</u> Township <u>21S</u> Range <u>37E</u> NMPM <u>Lea</u> County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3484' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
<input type="checkbox"/> Perform Remedial Work	<input type="checkbox"/> Remedial Work
<input type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Altering Casing
<input type="checkbox"/> Temporarily Abandon	<input type="checkbox"/> Commence Drilling Operations
<input type="checkbox"/> Change Plans	<input checked="" type="checkbox"/> Plug and Abandonment
<input type="checkbox"/> Pull or Alter Casing	<input type="checkbox"/> Casing Test and Cement Job
<input type="checkbox"/> Other	<input type="checkbox"/> Other

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

4/8/2002 Move in and rig up. Bled well down - had 350#. Nipple down wellhead and nipple up BOP. Run in hole w/ 5-1/2" CIBP, set @ 6350' and dump 35' cement on top. Run in hole and tag top of cement @ 6300'. Circulate hole w/ mud.

4/9/2002 Run in hole and perforate 4 holes @ 3190' and pressure up to 800#. Perforate 4 holes @ 3140' and pressure up to 850# - unable to pump into perforations. Spoke to E.L. Gonzalez @ OCD/Hobbs, he approved spotting of 60 sx cement plug @ 3250'.

4/10/2002 Run in hole & tag top of cement plug @ 2862'. Spot cement plug @ 1400' w/ 30 sx. Spot cement plug @ 250' w/ 75 sx. Wait on cement. Tag top of cement plug @ 75'. Spot 50 sx cement to surface. Install P&A marker and clean location.

Approved as to plugging of the Well Bore.
Liability under bond is retained until
surface restoration is completed.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Debra J. Anderson TITLE Sr. Engineering Technician DATE 4/29/2002

TYPE OR PRINT NAME Debra J. Anderson TELEPHONE NO. 713-296-6338

(This space for State Use)

APPROVED BY GARY W. WINK TITLE OC FIELD REPRESENTATIVE II/STAFF MANAGER DATE FEB 10 2003

CONDITIONS OF APPROVAL, IF ANY: 6WW