


# OIL CONSERVATION COMMISSION

Santa Fe, New Mexico

## MISCELLANEOUS REPORTS ON WELLS



Submit this report in triplicate to the Oil Conservation Commission or its proper agent within ten days after the work specified is completed. It should be signed and sworn to before a notary public for reports on beginning drilling operations, results of shooting well, results of test of casing shut off, result of plugging of well, and other important operations, even though the work was witnessed by an agent of the Commission. Reports on minor operations need not be signed and sworn to before a notary public. See additional instructions in the Rules and Regulations of the Commission.

Indicate nature of report by checking below.

REPORT ON BEGINNING DRILLING OPERATIONS <i>1-11-48</i> <i>1-11-48</i>	REPORT ON REPAIRING WELL
REPORT ON RESULT OF SHOOTING OR CHEMICAL TREATMENT OF WELL	REPORT ON PULLING OR OTHERWISE ALTERING CASING
REPORT ON RESULT OF TEST OF CASING SHUT-OFF	REPORT ON DEEPENING WELL
REPORT ON RESULT OF PLUGGING OF WELL	

1-11-48 Junice field  
Date Place

OIL CONSERVATION COMMISSION,  
SANTA FE, NEW MEXICO  
Gentlemen:

Following is a report on the work done and the results obtained under the heading noted above at the 660' from East line-1980' from South Line

Bert Fields Dansinger Well No. A. 2 in the  
Company or Operator Lease  
of Sec. B, T. 25-S, R. 36-E, N. M. P. M.,  
Junice Field, \_\_\_\_\_ County.

The dates of this work were as follows: 1-11-48

Notice of intention to do the work was ~~(yes, not)~~ submitted on Form C-102 on 1-10-48 19\_\_\_\_  
and approval of the proposed plan was ~~(yes, not)~~ obtained. (Cross out incorrect words.)

### DETAILED ACCOUNT OF WORK DONE AND RESULTS OBTAINED

Tested Casing with 1500# pressure . Test O.K.  
Drilled cement & plug and perforated casing from 3732' to 3731' with 80 shots.  
Swab casing dry then acidized with 1000 gallons. Results water. No Oil.  
Plug back to 3715' with 100 sacks cement. Then perforated from 3692' to 3702' with 90 shots. Then swab casing dry, acidize with 1000 gallons. Swab acid out.  
Recovery: water 100%. Then set plug at 3686 and cemented with 100 sacks.  
Perforated from 3680' to 3680' - 150 shots. Swabbed casing dry. Acidize with 1000 gallons.

Witnessed by E. W. Hunt Bert Fields - Production Foreman  
Name Company Title

Subscribed and sworn before me this 19th

I hereby swear or affirm that the information given above is true and correct.

day of January 1948

Name T. G. Hoffman

Position Supt.

Lucille B. Stephens  
**Lucille B. Stephens** Notary Public

Representing Bert Fields  
Company or Operator

My commission expires June 1, 1949

Address Box 526- Kermit, Texas

Remarks:

*stay your receipt*

[Signature]  
Name  
Supt.  
Title