

**UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY**

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well gas well other

2. NAME OF OPERATOR
TEXACO, Inc.

3. ADDRESS OF OPERATOR
P. O. Box 728, Hobbs, New Mexico 88240

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 330' FSL & 2310' FWL
AT TOP PROD. INTERVAL: (Unit Letter 'N')
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>		<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>		<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>		<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>		<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>		<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>		<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>		<input type="checkbox"/>
ABANDON*	<input type="checkbox"/>		<input type="checkbox"/>
(other) To:	Downhole Commingle		

5. LEASE
LC-032874 (a)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME
-

7. UNIT AGREEMENT NAME
-

8. FARM OR LEASE NAME
G. L. Erwin 'A' Federal

9. WELL NO.
1

10. FIELD OR WILDCAT NAME
Justis Blinebry & Justis Tubb Drinkard

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 35, T-24-S, R-37-E

12. COUNTY OR PARISH
Lea

13. STATE
New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
3716' (DF)

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Rig up.
2. Set CIBP in Drinkard String @ 5710, 5000, & 4450. Cap each plug w/40' cement.
3. Clean out Devonian String to 6200'. Log well.
4. Perforate Devonian String w/4-JSPF from 5640'-5650', 5995-6005', & 6100-6110'.
5. Set RBP @ 6130' & Pkr. @ 6050'. in Devonian String.
6. Acidize commingling perfs 6100-6110 w/500 gal. 15% NE Acid.
7. Reset RBP @ 6050 & Pkr. @ 5950. Acidize perfs 5995'-6005 w/500 gal 15% NE Acid.
8. Reset RBP @ 5750 & Pkr. @ 5550. Acidize perfs 5640-5650 w/500 gal 15% NE Acid.
9. Pull RBP & Pkr. Install production equipment. Test and place on production as Blinebry- Drinkard Downhole Commingle.

Administrative Order No. 343


Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature] TITLE Asst. Dist. Mgr. DATE 4-17-84

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:



RECEIVED
APR 26 1984
C.C.D.
HOBAS OFFICE