Submit 1 Copy To Appropriate District Office	State of New Mexico Energy, Minerals and Natural Resources OIL CONSERVATION DIVISION 1220 South St. Francis Dr. Santa Fe, NM 87505			Form C-103			
District I – (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240				Revised July 18, 2013 WELL API NO.			
<u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210				30-025-263			
<u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410				5. Indicate STA		ree 🖂	✓
<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM 87505				6. State Oil & Gas Lease No.			
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 1. Type of Well, Oil Well, Signal of W				7. Lease Name or Unit Agreement Name Gann			
				8. Well Nu	mber		
1. Type of Well: Oil Well	Gas Well Other 08/04/2016			1			
2. Name of Operator V-F PETROLEUM INC.	✓	70 D1	ECEIVED	9. OGRID 24010	Number		/
3. Address of Operator		KJ	CLIVE	10. Pool na			
P.O. Box 1889, Midland, Texas 79702				CAUDILL	;PERMO U	JPPER PEN	N V
4. Well Location		1 000		. 1.			
	et from the <u>North</u> line a			t_ line			
Section 9 Township 15-S Range 36-E NMPM Lea County \(\square\) 11. Elevation (Show whether DR, RKB, RT, GR, etc.)							
3,931' GL							
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:							
NOTICE OF IN	TENTION TO:	I	30	BSEQUE	VI KEPO	KI OF:	
PERFORM REMEDIAL WORK TEMORARILY ABONDON CHANGE PLANS COMMENCE DRILL CASING/CEMENT J DOWNHOLE COMMINGLE OTHER: OTHER:				NC ODNS	☐ ALTERI	NG CASING	
						~	
13. Describe proposed or completed starting any proposed work). SE completion or recompletion.	operations. (Clearly state EE RULE 19.15.7.14 NMA	all perti	nent details, and give Multiple Completions	pertinent dat s: Attach we	es, includin Ilbore diagr	g estimated of am of propos	late of ed
 TOH with all production equipment. Add perfs: 10,255' – 10,672' 							
3. Acidize perfs and swab	,						
4. Test for production.							
5. If new perfs are economically productive, run and cement a scab liner from 4,000' – 8,000'.							
I hereby certify that the information above is true and complete to the best of my knowledge and belief.							
	1 0	o to the c	cot of my knowledge	una conon			
SIGNATURE Emily	U TITL	E Petro	oleum Engineer		DATE <u>08</u>	/04/2016	
Type or print name <u>Eric Sprinkle</u>	E-ma	il addres	s: <u>eric@vfpetroleu</u>	m.com	PHONE:	432-683-334	4
For State Use Only	-/-						
APPROVED BY:	Zulky TITLE	E_Petr	oleum Engineer		DATE	08/17/2016	
Conditions of Approval (if any):							

KZ