	ct Office	State of N	lew Mexico				CI 102
District I - (575) 393-6161	Fr					Revise	Form C-103 d July 18,2013
1625 N. French Dr., Hobbs, NM 8824	575) 748-1283 OIL CONSERVATION DIVISION			WELL API NO. 30.025.04112 5. Indicate Type of Lease			
District II - (575) 748-1283 811 S. First St., Artesia, NM 88210							
Disrtict III - (505) 334-6178 1000 Rio Brazos Rd. Aztec, NM 874	10	1220 South 5	St. Francis Dr.		ATE		FEE 🗹
District IV - (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM		Santa Fe,	NM 87505	6. State C	Dil & Gas Lea	se No.	
		REPORTS ON WEI	TC	7 1 0000	Nome on Uni	A =======	ne Mana
(DO NOT USE THIS FORM FOR PERSERVIOR. USE "APPLICATION	ROPOSALS TO DRILL C	OR DEEPEN OR PLUG B	ACK TO A DIFFERENT		Name or Uni orth Monun	_	
				8. Well N			
2. Name of Operator	1. Type of Well: Oil Well Gas Well Other				9. OGRID Numer		
2. Name of Operator	Apache Corporation				873		
3. Address of Operator				10. Pool	Name or Wil		
303 Veterans	Airpark Lane, St	e. 3000, Midland,	TX 79705				
4. Well Location		***					
Unit Letter		660 S	line and	660	feet from t	E	line
Section		vnship 19S	Range 36E DR, RKB,RT, GR, etc.)	NMPM		County	LEA
	11, Eleva		632' DF				
1:	Chools Ammong				Mhan Data		
			te Nature of Notice, Re	eport, or C	ther Data		
NOTICE (OF INTENTION TO):	SUB	SEQUEN	T REPORT	OF:	
PERFORM REMEDIAL WORK	PLUG AN	ID ABANDON 🔼	REMEDIAL WORK		ALTERIN	G CASING	3 🗆
TEMPORARILY ABANDON	☐ CHANGE	PLANS 🔲	COMMENCE DRILLING	OPNS.	PANDA		
PULL OR ALTER CASING		E COMPL	CASING/CEMENT JOB				
DOWNHOLE COMMINGLE							
CLOSED-LOOP SYSTEM							
OTHER:			OTHER:				
13. Describe proposed or c	ompleted operation	ns. (Clearly state a	all pertinent details, and	d give per	inent dates,	includin	g estimated
date of starting any propose	ed work.) SEE RU	LE 19.15.7.14 NM	IAC. For Multiple Co.	npletions:	Attach well	lbore dia	gram or
proposed completion or rec			•				
k L							
	4" DIAMETER 4'	TALL ABOVE GROUND	MARKER				
Apache Corporation pro	poses to P&A the	above mentioned	d well by the attached	procedu	re. A close	d loop s	
			osed of required by C	•			vstem will
				ICD Rule			ystem will
			occionation by c	OCD Rule	19.15.17.14		ystem will
			ood or roquilou by c	OCD Rule	19.15.17.14		ystem will
				OCD Rule	19.15.17.14		ystem will
				OCD Rule	19.15.17.14		ystem will
				OCD Rule	19.10.17.14		ystem will
Spud Date:				OCD Rule		NMAC.	
Spud Date:			Rig Release Date:	OCD Rule	. See	NMAC.	ned
Spud Date:				OCD Rule	. See	NMAC.	
	ormation above is t	rue and complete t	Rig Release Date:		See Condition	NMAC.	ned
Spud Date: I hereby certify that the info	rmation above is t	rue and complete t	Rig Release Date:		See Condition	NMAC.	ned
I hereby certify that the info		_	Rig Release Date: o the best of my knowl	edge and	See Condition	Attach	ned Approvai
	ormation above is t	_	Rig Release Date:	edge and	See Condition	Attach	ned
I hereby certify that the info	Guinn Bur	ks TITLE	Rig Release Date: o the best of my knowledge of the best of my knowledge of the best of t	ledge and	See Condition belief. DATE	Attach	ned Approval /7/20
I hereby certify that the info		ks TITLE	Rig Release Date: o the best of my knowl	ledge and	See Condition belief. DATE	Attach	ned Approvai
I hereby certify that the info	Guinn Bur	ks TITLE	Rig Release Date: o the best of my knowledge of the best of my knowledge of the best of t	ledge and	See Condition belief. DATE	Attach	ned Approval /7/20
I hereby certify that the info	Guinn Bur	ks TITLE	Rig Release Date: o the best of my knowledge of the best of my knowledge of the best of t	ledge and	See Condition belief. DATE PHONE:	Attach	ned Approval /7/20




LEASE NAME NMGSAU WELL# 018 API# 30.025.04112 LEA COUNTY

	WELL BORE INFO.	
0		
	17 1/2" Hole 12 1/2" 50 # @ 248' w/ 150 to surf	
396		
791		
1187	11 1/2" Hole 9 5/8" 36 # @ 1201' w/ 350 sx to surf	
1582		
	Cal TOC @ 1	699'
1978		
2374		
2769		
3165		
3560	8 1/4" Hole 7" 24# @ 3701'	

w/ 250 sx 5 1/2" Liner from 3664'-3956'

w/ 50 sx CIRC

3956



Perfs @ 3925'-3940'

TD @ 3957'



LEASE NAME NMGSAU WELL# 018 API# 30.025.04112 COUNTY LEA

PROPOSED PROCEDURE

4. PUH & perf @ 300' & sqz/CIRC 110 sx Class "C" cmt

from 300' to surf. Attempt to CIRC 7" to surf. (Surf.

Shoe, Water Board & Surf Plug)

WELL BORE INFO.

17 1/2" Hole 12 1/2" 50 # @ 248' w/ 150 to surf

791

396

1187 11 1/2" Hole 9 5/8" 36 # @ 1201" w/ 350 sx to surf

1582

1978

2374

2769

3165

3560

Cal TOC @ 1699

PUH & perf @ 1556' & sqz 140 sx Class "C" cmt from 1556'-1151', WOC/TAG (Top of Salt & 9 5/8" Shoe)

2. PUH & perf @ 2270' & attempt to SQZ 50 sx Class "C" cmt from 2270'-2070', WOC/TAG (Base of Salt)

1. MIRU P&A rig. Wet CIBP @ 3875', RIH w/ tbg 7 CIRC w/ MLF & spot 50 sx Class "C" cmt from 3875'-3382', TAG (Grayburg & Queen)

Perfs @ 3925'-3940'

TD @ 3957

8 1/4" Hole 7" 24# @ 3701" w/ 250 sx

5 1/2" Liner from 3664'-3956' w/ 50 sx CIRC

3956

CONDITIONS OF APPROVAL FOR PLUGGING AND ABANDONMENT OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at (575)-263-6633 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- **2.** Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- **3.** Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- **5.** A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can +be released.
- **6.** If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- **8.** Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- **10.** All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- **13.** A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- **14.** All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
- **16.** When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- **18.** A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

- **19.** No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
- A) Fusselman
- B) Devonian
- C) Morrow
- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- I) Glorieta
- J) Yates.
- K) Potash---(In the R-111-P Area (Potash Mine Area),

A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, woe 4 hours and tag, this plug will be SO' below the bottom and 50' above the top of the Formation.

21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, woe and tagged. These plugs will be set SO' below formation bottom to 50' above formation top inside the casing.

DRY HOLE MARKER REQ.UIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and Well Number
- 3. API Number
- 4. Unit letter
- 5. Quarter Section (feet from the North, South, East or West)
- 6. Section, Township and Range
- 7. Plugging Date
- 8. County

SPECIAL CASES ----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)