Submit 1 Copy To Appropriate Dis	trict Office	Ctota of N	Maudaa			_		
District I - (575) 393-6161	ъ.		ew Mexico				orm C-103 d July 18,2013	
1625 N. French Dr., Hobbs, NM 88	Energy, 1	Minerals an	d Natural Reso	ources WE	LL API NO.	Kevise	1 July 16,2013	
<u>District II</u> - (575) 748-1283	OII C	ONSERVA	ATION DIVISI	ONI	30.025	.06694		
811 S. First St., Artesia, NM 88210)			5. Ir	ndicate Type of Le	ase		
<u>Disrtict III - (</u> 505) 334-6178 1000 Rio Brazos Rd. Aztec, NM 87	7410	1220 South S	St. Francis Dr.		STATE	F	EE 🗸	
<u>District IV - (505) 476-3460</u>	, 110	Santa Fe	NM 87505	6. S	tate Oil & Gas Lea	ise No.		
1220 S. St. Francis Dr., Santa Fe, N	NM 87505	Bunta I C,	1111 07303					
SUNDRY NOTICES AND REPORTS ON WELLS					7. Lease Name or Unit Agreement Name			
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR DEEPEN OR PLUG BACK TO A DIFFERENT					D.C. Hard	lv Gas U	+	
RESERVIOR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)					8. Well Number			
1. Type of Well: Oil Well 🗸 Gas Well 🗌 Other					005			
2. Name of Operator					9. OGRID Numer			
Apache Corporation					873			
3. Address of Operator				10.	10. Pool Name or Wildcat			
	ns Airpark Lane, Ste. 3000), Midland,	TX 79705		Pad	dock		
4. Well Location Unit Letter	P : 760	feet from the	. C lina	and 7	760 feet from t	E	line	
Section	20 Township	21S		37E NM		County	LEA	
Section			OR, RKB,RT, GR,		r IVI	County	LEA	
	11. Elevation (5)		496' DF	<i>cic.</i>)				
	12. Check Appropriate Bo	v To Indicat	to Noture of Not	ica Dapart	or Other Date			
	• • •	ox 10 maica		•				
	OF INTENTION TO:				UENT REPORT			
PERFORM REMEDIAL WOI		=	REMEDIAL WOR		_	G CASING	}	
TEMPORARILY ABANDON			COMMENCE DR		S. P AND A			
PULL OR ALTER CASING	MULTIPLE COM	PL	CASING/CEMEN	II JOB				
DOWNHOLE COMMINGLE								
CLOSED-LOOP SYSTEM OTHER:			OTHER:					
	completed energions (C	1000111 01010 0		ila and aire	nautinant datas	نماییانم		
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated								
date of starting any proposed work.) SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram or								
proposed completion or re	ecompletion.							
4" diameter 4' tallabove ground marker								
Anacha Corneration n	ranges to DVA the above	n montiones	l wall by the att	ached proc	adura A alasa	d loop o	rotom will	
	roposes to P&A the above		-	-			Stelli Will	
be used for	all fluids from this wellbo	re and disp	osea or require	а ву ОСБ І	Rule 19.15.17.14	NIVIAC.		
Spud Date:			Rig Release Da	te:				
1	<u>,</u>		\mathcal{E}	<u> </u>				
Lhereby certify that the in	nformation above is true and	d complete t	o the best of my	knowledge	and belief			
Thereby certary that the h		a complete t	o the best of my	mio wieuge	and series.			
SIGNATURE	Guínn Burks	TITLE	Sr. Reclama	tion Forem	an DATE	11/	24/20	
- DIGITALI UKL	9000000000000	-	Oi. Necialla		— DAIL	1 17.	L-7/ LU	
T	Cuina Durles	D : 1 - 1 1	aution burden @ :	an a ab a s a se	oom DIIONE	420.5	EC 04.40	
Type or print name	Guinn Burks	_E-mail add.	guinn.burks@a	apacnecorp.	<u>.com</u> PHONE:	432-5	56-9143	
For State Use Only	14							
APPROVED BY: //	my tollner	TITLE	Compliance On	fficer A	DATE	11/30/20		
Conditions of Approval (if a	ny): d	_						



w/ 400 to surf

 LEASE NAME
 D.C. Hardy Gas Ut.

 WELL #
 #005

 API #
 30.025.06694

 COUNTY
 LEA, NM

18" Hole 133/8" 36# @ 374'

TOC @ 500' by TS

640

1280

0

1920

2560

11" Hole 8 5/8" 32# @ 2898' w/ 1200 sx, TOC @ 500' by TS

3200

3839

4479

5759

6399


5119 Production equi

Production equipment still in the hole, Unkn depth?

CIBP @ 5500' w/ no cmt

Stuck pkr @ 5811'

7 7/8" Hole 5 1/2" 15.5# @ 6399' w/ 800 sx, TOC @ 2780' by TS



Perfs @ 5320'-5340'

Perfs @ 5550'-5730'

Perfs @ 6205'-6290'



LEASE NAME	D.C. Hardy Gas Ut.	
WELL#	#005	
API#	30.025.06694	
COUNTY	I FA NM	

PROPOSED PROCEDURE

0

18" Hole 133/8" 36# @ 374' w/ 400 to surf

TOC @ 500' by TS

640

1280

1920

2560

11" Hole 8 5/8" 32# @ 2898' w/ 1200 sx, TOC @ 500' by TS

3200

3839

4479

NOTE: Prior to MIRU P&A rig, a WO rig will pull prod equipment, dumpbail 35' of cmt on the CIBP @ 5500', PUH & set another CIBP @ 5300', RDMO, for P&A rig.


CIBP @ 5500' w/ no cmt

5759

6399

Stuck pkr @ 5811'

7 7/8" Hole 5 1/2" 15.5# @ 6399' w/ 800 sx, TOC @ 2780' by TS



PBTD @ 5300' TD @ 6399' 6. PUH & perf @ 424' & sqz 300 sx Class "C" cmt from 424' to surf. Attmept to CIRC 5 1/2" & 8 5/8" to surf. (Surf Shoe, Water Board, & Surf Plug)

5. PUH & perf @ 1340' & sqz 70 sx Class "C" cmt from 1340'-1140', WOC/TAG (Top of Salt)

4. PUH & perf @ 2194' & sqz 70 sx Class "C" cmt from 2194'-1994', WOC/TAG (Base of Salt)

 PUH & perf @ 2948' & attempt to sqz 70 sx Class "C" cmt from 2948'-2748', WOC/TAG (Interm. Shoe)

2. PUH & spot 25 sx Class "C" cmt from 3563'-3347', (Penrose & Queen)

1. MIRU P&A rig, RIH w/ tbg & verify CIBP @ 5300', CIRC w/MLF & spot 25 sx Class "C" cmt. (Blinebry)

Perfs @ 5320'-5340'

Perfs @ 5550'-5730'

Perfs @ 6205'-6290'

CONDITIONS OF APPROVAL FOR PLUGGING AND ABANDONMENT OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at (575)-263-6633 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- **2.** Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- **3.** Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- **5.** A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can +be released.
- **6.** If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- **8.** Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- **10.** All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- **13.** A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- **14.** All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
- **16.** When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- **18.** A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

- **19.** No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
- A) Fusselman
- B) Devonian
- C) Morrow
- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- I) Glorieta
- J) Yates.
- K) Potash---(In the R-111-P Area (Potash Mine Area),

A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, woe 4 hours and tag, this plug will be SO' below the bottom and 50' above the top of the Formation.

21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, woe and tagged. These plugs will be set SO' below formation bottom to 50' above formation top inside the casing.

DRY HOLE MARKER REQ.UIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and Well Number
- 3. API Number
- 4. Unit letter
- 5. Quarter Section (feet from the North, South, East or West)
- 6. Section, Township and Range
- 7. Plugging Date
- 8. County

SPECIAL CASES ----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)