

Submit 1 Copy To Appropriate District
Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1600 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM
87505

HOBBS OGD

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

JUL 07 2014

CONSERVATION DIVISION

1220 South St. Francis Dr.
Santa Fe, NM 87505

RECEIVED

WELL API NO. 30-025-03388 ✓
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B0-0244
7. Lease Name or Unit Agreement Name GULF STATE ✓
8. Well Number 004
9. OGRID Number 10155 ✓
10. Pool name or Wildcat Eumont (Yates Seven Rivers Queen)
11. Elevation (Show whether DR, RKB, RT, GR, etc.) GL 3569

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator

Harvard Petroleum Company, LLC ✓

3. Address of Operator

PO Box 936, Roswell, NM 80202-0936

4. Well Location

Unit Letter K : 2310 feet from the South line and 2310 feet from the West line ✓

Section 1 Township 21S Range 35E NMPM County LEA

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
GL 3569

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐
CLOSED-LOOP SYSTEM ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐
OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. RU Pulling unit. Pull rods and pump, if any, and LD same.
2. Install BOP. Pull and visual inspect tubing.
3. TIH w bit and scraper to 100' above the perfs (3730 -3917')
4. TIH with CIBP and set same 90' above the perfs. TAG same.
5. Pull above the CIBP and circulate hole with 10# gelled brine and spot 25 sxs cement plug on top of CIBP.
6. If necessary, perf and squeeze 25 sxs cement at top of the salt (circulation show cement above salt top). NMOC directive needed. **→ @ 1500' & WOC & TAG**
7. Perf squeeze hole at base of 8 5/8" (268") and squeeze 35 sxs cement. WOC and TAG same. **CIRC CMT 318'-SURF.**
8. Set 10 sxs surface plug. Cut off well head. Install DH marker. RD and cut off anchors. Clean location to the satisfaction of surface owner and NMOC:

56. SPOT 25 SXS CMT @ 2890'

Conditions of Approval: PROVIDE WELL BORE DIAGRAM WITH SUBSEQUENT C-103

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE Agent DATE 07/07/2014

Type or print name M.Y. Merchant E-mail address: mymerch@petrocooil.com PHONE: 575-492-1236

For State Use Only

APPROVED BY: [Signature] TITLE Dist. Supervisor DATE 7/7/2014

Conditions of Approval (if any):

JUL 08 2014