	Submit 3 Copies To Appropriate District Office	State of New Mexico	Form C-103	
ADD(Energy, Minerals and Natural Resource	May 27, 2004	
هواز	1 3625 N. French Dr., Hobbs, NM 88240 <u>District II</u> 1301 W. Grand Ave. Artesia NM 88210 OIL CONSERVATION DIVISION		WELL API NO. 30-025-29340	
	1301 W. Grand Ave., Artesia, NM 88210	1220 South St. Francis Dr.	5. Indicate Type of Lease	
J T	1220 South St. Francis Dr. District IV 1220 South St. Francis Dr. Santa Fe, NM 87505 Santa Fe, NM 87505		STATE FEE	
			6. State Oil & Gas Lease No. E-1582	
ros (SUNDRY NOTICES AND REPORTS ON WELLS LO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 1. Type of Well: Oil Well Gas Well Other P&A'D 2. Name of Operator SUNDOWN ENERGY LP		7. Lease Name or Unit Agreement Name	
Rep.			THE SECTION OF THE SE	
			8. Well Number	
			9. OGRID Number 232611	
	3. Address of Operator		10. Pool name or Wildcat	
	13455 NOEL RD, STE. 2000, DALLAS, TX 75240 REEVES (QUEEN) 4. Well Location			
	Unit Letter A : 660 feet from the NORTH line and 660 feet from the EAST line			
	Section 28 Township 18S Range 35E NMPM County LEA			
	11. Elevation (Show whether DR, RKB, RT, GR, etc.)			
	3910.7' GR Pit or Below-grade Tank Application or Closure			
	Pit type Depth to Groundwater Distance from nearest fresh water well Distance from nearest surface water			
	Pit Liner Thickness: mil	Below-Grade Tank: Volume b	obls; Construction Material	
	12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data			
	NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK ☑ PLUG AND ABANDON □ REMEDIAL WORK ☐ ALTERING CASING □			
	PERFORM REMEDIAL WORK ☑ PLUG AND ABANDON ☐ REMEDIAL WORK ☐ ALTERING CASING ☐ TEMPORARILY ABANDON ☐ CHANGE PLANS ☐ COMMENCE DRILLING OPNS.☐ P AND A ☐			
	PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMENT JOB			
	OTHER: RE-ENTER P&A WELL 🛛 OTHER:			
	13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated dat of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.			
	1- Dig out old cellar- weld on 8 5/8" stub and nipple up well head & BOP			
	2- Pick up 7 7/8" bit and clean out cement plugs (surface and 341'-525') down to top			
	Of cut casing at 1375'.			
	3- Run mill and dress off 4 1/2" casing stub at 1375'			
	4- Run 4 ½" 10.5 casing patch with cementing ports- latch up on stub. Pump cement circulating to surface.			
	5- RIH with 3 ¾" bit and drill out cement and CIBP at 4472'- Clean out to 4550' +/			
	POH laying down work string.			
	6- Run 4 1/2" internally coated packer & 2 3/8" Internally coated tubing to			
	4422' (PERFS: 4472'-4488')- test for injectivity. Test annulus as required by State of New Mexico			
	7- Install injection line and place well in service.			
	I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below grade tank has been/will be constructed or closed according to NMOCD guidelines , a general permit or an (attached) alternative OCD-approved plan			
	SIGNATURE Selinda			
	Type or print name BELINDA B	RADLE E-mail address: bbradley@sundov	SST. DATE 03/25/2014 wnenergy.com Telephone No. 432-943-8770	
	For State Use Only			
	APPROVED BY: Conditions of Approval (if any):	TITLE	DATE	