

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

HOBBS OGD

FORM APPROVED
OMB NO. 1004-0135
Expires: July 31, 2010

SUNDRY NOTICES AND REPORTS ON WELLS
Do not use this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals.

DEC 22 2015

RECEIVED

SUBMIT IN TRIPLICATE - Other instructions on reverse side.

1. Type of Well <input checked="" type="checkbox"/> Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other		8. Well Name and No. WEST BLINEBRY DRINKARD UNIT 66 ✓
2. Name of Operator APACHE CORPORATION ✓ Contact: REESA FISHER E-Mail: Reesa.Fisher@apachecorp.com		9. API Well No. 30-025-06638 ✓
3a. Address 303 VETERANS AIRPARK LANE SUITE 3000 MIDLAND, TX 79705	3b. Phone No. (include area code) Ph: 432-818-1062	10. Field and Pool, or Exploratory EUNICE; B-T-D, NORTH
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) Sec 17 T21S R37E SENE 1980FNL 660FEL ✓		11. County or Parish, and State LEA COUNTY COUNTY, NM

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)	<input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input type="checkbox"/> Other
	<input type="checkbox"/> Change Plans	<input type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon	
	<input checked="" type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomple horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

This well was previously approved for CTI; however, the project had to be postponed. Apache would like to convert this well in the early part of 2016. Please see attached procedure and current and proposed WBD's.

*MUTT RUN MIT PRIOR TO
BEGINNING
RETURNING WELL TO INJECTION*

14. I hereby certify that the foregoing is true and correct. Electronic Submission #326506 verified by the BLM Well Information System For APACHE CORPORATION, sent to the Hobbs	
Name (Printed/Typed) REESA FISHER	Title SR STAFF REGULATORY ANALYST
Signature (Electronic Submission)	Date 12/16/2015

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved By _____	Title Accepted for Record Only	Date _____
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.	<i>REQUIRES BLM APPROVAL</i>	
	Office _____	

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

**** OPERATOR-SUBMITTED ** OPERATOR-SUBMITTED ** OPERATOR-SUBMITTED ****

DEC 31 2015 4/4/16

af

WBDU 66 (API: 30-25-06638) Proposed Procedure

Deepen Well, Run Liner, and Convert to Injection in the Drinkard Formation

May 1, 2014

Day 1: MIRU SR. POOH and LD pump and rods. ND WH and NU BOPs. POOH and LD 2-7/8" production tubing.

Day 2: PU & RIH w/CIBP on 2-7/8" work string. Set CIBP at +/-3600', POOH

MIRU WL, log well with GR/CBL/CCL from +/-3600' to surface, POOH. RIH w/ casing punch and perforate casing above TOC, POOH. Establish circulation behind 7" casing to surface

Day 3: PU & RIH w/ cement retainer on 2-7/8" work string and set retainer

MIRU cementers, cement 7" casing to surface with +/-650 sx (estimated, confirm volumes) of Class C cement (weight 14.8 ppg, yield 1.33 cf/sack). POOH w/ 2-7/8" work string

Day 4: PU & RIH w/ bit on 2-7/8" work string, drill out cement and cement retainer

Day 5: Continue to drill out cement and cement retainer, circulate well clean. POOH

MIRU WL, log well with GR/CBL/CCL from +/-3600' to surface, POOH

Day 6: RIH w/ 2-7/8" work string & bit. Drill out CIBP. RIH to 6610' and drill out cement to TD @ 6645', circulate LCM as necessary

Day 7: Cont. to drill out cement to TD @ 6645', drill well out to new TD @ +/-6780', circulate LCM as necessary

Day 8: Cont. to drill well out to new TD @ +/-6780', circulate LCM as necessary. Circulate wellbore clean and POOH and LD 2-7/8" work string

Day 9: MIRU WL, run GR/CNL/CBL/CCL log from PBTD to surface, POOH. Send logs to Midland

Day 10: RU casing crew and equipment and RIH with 4-1/2" 11.6 lb/ft LTC 8 RD J-55 casing with DV tool (set at +/- 5500'), float collar, and float shoe to +/- 6780'. Perform two stage cement job to surface as follows:

- a. Pump first stage consisting of 10 bbl fresh water flush, 40 bbl seal bond LCM spacer, and 195 sacks of 50:50 Fly Ash (Pozzolan):Class C cement + additives (weight 14.2 ppg, yield 1.31 cf/sack, volume 45.5 bbls, 50% excess slurry)
- b. Drop plug, displace with 105 bbl fresh water (confirm volumes) and bump plug. Drop dart, open DV tool
- c. Circulate through stage tool with fresh water until setting time for first cement stage has elapsed
- d. Pump second cement stage consisting of 20 bbl fresh water flush, lead slurry of 330 sacks 35:65 Fly Ash (Pozzolan):Class C cement + additives (weight 12.5 ppg, yield 2.13 cf/sack, 125.5 bbl), tail slurry of 100 sacks of class C cement + additives (weight 14.8 ppg, yield 1.33 cf/sack, 23.7 bbl)
- e. Drop DV tool plug, displace with 85.4 bbl fresh water (confirm volumes)

Day 11: WOC

Day 12: RIH w/ 3-3/4" bit on 2-3/8" work string. Drill out DV tool, float collar and cement to +/- 6765'. Circulate clean. POOH

Day 13: MIRU WL and RIH w/ GR/CBL/CCL, log well from TD to surface, POOH

PU and RIH w/ 3-3/8" TAGs loaded with SDP charges and perforate the Drinkard @ 4 SPF, 90 deg phasing (estimated 70', 280 shots), POOH

PU and RIH w/ treating packer on 2-3/8" work string

Day 14: Cont. RIH w/ treating packer on 2-3/8" work string. Set packer @ +/-6500'


MIRU acidizers. Acidize the Drinkard w/10,000 gals 15% HCl and rock salt in 3 equal stages @ +/- 8 BPM. Release packer. Wash out salt. POOH

Day 15: PU and RIH with 4-1/2" injection packer with 2-3/8" IPC tubing subs, upper and lower profile nipples, and on/off tool on 2-3/8" work string. Set packer @ +/-6500'. Release on/off tool and pressure test casing to 500 psi. POOH and LD 2-3/8" work string

Day 16: PU & RIH w/2-3/8" IPC injection tubing and on/off tool. Circulate packer fluid and latch onto packer with on/off tool. ND BOPs and NU WH. Pressure test casing to 500 psi. RDMO SR

Day 17: Perform MIT test for NM OCD. Place well on injection

Current Wellbore Diagram



Proposed Wellbore Diagram

