

Submit 1 Copy To Appropriate District Office
District I – (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II – (575) 748-1283
811 S. First St., Artesia, NM 88210
District III – (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV – (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-025-21800
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. NM 434
7. Lease Name or Unit Agreement Name State AK SWD
8. Well Number 001
9. OGRID Number 308397
10. Pool name or Wildcat SWD: Strawn

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other SWD-558-A
2. Name of Operator 06 SWD, LLC
3. Address of Operator P.O Box 553 Lovington, NM 88260
4. Well Location Unit Letter <u>N</u> : <u>660</u> feet from the <u>South</u> line and <u>1980</u> feet from the <u>West</u> line Section <u>10</u> Township <u>11S</u> Range <u>33E</u> NMPM Lea County
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 4262 GL

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐
CLOSED-LOOP SYSTEM ☐
OTHER: perforate ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐
OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. move in rig up pulling unit, unset packer and pull tubing
2. run bit and tubing to clean perforations
3. rig up wireline perforate approximately 40 holes at 9,500-10,151 ft
4. re run packer and tubing, set packer within 100 ft of 9,129 ft, circulate packer fluid
5. rig down pulling unit, acidize with 2000 gallons of acid
6. Notify OCD 24 hours prior to running MIT
7. Pressure test
8. Return well to injection

HOBBS OCD

OCT 12 2016

RECEIVED

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Beatrice Skaggs
Beatrice Skaggs

TITLE

Office manager
Petroleum Engineer

DATE

10/11/16

Type or print name
For State Use Only

E-mail address:

acd@acdoilfield

PHONE:

575 390 8591

APPROVED BY:

[Signature]

TITLE

DATE

10/12/16

Conditions of Approval (if any):