Submit 1 Copy To Appropriate District Office <u>District 1</u> – (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240	State of New Mexico Energy, Minerals and Natural Resources	Form C-103 Revised August 1, 2011 WELL API NO.
District II – (575) 748-1283 811 S. First St., Artesia, NM 88210 District III – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410 District IV – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM 87505	OIL CONSERVATION DIVISION 1220 South St. Francis Dr. Santa Fe, NM 87505	30-025-10784 5. Indicate Type of Lease STATE FEE XX ✓ 6. State Oil & Gas Lease No.
SUNDRY NOT (DO NOT USE THIS FORM FOR PROPO DIFFERENT RESERVOIR. USE "APPLIC PROPOSALS.) 1. Type of Well: Oil Well X	CES AND REPORTS ON WELLS SALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A CATION FOR PERMIT" (FORM C-101) FOR SUCH Gas Well Other /	7. Lease Name or Unit Agreement Name E.L. Steeler 8. Well Number 002
2. Name of Operator Yarbrough O	II D	9. OGRID Number
3. Address of Operator	769, Eunice, NM 88231	025504 / 10. Pool name or Wildcat / Langlie Mattix SR-QU-GB
4. Well Location		1
Unit Letter A :	660 feet from the North line and	660 feet from the East line
Section 17	Township 23S Range 37E	NMPM Lea County
	11. Elevation (Show whether DR, RKB, RT, GR, etc.)	
NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING DOWNHOLE COMMINGLE OTHER: 13. Describe proposed or comp of starting any proposed wo proposed completion or rec	PLUG AND ABANDON X CHANGE PLANS COMMENCE DRIN MULTIPLE COMPL CASING/CEMENT CASING/CEMENT CASING/CEMENT OTHER: leted operations. (Clearly state all pertinent details, and ork). SEE RULE 19.15.7.14 NMAC. For Multiple Com	SEQUENT R LLING OPNS. INT TO PA A X P&A NR P&A R P&A R d give pertinent dates, including estimated date mpletions: Attach wellbore diagram of HOBBS OCD AUG 3 0 2017 RECEIVED
1 A		
SIGNATURE	TITLEAgent	DATE
Type or print nameJohn R. Stearns, Jr E-mail address:bobbystearns1@yahoo.com_ PHONE: 575-760-2482 For State Use Only		
APPROVED BY: Malli Conditions of Approval (if any):	Kitchen_TITLE P.E.S.	DATE 08/30/2017

NOTIFY OCD 24 HOURS PRIOR TO BEGINNING PLUGGING OPERATIONS

P&A Procedures E.L. Steeler #2 30-025-10784

- 1. Lay rods and POOH with tubing.
- 2. Pick up bit and collars. Drill out existing cement plug from approximately 3700' to 4000'. RIH with bit to 7198'.
- 3. Set 7" CIBP at 7100' Circulate MLF and test casing. Spot 25 sx Class H cement on top of CIBP.
- 4. Spot 35 sx cement across 9 5/8" casing shoe from 3931'. WOC and tag above 3831'
- 5. Set 7" CIBP at 2890'. Spot 25 sx cement on top of CIBP.
- 6. Perf and squeeze 7" casing at 2545' with 40 sx cement. WOC and tag at 2445' or higher. Base Salt Plug.
- 7. Spot 25 sx across casing patch at 1620' from 1670' to 1570'. WOC and tag at above 1570'.
- 8. Perf and squeeze 7" casing at 1168' with 40 sx cement. WOC and tag. Top Salt Plug.
- 9. Perforate 7" casing at 305'. Establish circulation and pump cement down 7" casing to perfs at 305' and up annulus to surface. Cut off wellhead and make sure cement is to surface in both strings of casing. Install marker and cut off anchors.

All fluids will be circulated to at steel pit.



