

#### H₂S Contingency Plan November 2016

H<sub>2</sub>S Contingency Plan Holders:

Attached is an H<sub>2</sub>S Contingency Plan for COPC Permian Drilling working in the West Texas and Southeastern New Mexico areas operated by ConocoPhillips Company.

If you have any question regarding this plan, please call Matt Oster (830) 583-1297, or Ryan Vacarella (985) 217-7594.

1278 M. Frankling Car.

## **Table of Contents**

#### **Section**

- I. Purpose
- II. Scope
- III. Procedures
- IV. Emergency Equipment and Maintenance

Emergency Equipment Suppliers
General Information
H2S Safety Equipment and Monitoring Systems

- V. Emergency Call List
- VI. Public/Media Relations
- VII. Pubic Notification/Evacuation
- VIII. Forms/Reports



# HYDROGEN SULFIDE (H<sub>2</sub>S) OPERATIONS

HOBBS OCD

NOV 27 2017

Contingency Plan
For
Permian Drilling Operations

RECEIVED

ConocoPhillips Company

## Mid-Continent Business Unit Permian Asset Area

#### **I.PURPOSE**

The purpose of this Contingency Plan is to provide an organized plan of action for alerting and protecting the public following the release of a potentially hazardous volume of hydrogen sulfide. This plan prescribes mandatory safety procedures to be followed in the event of a release of  $H_2S$  into the atmosphere from exploration and production operations included in the scope of this plan. The extent of action taken will be determined by the supervisor and will depend on the severity and extent of  $H_2S$  release. Release of  $H_2S$  must be reported to the Drilling Superintendent and documented on the IADC and in Wellview.

#### II. SCOPE

This Contingency plan shall cover the West Texas and Southeastern New Mexico areas, which contain H2S gas and could result in a release where the R.O.E. is greater than 100 ppm at 50' and less than 3000' and does not include a public area and 500 ppm R.O.E. does not include a public road. Radius of exposure is defined as the maximum distance from the source of release that a specified calculated average concentration of  $H_2S$  could exist under specific weather conditions.

## III. PROCEDURES

First Employee on Scene
Assess the incident and ensure your own safety.
Note the following:
<ul> <li>Location of the incident.</li> <li>Nature of the incident.</li> <li>Wind direction and weather conditions.</li> <li>Other assistance that may be needed.</li> </ul>
Call local supervisory personnel (refer to Section V: Emergency Call List until personal contact is made with a person on the list.
Perform emergency assessment and response as needed. The response may include rescue and/or evacuation of personnel, shutting in a system and/or notification of nearby residents/public (refer to Section VII: Public Notification/Evacuation).
Secure the site.
Follow the direction of the On-scene Incident Commander (first ConocoPhillips supervisor arriving on-scene).
First Supervisor on Scene (ConocoPhillips On-scene Incident Commander)
Becomes ConocoPhillips' On-scene Incident Commander upon arrival to location.
<ul> <li>Follow the principles of the <b>D.E.C.I.D.E.</b> process below to assess the incident. (Note wind direction and weather conditions and ensure everyone's safety).</li> </ul>
DETECT the problem ESTIMATE likely harm without intervention CHOOSE response objectives IDENTIFY action options DO the best option

	nary Emergency Information Sheet III: Forms/Reports).
Call your supervisor (	refer to Section V: Emergency Call List).
notification & evacua (refer to Section VII: assistance from Con Section V: Emergence	esponse as necessary. (This may include ation of all personnel and/or nearby residents/public Public Notification/Evacuation), requesting accoPhillips personnel or outside agencies (refer to cy Call List) and obtaining any safety equipment that fer to Section IV: Emergency Equipment and
	ocal emergency response agencies of the incident as the appropriate regulatory agencies. (refer to Section List).
Ensure site security.	
ppm H₂S radius	and /or warning signs at or beyond the calculated 100 of exposure (ROE). All manned barricades must be $n\ H_2S$ monitor and a 2-way radio.
Set roadblocks	and staging area as determined.
Establish the Incider scene response pers	nt Command Structure by designating appropriate onsonnel as follows:
Recording Secretary Public Information O Safety/Medical Office Decontamination Off	erer
	g Secretary" begin documenting the incident on the to Section VIII: Forms/Reports).
· · · · · · · · · · · · · · · · · · ·	adio silence on all channels that use your radio tower ther notice, the channels should be used for sications only.
Perform a Site Chara	acterization and designate the following:
Warm Zone	Hazardous Area Preparation & Decontamination Area Safe Area

## <u>AND</u>

	On-Scene Incident Command Post Public Relations Briefing Area Staging Area	(Cold Zone) (Cold Zone) (Cold Zone)
	Triage Area	(Cold Zone)
	Decontamination Area	(Warm Zone)
	_Refer all media personnel to ConocoPhillips' On-Scene Publ Officer (refer to Section VI: Public Media Relations).	ic Information
	Coordinate the attempt to stop the release of H <sub>2</sub> S. You show closing upstream and downstream valves to shut-off gas sure and/or plugging or clamping leaks. Igniting escaping gas to toxicity hazard should be used <b>ONLY AS A LAST RESORT</b> be determined if the gas can be safely ignited, taking into continuous approach to a possibility of a widespread flammable atmosphere	pply sources, reduce the f. (It must first onsideration if
	_Once the emergency is over, return the situation to normal b	y:
	Confirming the absence of H <sub>2</sub> S and combustible gas the area,	nroughout the
	Discontinuing the radio silence on all channels, stating emergency incident is over,	that the
	Removing all barricades and warning signs,	
	Allowing evacuees to return to the area, and	
	Advising all parties previously notified that the emerge	ncy has ended.
————	Ensure the proper regulatory authorities/agencies are notified incident (refer to Section V: Emergency Call List).	d of the
,	Clean up the site. (Be sure all contractor crews have had an HAZWOPER training.)	propriate
	Report completion of the cleanup to the Asset Environmental (Environmentalist will report this to the proper State and/or Fagencies.)	

Fill out all required incident reports and send originals to the Safety Department. (Keep a copy for your records.)

- · Company employee receiving occupational injury or illnesses.
- Company employee involved in a vehicle accident while driving a company vehicle.
- · Company property that is damaged or lost.
- Accident involving the public or a contractor; includes personal injuries, vehicle accidents, and property damage. Also includes any situation, which could result in a claim against the Company.
- Hazardous Material Spill/Release Report Form
- Emergency Drill Report

Assist the Safety Department in the investigation of the incident. Review the factors that caused or allowed the incident to occur, and modify operating, maintenance, and/or surveillance procedures as needed. Make appropriate repairs and train or retrain employees in the use and operation of the system.

If this incident was simulated for practice in emergency response, complete the Emergency Drill Report found in Section VIII: Forms/Reports and submit a copy to the Drilling Manager. (Keep one copy in area files to document exercising of the plan.)

## Emergency Procedures Responsibility

In the event of a release of potentially hazardous amounts of H2S, all personnel will immediately proceed upwind/ crosswind to the nearest designated briefing area. The COPC Drilling Rep. will immediately, upon assessing the situation, set this into action by taking the proper procedures to contain the gas and notify appropriate people and agencies.

- In an emergency situation, the Drilling Rep. on duty will have complete responsibility and will take whatever action is deemed necessary in an emergency situation to insure the personnel's safety, to protect the well and to prevent property damage.
- 2. The Toolpusher will assume all responsibilities of the Drilling Rep. in an emergency situation in the event the Drilling Rep. becomes incapacitated.
- 3. Advise each contractor, service company, and all others entering the site that H2S may be encountered and the potential hazards that may exist.
- 4. Authorize the evacuation of local residents if H2S threatens their safety.
- Keep the number of persons on location to a minimum during hazardous operations.
- 6. Direct corrective actions to control the flow of gas.
- 7. Has full responsibility for igniting escaping gas to reduce the toxicity hazard.

This should be used **ONLY AS A LAST RESORT**.

Courselle & R. G. Febru

型 ( **指::3**0.0 ( 10) 4.0 ( )

· 医细胞性 医结合性 医

#### IV. **EMERGENCY EQUIPMENT and MAINTENANCE**

#### **Emergency Equipment Suppliers**

DXP/ Safety International - Odessa, Tx.

432.580.3770 H<sub>2</sub>S monitors (a) the second of the second **必以推动。《新生》** 

Breathing air includes cascade systems

First aid and medical supplies Safety equipment

**H2S Specialist** 

432.561.5049 Odessa Total Safety US Odessa, Tx/ Hobs, NM

H<sub>2</sub>S monitors 575.392.2973 Hobbs

Breathing air includes cascade systems

First aid and medical supplies Safety equipment

क्षा हो असे देश है के में की अपने के अपने के DXP/ Indian Fire & Safety - Hobbs, NM 575.393.3093

H<sub>2</sub>S monitors

Breathing air including cascade systems trailer mounted

30 minute air packs

Safety Equipment

TC Safety - Odessa, Tx.

H<sub>2</sub>S monitors

Cascade systems trailer mounted

30 minute air packs Safety Equipment

H2S Specialist

Secorp Industries - Odessa: Tx. 432.614.2565

H2S Monitor Systems

Cascade Systems

H2S Specialist

H2S, CPR, First Aid Training

#### **Emergency Equipment and Maintenance (continued)**

#### General Information

Materials used for repair should be suitable for use where H<sub>2</sub>S concentrations exceed 100 ppm. In general, carbon steels having low-yield strengths and a hardness below RC-22 are suitable. The engineering staff should be consulted if any doubt exists on material specifications.

Appropriate signs should be maintained in good condition at location entrance and other locations as specified in Texas Rule 36 and NMOCD Rule 118.

All notification lists should be kept current with changes in names, telephone numbers, etc.

All shutdown devices, alarms, monitors, breathing air systems, etc., should be maintained in accordance with applicable regulations.

All personnel working in  $H_2S$  areas shall have received training on the hazards, characteristics, and properties of  $H_2S$ , and on procedures and safety equipment applicable for use in  $H_2S$  areas.

#### **H2S Safety Equipment and Monitoring Systems**

An H2S emergency response package will be maintained at locations requiring H2S monitoring. The package will contain at a minimum the following:

- 3 Fixed H2S sensors located as follows:
  - 1 on the rig floor
  - 1 at the Bell Nipple
  - 1 at the Shale Shaker or Flowline
- 1 <u>Entrance Warning Sign</u> located at the main entrance to the location, with warning signs and colored flags to determine the current status for entry into the location.
- 2 Windsocks that are clearly visible.
- 1 Audible warning system located on rig floor
- 2 Visual warning systems (Beacon Lights)
  - 1 Located at the rig floor
  - 1 Located in the mud mixing room

#### Note: All alarms (audible and visual) should be set to alarm at 10 ppm.

- 2 Briefing areas clearly marked
  - 2 SCBA's at each briefing area
  - 1- SCBA located at the Drilling Reps office

#### Note:

- 1. All SCBA's must be positive pressure type only!!!
- 2. All SCBA's must either be Scott or Drager brand.
- 3. All SCBA's face pieces should be <u>size large</u>, unless otherwise specified by the Drilling Supervisor.
- 5 Emergency Escape Paks located at Top Doghouse.

Note: Ensure provisions are included for any personnel working above rig floor in derrick.

Zia Hills 19 Pad #1

1 – <u>Tri or Quad gas monitor located at the Drilling Reps office.</u> This will be used to determine if the work area if safe to re-enter prior to returning to work following any alarm.

#### V. EMERGENCY CALL LIST:

The following is a <u>priority</u> list of personnel to contact in an emergency situation:

**Supervisory Personnel** Office No. Cellphone Drilling Supt. (Unconventional) **Scott Nicholson** 432.688.9065 432.230.8010 Field Superintendents: Clint Case. 432.688.6878 940.231.2839 Safety Support: **Matt Oster** 830.583.1245 601.540.6988 Ryan Vaccarella 985.217.7594 NA Supt Operations-SEMN/Shale Mike Neuschafer 432.688.6834 713.419.9919 MCBU Safety Coordinator James Buzan 432.688.6860 832.630.4320 Manger GCBU/MCBU D & C Seth Crissman 832.486.6191 832.513.9308

## **EMERGENCY CALL LIST: State Officials**

#### **Regulatory Agencies**

Texas Railroad Commission (District 8)

Midland, Texas

Office: 432.684.5581

New Mexico Oil Conservation Commission

P. O. Box 1980

Hobbs, New Mexico 88240-1980

Office: 575.393.6161

**Bureau of Land Mngt.** 

Carlsbad Field Office 620 E. Greene St. Carlsbad, NM 88220

Office: 575.234.5972 Fax: 575.885.9264

### **EMERGENCY CALL LIST: Local Officials**

Refer to the Location Information Sheet
Note: The LIS should include any area residents (i.e. rancher's house, etc)

#### VI. Public Media Relations

The **Public Information Officer** becomes the ConocoPhillips on-scene contact (once designated by the Phillips On-Scene Incident Commander).

Confers with Houston Office's Human Relations Representative, who is responsible for assisting in the coordination of local public relations duties.

Answer media questions honestly and <u>only with facts</u>, do not speculate about the cause, amount of damage, or the potential impact of the incident of the community, company, employees, or environment. (This information will be formally determined in the incident investigation.)

If you are comfortable answering a question or if you are unsure of the answer, use terms such as the following:

- "I do not know. I will try to find out."
- I am not qualified to answer that question, but I will try to find someone who can."
- "It is under investigation."

#### Note:

**Do Not** Say "No Comment." (This implies a cover-up.)

**Do Not Disclose Names of Injured or Dead!** Confer with the Houston Office's Human Relations Representative, who is responsible for providing that information.

#### VII. Public Notification/Evacuation

Alert and/or Evacuate People within the Exposure Area

1. <u>Public Notification</u> – If the escape of gas could result in a hazard to area residents, the general public, or employees, the person <u>first</u> observing the leak should take <u>immediate</u> steps to cause notification of any nearby residents. The avoidance of injury or loss of life should be of prime consideration and given top priority in all cases. If the incident is of such magnitude, or at such location as to create a hazardous situation, local authorities will be requested to assist in the evacuation and roadblocks of the designated area until the situation can be returned to normal.

Note: Bilingual employees may be needed to assist in notification of residents.

2. Evacuation Procedures – Evacuation will proceed upwind from the source of the release of H<sub>2</sub>S. Extreme caution should be exercised in order to avoid any depressions or low-lying areas in the terrain. The public area within the radius of exposure should be evacuated in a southwesterly and southeasterly direction so as to avoid the prevailing southern wind direction.

Roadblocks and the staging area should be established as necessary for current wind conditions.

**Note:** In all situations, consideration should be given to wind direction and weather conditions.  $H_2S$  is heavier than air and can settle in low spots. Shifts in wind direction can also change the location of possible hazardous areas.

#### VIII. FORMS & REPORTS

- I. Incident Log
- II. Preliminary Emergency Information Sheet
- III. Emergency Drill Report
- IV. Onshore Hazardous Material Spill/Release Report Form
- V. Immediate Report of Occupational Injury or Illness Report of Accident-Public Contractor Report of Loss or Damage to Company Property Report of Automotive Incident