Form 3160-5 (June 2015)	FORM APPROVED OMB NO. 1004-0137						
DE	PARTMENT OF THE I				Expires: Jan		
SUNDRY NOTICES AND REPORTS ON WELLS					5. Lease Serial No. NMNM26394		
Do not use this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals.					6. If Indian, Allottee or Tribe Name		
			LICO	000			
SUBMIT IN 1	RIPLICATE - Other inst	tructions on p	bage 2	OCD	7. If Unit or CA/Agree	ment, Nam	ie and/or No.
<ol> <li>Type of Well</li> <li>☐ Oil Well</li></ol>	8. Well Name and No. VACA DRAW 20-17 FEDERAL 1H						
2. Name of Operator CIMAREX ENERGY COMPAN	TERECEN	9. API Well No. 30-025-44135-0			D-S1		
3a. Address		3b. Phone No.	(include area code)		10. Field and Pool or Exploratory Area		
600 N. MARIENFELD SUITE MIDLAND, TX 79701	600	Ph: 918.56	0.7060	WILDCAT;WOLFCAMP			
4. Location of Well (Footage, Sec., T.	, R., M., or Survey Description	1)			11. County or Parish, S	State	
Sec 20 T25S R33E SWSW 39 32.109901 N Lat, 103.600945	1		LEA COUNTY, NM				
12. CHECK THE AL	PPROPRIATE BOX(ES)	TO INDICA	TE NATURE OF	F NOTICE,	REPORT, OR OTH	ER DA	ГА
TYPE OF SUBMISSION			TYPE OF	ACTION			
D Nation of Internet	Acidize	Dee	pen	Product	ion (Start/Resume)	U Wat	ter Shut-Off
☑ Notice of Intent	Alter Casing	🗖 Hyd	raulic Fracturing	Reclam	ation	U We	ll Integrity
Subsequent Report	Casing Repair	New	Construction	Recom	plete	Oth	er
Final Abandonment Notice	Change Plans	D Plug	and Abandon	Tempor	rarily Abandon	PD	e to Original A
	Convert to Injection	D Plug	Back	U Water I	Disposal		
If the proposal is to deepen direction: Attach the Bond under which the wo following completion of the involved testing has been completed. Final Al determined that the site is ready for f Cimarex respectfully requests See attached procedure.	rk will be performed or provide l operations. If the operation re bandonment Notices must be fi inal inspection.	e the Bond No. or esults in a multipl led only after all	a file with BLM/BIA e completion or reco requirements, include	. Required su mpletion in a ing reclamation	bsequent reports must be new interval, a Form 316 n, have been completed a	filed with	in 30 days be filed once
Please update the COAs to re	eflect the approved Surfa	ce casing as 1	0-3/4".				
and the second se	11 24.241				,		
			2		a		
OCD Hohh	S	13			\$		
		1	CCD H	lobbs	5		
14. I hereby certify that the foregoing is	Electronic Submission #	4398014 verifie	d by the BLM Wel	I Informatio	n System		
Co	For CIMARES mmitted to AFMSS for pro	X ENERGY CO ocessing by Z0	MPÁNY, sent to t TA STEVENS on	he Hobbs 12/18/2017 (	18ZS0029SE)		
Name (Printed/Typed) ARICKA				ATORY AN			
Signature (Electronic S	Submission)		Date 12/14/20	017			
	THIS SPACE FO	OR FEDERA	L OR STATE	OFFICE U	SE		
							101101000
Approved By_ZQTA_STEVENS			TitlePETROLE	EER	D	ate 12/18/2017	
Conditions of approval, if any, are attached. Approval of this notice does not warrant certify that the applicant holds legal or equitable title to those rights in the subject least							
which would entitle the applicant to condu			Office Hobbs				
Title 18 U.S.C. Section 1001 and Title 43 States any false, fictitious or fraudulent	U.S.C. Section 1212, make it a statements or representations a	a crime for any pe s to any matter w	rson knowingly and ithin its jurisdiction.	willfully to m	ake to any department or	agency of	the United
(Instructions on page 2)	ISED ** BLM REVISE					D **	1/2/
	ISED DLIVI KEVISE		VIGED BLW	I REVISEL			K



# Cimarex 10M Well Control Plan

Version 1.0

# **BOPE Preventer Utilization**

The table below displays all BHA components, drill pipe, casing, or open hole that could be present during a required shut in and the associated preventer component that would provide a barrier to flow. It is specific to the hole section that requires a 10M system. The mud system being utilized in the hole will always assumed to be the first barrier to flow. The below table, combined with the mud program, documents that two barriers to flow can be maintained at all times, independent of the rating of the annular preventer.

Drill String Element	OD	Preventer	RWP
4" Drillpipe	4″	Lower Ram 3 1/2" - 5 ½" VBR* Upper Ram 3 1/2" - 5 ½" VBR*	10M
4.5" Drillpipe	4.5"	Lower Ram 3 1/2" - 5 ½" VBR* Upper Ram 3 1/2" - 5 ½" VBR*	10M
4" HWDP Drillpipe	4"	Lower Ram 3 1/2" - 5 ½" VBR* Upper Ram 3 1/2" - 5 ½" VBR*	10M
4.5" HWDP Drillpipe	4.5"	Lower Ram 3 1/2" - 5 ½" VBR* Upper Ram 3 1/2" - 5 ½" VBR*	10M
Drill Collars (including non- magnetic)	4.75- 5.25″	Lower Ram 3 1/2" - 5 ½" VBR* Upper Ram 3 1/2" - 5 ½" VBR*	10M
Production Casing	5.5"	Lower Ram 3 1/2" - 5 ½" VBR* Upper Ram 3 1/2" - 5 ½" VBR*	10M
Production Casing	5″	Lower Ram 3 1/2" - 5 ½" VBR* Upper Ram 3 1/2" - 5 ½" VBR*	10M
Production Casing	4.5"	Lower Ram 3 1/2" - 5 ½" VBR* Upper Ram 3 1/2" - 5 ½" VBR*	10M
ALL	0-13 5/8"	Annular	5M
Open Hole		Blind Rams	10M

\*VBR – Variable Bore Ram

# **Well Control Procedures**

Proper well control response is highly specific to current well conditions and must be adapted based on environment as needed. The procedures below are given in "common" operating conditions to cover the basic and most necessary operations required during the wellbore construction. These include drilling ahead, tripping pipe, tripping BHA, running casing, and pipe out of the hole/open hole. In some of the procedures below, there will be a switch of control from the lesser RWP annular to the appropriate 10M RWP ram. The pressure at which this is done is variable based on overall well conditions that must be evaluated situationally. The pressure that control is switched may be equal to or less than the RWP but at no time will the pressure on the annular preventer exceed the RWP of the annular. The annular will be tested to 5,000 psi. This will be the RWP of the annular preventer.

### Shutting In While Drilling

- 1. Sound alarm to alert crew
- 2. Space out drill string
- 3. Shut down pumps
- 4. Shut in uppermost BOPE preventer (typically the annular preventer) and open HCR.
- 5. Verify well is shut-in and flow has stopped
- 6. Notify supervisory personnel
- 7. Record data (SIDP, SICP, Pit Gain, and Time)
- 8. Hold pre-job safety meeting and discuss kill procedure

 If pressure is anticipated to climb to the RWP of the annular preventer during kill procedure, swap control of the well to the upper pipe ram

## Shutting In While Tripping

- 1. Sound alarm and alert crew
- 2. Install open, full open safety valve and close valve
- 3. Shut in uppermost BOPE preventer (typically the annular preventer) and open HCR.
- 4. Verify well is shut-in and flow has stopped
- 5. Notify supervisory personnel
- 6. Record data (SIDP, SICP, Pit Gain, and Time)
- 7. Hold pre-job safety meeting and discuss kill procedure
- 8. If pressure is anticipated to climb to the RWP of the annular preventer during kill procedure, swap control of the well to the upper pipe ram

## Shutting In While Running Casing

- 1. Sound alarm and alert crew
- 2. Install circulating swedge. Close high pressure, low torque valves.
- 3. Shut in uppermost BOPE preventer (typically the annular preventer) and open HCR.
- 4. Verify well is shut-in and flow has stopped
- 5. Notify supervisory personnel
- 6. Record data (SIDP, SICP, Pit Gain, and Time)
- 7. Hold Pre-job safety meeting and discuss kill procedure
- 8. If pressure is anticipated to climb to the RWP of the annular preventer during kill procedure, swap control of the well to the upper pipe ram

#### Shutting in while out of hole

- 1. Sound alarm
- 2. Shut-in well: close blind rams
- Verify well is shut-in and monitor pressures
- 4. Notify supervisory personnel
- 5. Record data (SIDP, SICP, Pit Gain, and Time)
- 6. Hold Pre-job safety meeting and discuss kill procedure

#### Shutting in prior to pulling BHA through stack

- 1. Prior to pulling last joint of drill pipe thru the stack space out and check flow. If flowing see steps below.
- 2. Sound alarm and alert crew
- 3. Install open, full open safety valve and close valve
- 4. Shut in upper pipe ram and open HCR.

- 5. Verify well is shut-in and flow has stopped
- 6. Notify supervisory personnel
- 7. Record data (SIDP, SICP, Pit Gain, and Time)
- 8. Hold pre-job safety meeting and discuss kill procedure

Shutting in while BHA is in the stack and ram preventer and combo immediately available

1. Sound alarm and alert crew

- 2. Stab Crossover and install open, full open safety valve and close valve
- 3. Space out drill string with upset just beneath the compatible pipe ram.
- 4. Shut in upper compatible pipe ram and open HCR.
- 5. Verify well is shut-in and flow has stopped
- 6. Notify supervisory personnel
- 7. Record data (SIDP, SICP, Pit Gain, and Time)
- 8. Hold pre-job safety meeting and discuss kill procedure

## Shutting in while BHA is in the stack and no ram preventer or combo immediately available

- 1. Sound alarm and alert crew
- 2. If possible pick up high enough, to pull string clear and follow "Open Hole" scenario
- 3. If not possible to pick up high enough:
  - 1. Stab Crossover, make up one joint/stand of drill pipe, and install open, full open safety valve and close valve
- 4. Space out drill string with upset just beneath the compatible pipe ram.
- 5. Shut in upper compatible pipe ram and open HCR.
- 6. Verify well is shut-in and flow has stopped
- 7. Notify supervisory personnel
- 8. Record data (SIDP, SICP, Pit Gain, and Time)
- 9. Hold pre-job safety meeting and discuss kill procedure