Form 3160-5 (June 2015)

Form 3160-5 (June 2015)	DE BU	UNITED STATES PARTMENT OF THE IN UREAU OF LAND MANAGE NOTICES AND REPORT S form for proposals to I. Use form 3160-3 (API	S NTERIOR GEMENT	- ABS	ocp	OMB N	APPROVED D. 1004-0137 unuary 31, 2018
	SUNDRY I	NOTICES AND REPOR s form for proposals to l. Use form 3160-3 (API	RTS ON Wi	en Heabbs	6 2018	NMNM122622	r Taiba Nama
	abandoned wel	I. Use form 3160-3 (API	D) for such p	proposals	MED	6. If Indian, Allottee of	r Tribe Name
	SUBMIT IN T	RIPLICATE - Other inst	ructions on	page 2 REC	Ela	7. If Unit or CA/Agree	ement, Name and/or No.
1. Type of Well ☑ Oil Well	Gas Well Oth					8. Well Name and No. DOGWOOD 23 F	ED COM 702H
Name of Operator EOG RESOUR		Contact: E-Mail: stan_wagn	STAN WAGN er@eogresour			9. API Well No. 30-025-44074	
3a. Address ATTN: STAN MIDLAND, TX	WAGNER P.O. E 79702	BOX 2267	3b. Phone No Ph: 432-68	6. (include area code) 66-3689) .	10. Field and Pool or 1 WC-025 S2633	Exploratory Area 27G UPPER WC
4. Location of Well	(Footage, Sec., T.	, R., M., or Survey Description,)			11. County or Parish,	State
Sec 23 T26S I	R33E Mer NMP	SESE 200FSL 604FEL		(LEA COUNTY,	NM
12. C	HECK THE AP	PROPRIATE BOX(ES)	TO INDICA	TE NATURE O	F NOTICE,	REPORT, OR OTH	IER DATA
TYPE OF SUI	BMISSION			TYPE O	F ACTION		,
Notice of Inte	ent	☐ Acidize	□ Dee	pen	☐ Product	ion (Start/Resume)	☐ Water Shut-Off
_		☐ Alter Casing	☐ Hyo	Iraulic Fracturing	☐ Reclama	ation	☐ Well Integrity
☐ Subsequent I		☐ Casing Repair		v Construction	□ Recomp		☑ Other Change to Original A
☐ Final Abando	onment Notice	Change Plans		g and Abandon		oraniy Abandon PD	
14.5		Convert to Injection	Plu		□ Water D	_	
If the proposal is Attach the Bond u following comple testing has been c	to deepen directiona inder which the wor tion of the involved	ration: Clearly state all pertiner illy or recomplete horizontally, k will be performed or provide operations. If the operation re- andonment Notices must be fil- nal inspection.	give subsurface the Bond No. o sults in a multip	locations and measure file with BLM/BIA le completion or received.	ared and true ve A. Required sub ompletion in a r	rtical depths of all perting esequent reports must be new interval, a Form 316	ent markers and zones. filed within 30 days 0-4 must be filed once
EOG Resourc design as atta		amendment to our approv	red APD for t	his well to reflect	t a change in	casing	
	OG Resources or drilling this we	requests a variance of the	e 10,000 psi	annular			
EOG Resourc Specific detail	es will use 5000 s attached.	psi annular BOP with a 1	10,000 psi sta	ack.			
We	Walve	do daled	5				,
14. I hereby certify	that the foregoing is	Electronic Submission #3 For EOG R	393617 verifie RESOURCES,	d by the BLM We	Il Information Hobbs	System	
Name (Printed/Ty	ped) STAN WA	Committed to AFMSS fo GNER	r processing		ATORY AN	11 " / /	
Signature	(Electronic S	uhmission) "		Date 10/31/2	EPTED F	OR RECORD	1
Digitatare	(Diotal of the	THIS SPACE FO	R FEDER			SEA	
			,		FED	9 2918	2
Approved By				Title	Chu on the		Date
Conditions of approva certify that the applica which would entitle th	nt holds legal or equ	d. Approval of this notice does itable title to those rights in the ct operations thereon.	not warrant or e subject lease	Office	CARLSBAD F	ELD OFFICE	
Title 18 U.S.C. Section States any false, ficti	n 1001 and Title 43	U.S.C. Section 1212, make it a statements or representations as	crime for any p	rson knowingly and	willfully to ma	ke to any department or	gency of the United

Revised Permit Information 10/31/17:

Well Name: Dogwood 23 Fed Com No. 702H

Location:

SL: 200' FSL & 604' FEL, Section 23, T-26-S, R-33-E, Lea Co., N.M. BHL: 230' FNL & 843' FEL, Section 14, T-26-S, R-33-E, Lea Co., N.M.

Casing Program:

Hole Size	Interval	Csg OD	Weight	Grade	Conn	DF _{min} Collapse	DF _{min} Burst	DF _{min} Tension
17.5"	0 - 1,040	13.375"	54.5#	J55	STC	1.125	1.25	1.60
12.25"	0-4,000'	9.625"	40#	J55	LTC	1.125	1.25	1.60
12.25"	4,000' - 5,100'	9.625"	40#	HCK55	LTC	1.125	1.25	1.60
8.75"	0-11,600	7.625"	29.7#	HCP-110	FlushMax III	1.125	1.25	1.60
6.75"	0'-22,572'	5.5"	20#	HCP-110	VAM SFC	1.125	1.25	1.60

Cement Program:

	No.	Wt.	Yld	Water				
Depth	Sacks	lb/gal	Ft ³ /ft	Gal/sk	Slurry Description			
1,040'	600	13.5	1.74	9.13	Lead: Class 'C' + 4.00% Bentonite + 2.00% CaCl2			
					(TOC @ Surface)			
	300	14.8	1.35	6.34	Tail: Class 'C' + 0.6% FL-62 + 0.25 lb/sk Cello-Flake +			
					0.2% Sodium Metasilicate + 2.0% KCl (1.06 lb/sk)			
5,000'	1780	12.7	2.20	11.64	Lead: Class C + 0.15% C-20 + 11.63 pps Salt + 0.1% C-51			
					+ 0.75% C-41P (TOC @ Surface)			
	200	16.0	1.12	4.75	Tail: Class C + 0.13% C-20			
11,600'	340	11.5	2.72	15.70	Lead: Class C + 0.40% D013 + 0.20% D046 + 0.10% D065			
					+ 0.20% D167 (TOC @ 4,500')			
	210	16.0	1.12	4.74	Tail: Class H + 94.0 pps D909 + 0.25% D065 + 0.30%			
					D167 + 0.02% D208 + 0.15% D800			
22,572'	950	14.1	1.26	5.80	Class H + 0.1% C-20 + 0.05% CSA-1000 + 0.20% C-49 +			
		,			0.40% C-17 (TOC @ 11,100')			

Mud Program:


Depth	Type	Weight (ppg)	Viscosity	Water Loss
0 – 1,040'	Fresh - Gel	8.6-8.8	28-34	N/c
1,040' - 5,100'	Brine	10.0-10.2	28-34	N/c
5,100'-11,600'	Oil Base	8.7-9.4	58-68	N/c - 6
11,600'- 22,572' Lateral	Oil Base	10.0-11.5	58-68	3 - 6

Dogwood 23 Fed Com #702H Lea County, New Mexico

200' FSL 604' FEL Section 23 T-26-S, R-33-E

Proposed Wellbore Revised 10/31/17 API: 30-025-44074

KB: 3,356' GL: 3,331'



Lateral: 22,574' MD, 12,500' TVD
Upper Most Perf:
330' FSL & 843' FEL Sec. 23
Lower Most Perf:
330' FNL & 843' FEL Sec. 14
BH Location: 230' FNL & 843' FEL
Section 14
T-26-S, R-33-E

10,000 PSI BOP Annular Variance Request

EOG Resources request a variance to use a 5000 psi annular BOP with a 10,000 psi BOP stack. The component and compatibility tables along with the general well control plans demonstrate how the 5000 psi annular BOP will be protected from pressures that exceed its rated working pressure (RWP). The pressure at which the control of the wellbore is transferred from the annular preventer to another available preventer will not exceed 3500 psi (70% of the RWP of the 5000 psi annular BOP).

1. Component and Preventer Compatibility Tables


The tables below outlines the tubulars and the compatible preventers in use. This table, combined with the drilling fluid, documents that two barriers to flow will be maintained at all times.

9-7/8" & 8-3/4" Intermediate Hole Section 10M psi requirement								
Component	OD	Primary Preventer	RWP	Alternate Preventer(s)	RWP			
Drillpipe	4.500"	Annular	5M	Upper 3.5 - 5.5" VBR Lower 3.5 - 5.5" VBR	10M 10M			
HWDP	4.500"	Annular	5M	Upper 3.5 - 5.5" VBR Lower 3.5 - 5.5" VBR	10M 10M			
Jars	4.500"	Annular	5M	Upper 3.5 - 5.5" VBR Lower 3.5 - 5.5" VBR	10M 10M			
DCs and MWD tools	6.500 - 8.000"	Annular	5M	-	-			
Mud Motor	6.750 - 8.000"	Annular	5M	-	-			
Intermediate casing	7.625"	Annular	5M		-			
Open-hole	-	Blind Rams	10M	*	-			

6-3/4" Production Hole Section 10M psi requirement								
Component	OD	Primary Preventer	RWP	Alternate Preventer(s)	RWP			
Drillpipe	4.500"	Annular	5M	Upper 3.5 - 5.5" VBR Lower 3.5 - 5.5" VBR	10M 10M			
HWDP	4.500"	Annular	5M	Upper 3.5 - 5.5" VBR Lower 3.5 - 5.5" VBR	10M 10M			
DCs and MWD tools	4.750 - 5.500"	Annular	5M	Upper 3.5 - 5.5" VBR Lower 3.5 - 5.5" VBR	10M 10M			
Mud Motor	4.750 – 5.500"	Annular	5M	Upper 3.5 - 5.5" VBR Lower 3.5 - 5.5" VBR	10M 10M			
Mud Motor	5.500 - 5.750"	Annular	5M	-	-			
Production casing	5.500"	Annular	5M	Upper 3.5 - 5.5" VBR Lower 3.5 - 5.5" VBR	10M 10M			
Open-hole	-	Blind Rams	10M		-			

VBR = Variable Bore Ram

EOG Resources 13-5/8" 10M PSI BOP Stack



2. Well Control Procedures

Below are the minimal high-level tasks prescribed to assure a proper shut-in while drilling, tripping, running casing, pipe out of the hole (open hole), and moving the BHA through the BOPs. At least one well control drill will be performed weekly per crew to demonstrate compliance with the procedure and well control plan. The well control drill will be recorded in the daily drilling log. The type of drill will be determined by the ongoing operations, but reasonable attempts will be made to vary the type of drill conducted (pit, trip, open hole, choke, etc.). This well control plan will be available for review by rig personnel in the EOG Resources drilling supervisor's office on location, and on the rig floor. All BOP equipment will be tested as per Onshore O&G Order No. 2 with the exception of the 5000 psi annular which will be tested to 70% of its RWP.

General Procedure While Drilling

- 1. Sound alarm (alert crew)
- 2. Space out drill string
- 3. Shut down pumps (stop pumps and rotary)
- 4. Shut-in Well (uppermost applicable BOP, typically annular preventer first. HCR and choke will already be in the closed position.)
- 5. Confirm shut-in
- 6. Notify toolpusher/company representative
- 7. Read and record the following:
 - a. SIDPP and SICP
 - b. Pit gain
 - c. Time
- 8. Regroup and identify forward plan
- 9. If pressure has built or is anticipated during the kill to reach 70% or greater of the RWP of the annular preventer, confirm spacing and close the upper variable bore rams.

General Procedure While Tripping

- 1. Sound alarm (alert crew)
- 2. Stab full opening safety valve and close
- 3. Space out drill string
- 4. Shut-in (uppermost applicable BOP, typically annular preventer first. HCR and choke will already be in the closed position.)
- 5. Confirm shut-in
- 6. Notify toolpusher/company representative
- 7. Read and record the following:
 - a. SIDPP and SICP
 - b. Pit gain
 - c. Time
- 8. Regroup and identify forward plan
- If pressure has built or is anticipated during the kill to reach 70% or greater of the RWP of the annular preventer, confirm spacing and close the upper variable bore rams.

General Procedure While Running Production Casing

- 1. Sound alarm (alert crew)
- 2. Stab crossover and full opening safety valve and close
- 3. Space out string

- 4. Shut-in (uppermost applicable BOP, typically annular preventer first. HCR and choke will already be in the closed position.)
- 5. Confirm shut-in
- 6. Notify toolpusher/company representative
- 7. Read and record the following:
 - a. SIDPP and SICP
 - b. Pit gain
 - c. Time
- 8. Regroup and identify forward plan
- 9. If pressure has built or is anticipated during the kill to reach 70% or greater of the RWP of the annular preventer, confirm spacing and close the upper variable bore rams.

General Procedure With No Pipe In Hole (Open Hole)

- 1. Sound alarm (alert crew)
- 2. Shut-in with blind rams. (HCR and choke will already be in the closed position.)
- 3. Confirm shut-in
- 4. Notify toolpusher/company representative
- 5. Read and record the following:
 - a. SICP
 - b. Pit gain
 - c. Time
- 6. Regroup and identify forward plan

General Procedures While Pulling BHA thru Stack

- 1. PRIOR to pulling last joint of drillpipe thru the stack.
 - a. Perform flowcheck, if flowing:
 - b. Sound alarm (alert crew)
 - c. Stab full opening safety valve and close
 - d. Space out drill string with tool joint just beneath the upper variable bore rams.
 - e. Shut-in using upper variable bore rams. (HCR and choke will already be in the closed position.)
 - f. Confirm shut-in
 - g. Notify toolpusher/company representative
 - h. Read and record the following:
 - i. SIDPP and SICP
 - ii. Pit gain
 - iii. Time
 - i. Regroup and identify forward plan
- 2. With BHA in the stack and compatible ram preventer and pipe combo immediately available.
 - a. Sound alarm (alert crew)
 - b. Stab crossover and full opening safety valve and close
 - c. Space out drill string with upset just beneath the upper variable bore rams.
 - d. Shut-in using upper variable bore rams. (HCR and choke will already be in the closed position.)
 - e. Confirm shut-in
 - f. Notify toolpusher/company representative
 - g. Read and record the following:
 - i. SIDPP and SICP

- ii. Pit gain
- iii. Time
- h. Regroup and identify forward plan
- 3. With BHA in the stack and NO compatible ram preventer and pipe combo immediately available.
 - a. Sound alarm (alert crew)
 - If possible to pick up high enough, pull string clear of the stack and follow "Open Hole" scenario.
 - c. If impossible to pick up high enough to pull the string clear of the stack:
 - d. Stab crossover, make up one joint/stand of drillpipe, and full opening safety valve and close
 - e. Space out drill string with tooljoint just beneath the upper variable bore ram.
 - f. Shut-in using upper variable bore ram. (HCR and choke will already be in the closed position.)
 - g. Confirm shut-in
 - h. Notify toolpusher/company representative
 - i. Read and record the following:
 - i. SIDPP and SICP
 - ii. Pit gain
 - iii. Time
 - j. Regroup and identify forward plan