

Submit 1 Copy To Appropriate District Office
District I – (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II – (575) 748-1283
811 S. First St., Artesia, NM 88210
District III – (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV – (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised August 1, 2011

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO.	
30-015-00938	✓
5. Indicate Type of Lease STATE X FEE	✓
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name	
Artesia Metex Unit	✓
8. Well Number 003	✓
9. OGRID Number 269864	✓
10. Pool name or Wildcat Artesia; QU-GB-SA	✓
11. Elevation (Show whether DR, RKB, RT, GR, etc.)	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well X Gas Well Other ✓

2. Name of Operator
State of New Mexico formerly Canyon E&P Company

3. Address of Operator
1625 N. French Drive Hobbs, NM 88240

4. Well Location
Unit Letter H : 2310 feet from the North line and 990 feet from the East line
Section 24 Township 18S Range 27E NMPM Eddy County ✓

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INT'

PERFORM REMEDIAL WORK ☐

TEMPORARILY ABANDON ☐

PULL OR ALTER CASING ☐

DOWNHOLE COMMINGLE ☐

INT TO PA

P&A NR pm

P&A R

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

COMMENCE DRILLING OPNS. ☐

CASING/CEMENT JOB ☐

ALTERING CASING ☐

P AND A XX

OTHER:

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

SEE ATTACHED

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE _____ TITLE _____ DATE _____

Type or print name _____ E-mail address: _____ PHONE: _____

For State Use Only

APPROVED BY: M. White TITLE P.E.S. DATE 04/02/2018

Conditions of Approval (if any):

mw

Plugging Report
Artesia Metex Unit #3
30-015-00938

3/16/2018 Clear location. Move in equipment and rig up. Rods and pump were stuck. Worked to free pump and then backed off the rods. Laid down 29 rods. Installed BOP and started to pull the tubing. The tubing was stuck, but worked free. SION.

3/19/2018 POOH with tubing and lay down due to condition. The seating nipple was gone, leaving the remaining rods in the open hole. Picked up workstring. Started feeling the rods in the open hole at 1007'. Continued into the hole to 1495'. Could not get circulation. Spotted 50 sx cement with LCM and CaCl at 1495' as per OCD. POOH and WOC. RIH and did not tag anything at 1495'. Called OCD. Spotted another 50 sx cement at 1495' with LCM and CaCl. POOH and SION.

3/20/2018 Tagged cement at 1249'. Pumped MLF. POOH to 552' and spotted 50 sx cement with CaCl & paper. POOH and WOC 3 hrs. No tag. Spot 50 sx cement with CaCl and paper. POOH and WOC 3 hrs. No tag and still no circulation. Spot 25 sx cement with CaCl and paper. POOH and SION

3/21/2018 RIH and tagged cement at 1249'. The same depth as yesterday morning. Pumped 30 bbls of LCM from 1235'. Did not help get circulation to surface. Brought 5.25 yards of washed 1/2" to 3/4" gravel and shoveled down the wellbore. RIH with tubing and tagged fill at 572'. Attempted to get circulation with 30 bbls. Slight blow to the tank but still no fluid to surface. Called OCD. Spotted 25 sx cement with CaCl and paper at 572'. WOC and tag at 572'. POOH with tubing and dump another yard of gravel down the wellbore. RIH with tubing and tag again at 5702'. Believe there is a cross flow at 572'. POOH and SION.

3/22/2018 Dumped 2 yards of gravel down the well. Tagged at 568'. POOH with tubing and dumped another 2 yards gravel down the wellbore. RIH and tagged at 503. Attempted to get circulation. Good blow to the pit for the 1st 10 bbls then lost blow and casing went on a vacuum. Got another load of gravel and dumped another 2 yards of gravel with 2 sacks of gel in between the 1st yard and the 2nd yard. RIH and tagged fill at 341'. Spotted 25 sx cement with CaCl and paper on top of fill without attempting circulation. WOC and tagged at 254'. Established circulation from 254'. Started pumping cement. Lost circulation at 50 sx. Laid down pipe and rigged down. Dumped another 1.5 yards of gravel. Filled up casing to surface with 20 sx. Cut off wellhead and installed marker.