

Submit 1 Copy To Appropriate District Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-025-33297	✓
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>	✓
6. State Oil & Gas Lease No. 685343	
7. Lease Name or Unit Agreement Name Skelly D STATE	✓
8. Well Number 5	✓
9. OGRID Number 196069	✓
10. Pool name or Wildcat Paddock	✓
11. Elevation (Show whether DR, RKB, RT, GR, etc.)	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other ☐ **HOBBS OCD**

2. Name of Operator
Momentum Operating Co., Inc. **AUG 06 2018**

3. Address of Operator
P.O. Box 2439 Albany, Tx 76430 **RECEIVED**

4. Well Location
Unit Letter I : 1840 feet from the South line and 330 feet from the East line
Section 1 Township 20-S Range 36-E NMPM County Lea ✓

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐
CLOSED-LOOP SYSTEM ☐
OTHER: ☐

SUBSEQUENT
REMEDIAL WORK
COMMENCE DRILLING OPN: INT TO PA **PA**
CASING/CEMENT JOB P&A NR
P&A R

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. **25SX**

1. Set CIBP @ 3700' w/ 25' cement on top. Circulate well w/ MLF. **WOC TAG (DN Tool)**
2. Spot a 25 sx plug 2600'-2400'. **Pressure test csg to 500#**
3. Spot a 25 sx plug 1250'-1050'.
4. Spot a 50 sx plug 300'-surface.

**Cut Wellhead off 3' below ground level
Verify cement to surface all strings
Install upright P&A marker**

**TAG CIBP @ 5097'
Spot 25 sx Class
'C' Cement Spot,
MLF up to 3800'**

Spud Date:

**NOTIFY OCD 24 HOURS PRIOR TO
BEGINNING PLUGGING OPERATIONS**

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE _____ TITLE Operations DATE 7/19/2018

Type or print name Ted Tidwell E-mail address: Ted@momentumoperating.com PHONE: 325-762-0420

For State Use Only

APPROVED BY: **Mark L. Pritchard** TITLE P.E.S. DATE 08/06/2018

Conditions of Approval (if any):

C103 INTENT TO P&A EXPIRES
1 YEAR FROM DATE OF APPROVAL

Momentum Operating Co., Inc.

8/3/2018

Skelly D #5

API 30-025-33297

Top Salt - 1,200'

Base Salt - 2,500'

Spot 50 sx 300 - Surface

~~3 5/8 24" @ 1450' w/ 5003~~

Spot 25 sx 1,250 - 1,050' WOC & TAG

Spot 25 sx 2,600 - 2,400'

Set CIBP @ 3700' W/ 35' on top
Circulate well w/ MLF

3740 - 3830'

CIBP @ 5099' w/ 2sx

5142-5206'

4 1/2"

~~3 1/2 15.5" @ 6000' - DU Tool @ 3505'~~

~~1st stage 650' x 4~~

~~2nd stage 2405' x 4~~

TD 6001'