

Submit 1 Copy To Appropriate District
Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised August 1, 2011

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-025-42647
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other: Injector		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator Occidental Permian Ltd.		6. State Oil & Gas Lease No.
3. Address of Operator HCR 1 Box 90 Denver City, TX 79323		7. Lease Name or Unit Agreement Name South Hobbs (G/SA) Unit
4. Well Location Unit Letter <u>I</u> : <u>2188</u> feet from the <u>South</u> line and <u>657</u> feet from the <u>East</u> line Section <u>4</u> Township <u>19S</u> Range <u>38E</u> NMPM Lea County		8. Well Number: 256
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3612' (GR)		9. OGRID Number: 157984
		10. Pool name or Wildcat Hobbs (G/SA)

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:
PERFORM REMEDIAL WORK ☒ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐

SUBSEQUENT REPORT OF:
REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐

OTHER:

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. RUPU, NDWH, NUBOP, POOH injection tubing and packer
2. Dump 75' of sand to bring top of sand to 5056'
3. Dump bail 20' of cement on sand.
4. Set CIBP at 5025'
5. RIH injection equipment and set packer at 4720'
6. Circulate packer fluid and NDBOP, NUWH
7. Turn well to injection

During this procedure we plan to use
the closed-loop system with a steel
tank and haul contents to the required
disposal per ODC Rule 19.15.17

**Condition of Approval: notify
OCD Hobbs office 24 hours
prior of running MIT Test & Chart**

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE JMP TITLE Production Engineer DATE 11/2/2018

Type or print name Jake Perry E-mail address: Jake_Perry@oxy.com PHONE: 713-215-7546

For State Use Only

APPROVED BY: Mary Brown TITLE AO/I DATE 11/5/2018
Conditions of Approval (if any):