Submit 1 Copy To Appropriate District Office	State of New Mexico	Form C-103
<u>x I</u> – (575) 393-6161	Energy, Minerals and Natural Resources	Revised August 1, 2011
1625 N. French Dr., Hobbs, NM 88240		WELL API NO.
<u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIVISION	30-025-26118
District III - (505) 334-6178	1220 South St. Francis Dr.	5. Indicate Type of Lease
1000 Rio Brazos Rd., Aztec, NM 87410	:	STATE FEE 🛚
<u>District IV</u> – (505) 476-3460	Santa Fe, NM 87505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 87505		
SUNDRY NOTICES AND REPORTS ON WELLS  7. Lease Name or Unit Agreement Name		
	TO DRILL OR TO DEEPEN OR PLUG BACK TO A	South Hobbs (G/SA) Unit
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH		504111 110505 (6,611) 01111
PROPOSALS.)  1. Type of Well: Oil Well  Gas Well  Other: Injector		8. Well Number: 123
2. Name of Operator Occidental Permian Ltd.		9. OGRID Number: 157984
3. Address of Operator		10. Pool name or Wildcat Hobbs (G/SA)
PO Box 4294 Houston, TX 77210		10. Foot hame of whiteat Hoods (C/SA)
4. Well Location		
Unit Letter H: 2390 feet from the North line and 150 feet from the East line		
Section 6 Township 19S Range 38E NMPM Lea County		
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3624' (GL)		
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data		
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:		
PERFORM REMEDIAL WORK D PLUG AND ABANDON REMEDIAL WORK D ALTERING CASING D		
TEMPORARILY ABANDON		
	CASING/CEIVIE	NT JOB
DOWNHOLE COMMINGLE		
OTHER:	OTHER:	
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date		
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of		
proposed completion or recompletion.		
1. MIRU PU. NDWH and NDBOP. POOH with ESP 2. RIH with packer and plug and isolate water hearing zone.  During this procedure we plan to use		
2. Kill with packer and plug and isolate water bearing zone		to an electron with a steel
2. RIH with packer and plug and isolate water bearing zone 3. Set CIBP and CICR and squeeze the closed-loop system with a steel		
4. Drill out squeeze and pressure test tank and haul contents to the required		
5. RIH new ESP disposal pe		per ODC Rule 19.15.17
6. NDBOP and NUWH, return well to production		
		•
Spud Date:	Rig Release Date:	
Span Zaite.		
I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
	one was and complete to the cost of my knowned	ge and coner.
( ) wh /		
SIGNATURE TITLE Production Engineer DATE 2/21/2019		
Type or print name Jake Perry E-mail address: Jake_Perry@oxy.com PHONE: _713-215-7546_		
For State Use Only		
Petroleum Engineer		
APPROVED BY:	TITLE	DATE DY ZZ/JG
Conditions of Approval (If any):		