

State of New Mexico  
Energy, Minerals and Natural Resources Department  
Oil Conservation Division Hobbs District Office

BRADENHEAD TEST REPORT

HOBBS OCD  
AUG 12 2019  
RECEIVED

Operator Name <b>Chevron USA INC</b>		API Number <b>30-025-31489</b>
Property Name <b>W D D U</b>		Well No. <b>122</b>

1. Surface Location

UL - Lot <b>K</b>	Section <b>32</b>	Township <b>24S</b>	Range <b>38E</b>	Feet from <b>2055</b>	N/S Line <b>S</b>	Feet From <b>1981</b>	E/W Line <b>W</b>	County <b>Lea</b>
----------------------	----------------------	------------------------	---------------------	--------------------------	----------------------	--------------------------	----------------------	----------------------

Well Status

TA'D WELL YES <input checked="" type="checkbox"/> NO	SHUT-IN YES <input checked="" type="checkbox"/> NO	INJECTOR <input checked="" type="checkbox"/> SWD	PRODUCER OIL <input checked="" type="checkbox"/> GAS	DATE <b>6-3-19</b>
---	---	---	---	-----------------------

OBSERVED DATA

	(A)Surface	(B)Interm(1)	(C)Interm(2)	(D)Prod Casing	(E)Tubing
Pressure	<b>0</b>	<b>0</b>	<b>—</b>	<b>0</b>	<b>1400</b>
Flow Characteristics					
Puff	<b>Y / N</b>	<b>Y / N</b>	<b>Y / N</b>	<b>Y / N</b>	CO2 <input type="checkbox"/>
Steady Flow	<b>Y / N</b>	<b>Y / N</b>	<b>Y / N</b>	<b>Y / N</b>	WTR <input type="checkbox"/>
Surges	<b>Y / N</b>	<b>Y / N</b>	<b>Y / N</b>	<b>Y / N</b>	GAS <input type="checkbox"/>
Down to nothing	<b>Y / N</b>	<b>Y / N</b>	<b>Y / N</b>	<b>Y / N</b>	Type of Fluid
Gas or Oil	<b>Y / N</b>	<b>Y / N</b>	<b>Y / N</b>	<b>Y / N</b>	Injected for
Water	<b>Y / N</b>	<b>Y / N</b>	<b>Y / N</b>	<b>Y / N</b>	Waterflood if
					applies

Remarks - Please state for each string (A,B,C,D,E) pertinent information regarding bleed down or continuous build up if applies.

(ART) Chemical Serv

Ser# **81586 81568**  
**22**

Cal **3/2/19**

**385**  
Start **380#**

END **380#**

Signature: <b>Julia Jones</b>		OIL CONSERVATION DIVISION
Printed name: <b>Julia Jones</b>		Entered into RBDMS <input checked="" type="checkbox"/>
Title: <b>Regulatory Assistant</b>		Re-test <input checked="" type="checkbox"/>
E-mail Address: <b>j121@chevron.com</b>		
Date: <b>6-3-19</b>	Phone:	
Witness: <b>Kerry Furtner - OCD</b>		

399-3221

INSTRUCTIONS ON BACK OF THIS FORM

## PERFORMING BRADENHEAD TEST

### General Procedure for Bradenhead Test

Identify: All valves prior to testing

Gauges: Install on each casing string to record pressure.

Assure: That all valves are in good working condition and **closed at least 24 hours prior to testing.**

Open: Each valve (Bradenhead, intermediate and casing valves) is to be opened separately.

Check Gauges: Record pressure on each gauge and casing string on BHT form. Open valves to atmosphere and record results on BHT form.

Designate what applies to the result of opening the valves for each string:

- |                        |           |
|------------------------|-----------|
| • Blow or Puff         | Yes or No |
| • Bled down to Nothing | Yes or No |
| • Steady Flow          | Yes or No |
| • Oil or Gas           | Yes or No |
| • Water                | Yes or No |

Start: Injection or SWD pump so tubing pressure can be read.

Instructions below apply to the District 1 Hobbs office since this must be reported on a form.

In case of pressure:

1. Record pressure reading on gauge.
2. Bleed and note time elapsed to bleed down.
3. Leave valve open for additional observation.
4. Note any fluids expelled.

In absence of Pressure:

1. Leave valve open for additional observation.
2. Note types of fluids expelled.
3. Note if fluids persist throughout test.

Note: Tubing pressure on injection or SWD wells.

Test will be signed by person performing test with a contact phone number.