State of New Mexico

Energy, Minerals and Natural Resources Department

Oil Conservation Division Hobbs District Office BRADENHEAD TEST REPORT

Operator Nanie SET API Numb 30 - OSTEMBS O REF # 19 Veli No. 1 Surface Location	39
N. Mexico m 87.	
¹ Surface Location	
Out the Doctation	
UL-Let Section Township Range Feet from N/S Line Feet From E/W Line LE	County
Well Status	
YES TA'D WELL NO YES SHUT-IN NO INJ INJECTOR SWD OIL PRODUCER GAS 8-27.	-19
	,

OBSERVED DATA

	(A)Surface	(B)Interm(1)	(C)Interm(2)	(D)Prod Csng	(E) Lubing
ressure	0	NA	NA	25	25
low Characteristics		1//	7/		
Pull	TO TO	YIN	YIN	YIN	CO2
Steady Flow	Y 100	Y/N	Y/N	YIN	WTR GAS
Surges	1/8	YIN	Y/N	YIN	Type of Field
Down to nothing	0	YIN	YIN	YIN	Injected for Waterfield if
Gas or Oil	1 10	YiN	YIN	YIN	applied
Water	1/5)	7/2	Y / N	Y / N	

Remarks - Please state for each string (AB,C.D.E) pertinent information regarding bleed down or continuous build up if applies. OIL CONSERVATION DIVISION Entered into RBDMS Re-test Phone: Witness

PERFORMING BRADENHEAD TEST

General Procedure for Bradenhead Test

Identify: '

All valves prior to testing

Gauges:

Install on each casing string to record pressure.

· Assure: -

That all valves are in good working condition and closed at least 24 hours prior

to testing.

Open:

Each valve (Bradenhead, intermediate and casing valves) is to be opened

separately.

Check Gauges: Record pressure on each gauge and casing string on BHT form. Open

valves to atmosphere and record results on BHT form.

Designate what applies to the result of opening the valves for each string:

•	Blow or Puff	Yes or No
•	Bled down to Nothing	Yes or No
•	Steady Flow	Yes or No
•	Oil or Gas	Yes or No
•	Water	Yes or No

Start: Injection or SWD pump so tubing pressure can be read.

Instructions below apply to the District 1 Hobbs office since this must be reported on a form.

In case of pressure:

- 1. Record pressure reading on gauge.
- 2. Bleed and note time elapsed to bleed down.
- 3. Leave valve open for additional observation.
- 4. Note any fluids expelled.

In absence of Pressure:

- 1. Leave valve open for additional observation.
- 2. Note types of fluids expelled.
- 3. Note if fluids persist throughout test.

Note: Tubing pressure on injection or SWD wells.

Test will be signed by person performing test with a contact phone number.