

Submit 1 Copy To Appropriate District Office

District I - (575) 393-6161

1625 N. French Dr., Hobbs, NM 88240

District II - (575) 748-1283

811 S. First St., Artesia, NM 88210

District III - (505) 334-6178

1000 Rio Brazos Rd., Aztec, NM 87410

District IV - (505) 476-3460

1220 S. St. Francis Dr., Santa Fe, NM

87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103

Revised August 1, 2011

WELL API NO.

30-025-31487

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name

West Dollarhide Drinkard Unit

8. Well Number: 120

9. OGRID Number

4323

10. Pool name or Wildcat
Dollarhide; Tubb-Drinkard

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☒ Other Injection

2. Name of Operator

Chevron USA Inc.

3. Address of Operator

6301 DEAUVILLE BLVD., MIDLAND, TX 79706

4. Well Location

Unit Letter F : 2190 feet from the North line and 2224 feet from the West line
Section 32 Township 24S Range 38E NMPM County Lea

11. Elevation (Show whether DR, RKB, RT, GR, etc.)

3,184' GL, 3,170' KB

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐

OTHER: ☐

TEMPORARILY ABANDON ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. 8-5/8" @ 1,202' TOC Surface, 5-1/2" @ 7,495' TOC Surface, Perforations: 6,467'-7,337', CIBP's set at 6900' (20' cmt cap) and 6,390'.

Chevron USA INC respectfully request to abandon this well as follows:

1. Call and notify NMOCD 24 hrs before operations begin.
2. Pressure test casing to 500 psi f/ 15 min rig-less.
3. MIRU CTU, check well pressures, perform bubble test on surface casing annuli, if bubble test fails Chevron intends to Zonite or cut and pull casing after the well after it is plugged to a certain point agreed upon by the NMOCD and Chevron.
4. TIH w/ coil tubing and tag CIBP at 6,390', spot enough MLF t/ allow it to be between cement plugs, and spot 140 sx CL "C" cmt f/ 6,390' t/ 4,974', WOC & tag only if casing does not pressure test.
 - a. Utilize a running plug method for all cement plugs, keeping the end of the CT 100' inside the cement.
 - b. TOC must be at 5,030' or shallower.
5. Spot 60 sx CL "C" cmt f/ 4,080' t/ 3,488' (San Andres, Queen).
 - a. TOC must be at 3,534' or shallower.
6. Spot 30 sx CL "C" cmt f/ 2,753' t/ 2,457' (Yates, B.Salt).
 - a. TOC must be at 2,515' or shallower.
7. Spot 150 sx CL "C" cmt f/ 1,453' t/ surface (T.Salt, FW, Shoe, Surf).
 - a. Deepest freshwater zone in the area is ~340'.
8. Cut all casings & anchors & remove 3' below grade. Verify cement to surface & weld on dry hole marker (4" diameter, 4' tall). Clean location.

Note: All cement plugs class "C" (<7,500') or "H" (>7,500') with closed loop system used, and MLF spotted between plugs.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE P&A Engineer, Attorney in fact DATE 12/3/19

Type or print name Howie Lucas E-mail address: howie.lucas@chevron.com PHONE: (832)-588-4044

**See Attached
Conditions of Approval**

For State Use Only

APPROVED BY: Kerry Futer TITLE C O. A DATE 12-11-19
Conditions of Approval (if any):

WDDU #120


Location: 2190' FNL & 2224' FWL, Sec. 32, Township 24S, Range 38E, Unit F, Lea Co., NM

TEAM:
FIELD: Dollarhide (WDDU)
LEASE/UNIT: West Dollarhide Drinkard Unit
COUNTY: Lea

DATE CHKD: Dec. 03, 2019
BY: H Lucas
WELL: WDDU #120
STATE: New Mexico

SPUD DATE: 7/15/1993
TD REACHED DATE: 8/4/1993
COMP. DATE: 8/17/1993
CURRENT STATUS: TA'd

Elevation = 3184' KB
Elevation = 3170' GL
TD = 7495'
ETD = 6890'
API = 30-025-31487
CHEVNO = QU2367



11-3/4" 42# WC40 set @ 1202' w/ 700 sx. cmt., Circ. to surface.
14-1/2" Hole Size

Wellwork

7/15/1993 - Spud date.

8/17/1993 - Completion date. TD'd @ 7495', C/O to 7455' (PBDT). Perf Abo FM f/ 6923-7337' & stim w/ 6500 gals 15% HCl. Set CIBP @ 6900', cap w/ 20' cmt. Perf Drinkard FM f/ 6512-6627' & stim w/ 5200 gals 15% HCl. TIH w/ 2-3/8" tbg & pkr, set pkr @ 6437'.

4/13/1999 - POOH w/ inj equipment. Tag fill @ 6418', d/o scale & iron sulfide to 6837'. Perf Drinkard FM f/ 6467-6493' & stim w/ 6000 gals 15% NEFE HCl acid. Spot 250 gals 15% NEFE HCl f/ 6512-6627'. Set inj pkr @ 6396' on 2-3/8" tbg.

12/18/2003 - POOH w/ inj equipment. Tag scale @ 6480' w/ bit & c/o to 6509' (returns indicate collapsed csg). TIH w/ CIBP & set @ 6390'. No cmt cap. TA'd well.

CIBP @ 6390'

Drinkard Perfs @ 6467-6627'
Possible collapsed csg @ 6480-6509'

TOC @ 6880'
CIBP @ 6900' w/ 20' cmt cap

Abo Perfs @ 6923-7337'

5-1/2" 15.5# & 17# WC50 @ 7495' w/ 2350 sxs cmt circulated.
7-7/8" Hole Size

7455' PBDT
7495' TD

T. Anhy	1203'
T. Salt	1403'
B. Salt	2565'
T. Yates	2703'
T. 7 Rivers	
T. Queen	3634'
T. Grayburg	
T. San Andres	4030'
T. Glorieta	5130'
T. Paddock	
T. Blinbry	
T. Tubb	6060'
T. Drinkard	6378'
T. Abo	6628'

Perforations:

Drinkard @ 6467-6493' (4/1999)
Drinkard @ 6512-6627' (8/1993)
Abo @ 6923-7337' (8/1993)

WDDU #120

Location: 2190' FNL & 2224' FWL, Sec. 32, Township 24S, Range 38E, Unit F, Lea Co., NM

TEAM:

FIELD: Dollarhide (WDDU)

LEASE/UNIT: West Dollarhide Drinkard Unit

COUNTY: Lea

DATE CHKD:

Dec. 03, 2019

BY:

H Lucas

WELL:


WDDU #120

STATE:

New Mexico

SPUD DATE: 7/15/1993
TD REACHED DATE: 8/4/1993
COMP. DATE: 8/17/1993
CURRENT STATUS: TA'd

Elevation = 3184' KB
Elevation = 3170' GL
TD = 7495'
ETD = 6890'
API = 30-025-31487
CHEVNO = QU2367



11-3/4" 42# WC40 set @ 1202' w/ 700 sx. cmt., Circ. to surface.
14-1/2" Hole Size

4 Pump cement across casing shoe, T. Salt t/ surface

3 Pump cement across the Yates and B. Salt

2 Pump cement across the San Andres and Queen

1 MIRU CTU, pressure test casing, tag top of CIBP
pump cement t/ above the Glorieta

CIBP @ 6390'

Drinkard Perfs @ 6467-6627'
Possible collapsed csg @ 6480-6509'

TOC @ 6880'
CIBP @ 6900' w/ 20' cmt cap

Abo Perfs @ 6923-7337'

5-1/2" 15.5# & 17# WC50 @ 7495' w/ 2350 sxs cmt circulated.
7-7/8" Hole Size

7455' PBTD
7495' TD

T. Anhy	1203'
T. Salt	1403'
B. Salt	2565'
T. Yates	2703'
T. 7 Rivers	
T. Queen	3634'
T. Grayburg	
T. San Andres	4030'
T. Glorieta	5130'
T. Paddock	
T. Blinberry	
T. Tubb	6060'
T. Drinkard	6376'
T. Abo	6628'

Perforations:

Drinkard @ 6467-6493' (4/1999)
Drinkard @ 6512-6627' (8/1993)
Abo @ 6923-7337' (8/1993)

CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at (575)-399-3221 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
8. Produced water **will not** be used during any part of the plugging operation.
9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
11. Class 'C' cement will be used above 7500 feet.
12. Class 'H' cement will be used below 7500 feet.
13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIREMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION