Office	State of New I	Mexico	Form C-103
District I - (575) 393-6161	Energy, Minerals and Natural Resources		Revised July 18,2013
1625 N, French Dr., Hobbs, NM 88240			WELL API NO. 30-025-46257
<u>District II</u> - (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIVISION		5. Indicate Type of Lease
District III - (505) 334-6178	1220 South St. Francis Dr.		STATE S FEE
1000 Rio Brazos Rd., Aztec, NM 87410 District IV ~ (505) 476-3460	Santa Fe, NM 87505		6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM	•		3. 3.3.3 3.3.3 3.3.3 3.3.3
SUNDRY NOTICES AND REPORTS ON WELLS			7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A			Valor State Com
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH			8. Well Number 702H
PROPOSALS.) 1. Type of Well: Oil Well Gas Well Other			o. Well Mullicel /UZA
2. Name of Operator	Gas well LI Other	- unbbs	9. OGRID Number
COG Operating, LLC	0	CD - HOBBS 03/18/2020	229137
3. Address of Operator		03 18 110	10. Pool name or Wildcat
2208 W Main Artesia, NM 8821	10	RECEIVED	Bobcat Draw; Upper Wolfcamp
4. Well Location		Kr.	
Unit Letter A:	210 feet from the N	lineand 755	feet from the <u>E</u> line
Section 25			MPM County Lea
Section 25 Township 25S Range 33E NMPM County Lea 11. Elevation (Show whether DR, RKB, RT, GR, etc.)			
3329' GR			
	NTENTION TO:		SSEQUENT REPORT OF:
PERFORM REMEDIAL WORK□	 -	REMEDIAL WO	
TEMPORARILY ABANDON		ſ	RILLING OPNS. P AND A
PULL OR ALTER CASING		CASING/CEMEN	T JOB 🗆
DOWNHOLE COMMINGLE			•
CLOSED-LOOP SYSTEM	' п	OTHER:	<i>б</i>
OTHER: OTHER: OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date			
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of			
proposed completion or recompletion.			
COG Operating LLC respectfully requests approval to P&A the pre-set surface hole of the Valor State Com 702H (API#			
3002546257) by setting a 250 sx class C cemet w/1 % Calcium Chloride plug from TD@1198-600' through open-ended pipe, pull			
up & WOC6 hrs. Tag TOC. Spot 250 sx Class C neat from 600' to surface. TOH. Cut off wellhead, top off casing w/cement, weld			
on plate. Rig down & move out rig. Install P&A marker in accordance w/NMOCD regulations.			
No reclamation will be performed, as the P&A wellbore shares the pad w/other wells that are currently being drilled. Additionally, considering the uncertainties of rig scheduling, it may be necessary to move out Scandrill Quest & move in a smaller			
pre-set rig to perform this P&A procedure; COG requests permission to use a pre-set rig for this P&A if it becomes required to			
unforeseen circumstances.			
			See Attached
Spud Date:	Rig Releas	e Date:	Conditions of Approval
L		L	
I hereby certify that the information above is true and complete to the best of my knowledge and belief.			
Pelila.	<i>h Flores</i> TITLE: R	amilator: Taskaisis =	DATE: 2/17/000
SIGNATURE	HILE: K	egulatory Technician	DATE: 3/17/2020
Type or print name: Delilah Flores E-mail address: dflores@concho.com PHONE: 575-748-6946			
For State Use Only	D-manaducas. <u>di</u>	W. COME CONCINCTION	1
<u>-</u>	1	ام م	1
APPROVEDBY: Conditions of Approval (if any):	Just TITLE (_ 0	H DATE 3-25-20
Conditions of Approval (if any):			

.ea County, NM iec 35, T25S, R33E

Valor State Com #702H

SHL Lat NAD 27: 32.093551*N SHL Long:


Scanonii Quest 103.536564°W

PRESENT & Proposed Wellbore

3HL Sec 35 210' FNL 755' FEL

API: 3002546257

KB: 3360', GL: 3330'



.ea County, NM sec 35, T25S, R33E

10-34" 45.5# 155 BTC* @ 1198'
451 sx C w/ 4% Gel 13.5 ppg, 1.73 cVsk
151 sx C w/ 1% Ca(12, 148 ppg, 1.35 cVsk
Circulated 357 sade to surface

Valor State Com #702H

SHL Lat NAD 27: 32.093551°N SHL Long:

Scangrill Quest 103.536564° W

CUB: 3/16/2020

3HL Sec 35 210' FNL

PRESENT & Proposed Wellbore API: 3002546257 755' FEL KB: 3360', GL: 3330' AFS Wellheads: 13-3/8" SOW x13-5/8" 3M Multibowi Csq Hd Bit Size: 14-3/4" 250 sacks Class C Neat

T/Salt@ 1454*

Rustler @ 1121'

TD 1198

250 sacks Class C w/ 1% CaC12

CONDITIONS OF APPROVAL FOR PLUGGING AND ABANDONMENT OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at (575)-263-6633 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.

والمراوية والمرا

- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
 - 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
- A) Fusselman
- B) Devonian
- C) Morrow
- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- l) Glorieta
- J) Yates.
- K) Potash---(In the R-111-P Area (Potash Mine Area),

A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, woe 4 hours and tag, this plug will be SO' below the bottom and 50' above the top of the Formation.

21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, woe and tagged. These plugs will be set SO' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQ.UIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least%" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and Well Number
- 3. API Number
- 4. Unit letter
- 5. Quarter Section (feet from the North, South, East or West)
- 6. Section, Township and Range
- 7. Plugging Date
- 8. County

SPECIAL CASES ----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION