

Submit 1 Copy To Appropriate District  
Office  
District I - (575) 393-6161  
1625 N. French Dr., Hobbs, NM 88240  
District II - (575) 748-1283  
811 S. First St., Artesia, NM 88210  
District III - (505) 334-6178  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV - (505) 476-3460  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

Form C-103  
Revised August 1, 2011

|   |
|---|
| WELL API NO.<br>30-025-31547  |
| 5. Indicate Type of Lease<br>STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/> |
| 6. State Oil & Gas Lease No.  |
| 7. Lease Name or Unit Agreement Name<br>Lovington San Andres Unit                                   |
| 8. Well Number: 81  |
| 9. OGRID Number<br>241333   |
| 10. Pool name or Wildcat<br>ving n ray urg  |

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG OR TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH  
PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator  
Chevron USA INC

3. Address of Operator  
6301 DEAUVILLE BLVD., MIDLAND, TX 79706

4. Well Location

Unit Letter \_\_\_\_\_ : 22 \_\_\_\_\_ feet from the \_\_\_\_\_ South \_\_\_\_\_ line and \_\_\_\_\_ 2 32 \_\_\_\_\_ feet from the  
\_\_\_\_\_ e \_\_\_\_\_ line Section 31 Township 16S Range 37E NMPM County Lea

11. Elevation (Show whether DR, RKB, RT, GR, etc.)  
3,806' GL, 3,822' KB

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐  
DOWNHOLE COMMINGLE ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ P AND A ☐  
CASING/CEMENT JOB ☐

OTHER: ☐

OTHER: TEMPORARILY ABANDON ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Chevron USA INC respectfully request to re-abandon this well as follows:

1. Call and notify NMOCD 24 hrs before operations begin.
2. Rig up single rig and POOH laying all production equipment down.
3. MIRU wireline unit. Test lubricator to 1500 psi for 15 minutes. RIH and set CIBP @ 4526'. Pressure test @ 1000 psi for 15 minutes.
4. Rig down single unit
5. MIRU coil unit
6. Spot 75 sx of Class C CMT from 4526' to 3768' (Perfs, Queen)
7. Spot 45 sx of Class C CMT from 3350' to 2895' Pressure test @ 1000 psi for 15 minutes. (Yates, Seven Rivers)
8. Spot 140 sx of Class C CMT from 1405' to surface. (FW, Shoe)
9. Verify cement to surface & weld on dry hole marker. Clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

See Attached  
Conditions of Approval

SIGNATURE Ricky Villanueva TITLE Well Abandonment Engineer, Attorney-in-Fact DATE 7/8/20

Type or print name Ricky Villanueva E-mail address: ryqg@chevron.com PHONE: 432-488-7448

For State Use Only

APPROVED BY: Kerry Inta TITLE COA DATE 7-14-20

# WIW LSAU 81 WELLBORE DIAGRAM

Created: 05/01/08 By: I da Silva  
 Updated: By:  
 Lease: Lovington San Andres Unit  
 Field: Lovington San Andres Unit  
 Surf. Loc.: 2532' WL 122' SL  
 Bot. Loc.:  
 County: Lea St.: NM  
 Status: Active Oil Producer

Well #: 81 St. Lse:  
 API 300-025-31547  
 Unit Ltr.: N Section: 31  
 TSHP/Rng: 16S / 37E  
 Unit Ltr.: Section:  
 TSHP/Rng:  
 Directions: Lovington, NM  
 Cheveno: OV1656

## Surface Casing

Size: 8-5/8"  
 Wt., Grd.: 20# J-55 st&c  
 Depth: 1355  
 Sxs Cmt: 550  
 Circulate: Y  
 TOC: Surface  
 Hole Size: 12-1/4"

KB:  
 DF:  
 GL: 3808'  
 Ini. Spud: 05/12/92  
 Ini. Comp.: 06/11/92

## Production Casing

Size: 5-1/2"  
 Wt., Grd.: 15.5# K-55 lt&c  
 Depth: 5155  
 Sxs Cmt: 1150  
 Circulate: Y (120 sx)  
 TOC: Surface  
 Hole Size: 7-7/8"

## Prod/Inj Interval

Completion: C&P  
 Hole Size: -

5/12/92 Spud  
 6/11/92 Complete - 5107' PBTD, 5155'  
 TD. Perf f/ 4626-5040'. Stim w/ 32 tons  
 CO2 and 10K gals 20% NEFe SGA acid.  
 1/17/94 Change pump.  
 9/4/96 Spotted 1000 gals 15% NEFe acid  
 across perms. SI 30 mins. Put acid away  
 @ 1/2 bpm w/ 1800# cp. RTP.  
 9/8/01 Tagged bottom and long stroked  
 pump. Installed pressure gauge.  
 12/8/07 4 bopd, 89 bwpd, 2 mcfpd.  
 12/18/08 Rods parted.  
 9/24/12 Rods parted - replaced pump.

Perfs: 4626-5040'

PBTD: 5067'  
 TD: 5155'

# WIW LSAU 81 WELLBORE DIAGRAM

|             |                           |      |            |             |               |               |    |
|-------------|---------------------------|------|------------|-------------|---------------|---------------|----|
| Created:    | 05/01/08                  | By:  | I da Silva | Well #:     | 81            | St. Lse:      |    |
| Updated:    |                           | By:  |            | API         |               | 300-025-31547 |    |
| Lease:      | Lovington San Andres Unit |      |            | Unit Ltr.:  | N             | Section:      | 31 |
| Field:      | Lovington San Andres Unit |      |            | TSHP/Rng:   | 16S / 37E     |               |    |
| Surf. Loc.: | 2532' WL 122' SL          |      |            | Unit Ltr.:  |               | Section:      |    |
| Bot. Loc.:  |                           |      |            | TSHP/Rng:   |               |               |    |
| County:     | Lea                       | St.: | NM         | Directions: | Lovington, NM |               |    |
| Status:     | Active Oil Producer       |      |            | Chevno:     | OV1656        |               |    |

## Surface Casing

Size: 8-5/8"  
Wt., Grd.: 20# J-55 st&c  
Depth: 1355  
Sxs Cmt: 550  
Circulate: Y  
TOC: Surface  
Hole Size: 12-1/4"

KB: \_\_\_\_\_  
DF: \_\_\_\_\_  
GL: 3808'  
Ini. Spud: 05/12/92  
Ini. Comp.: 06/11/92

## Production Casing

Size: 5-1/2"  
Wt., Grd.: 15.5# K-55 lt&c  
Depth: 5155  
Sxs Cmt: 1150  
Circulate: Y (120 sx)  
TOC: Surface  
Hole Size: 7-7/8"

## Prod/Inj Interval

Completion: C&P  
Hole Size: -

| Formation Name | TD, ft |
|----------------|--------|
|                | Top    |
| Rustler        | 1995*  |
| Yates          | 3045*  |
| Seven Rivers   | 3300   |
| Queen          | 3898   |
| Grayburg       | 4334   |
| San Andres     | 4603   |
| TD             | 5155   |

Spot 140 sx of Class C CMT f/ 1405' to Surface  
(FW, Shoe)

Spot 45 sx of Class C CMT f/ 3350' to 2895'  
(Yates, Seven Rivers)  
Pressure Test @ 1000 psi for 15 minutes

Spot 75 sx of Class C CMT f/ 4526' to 3768'  
Pressure Test @ 1000 psi for 15 minutes  
(Queen)  
Set CIBP @ 4526'

Perfs: 4626-5040'

PBTD: 5067'  
TD: 5155'

**CONDITIONS OF APPROVAL  
FOR PLUGGING AND ABANDONMENT  
OCD - Southern District**

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify **NMOCD District Office I (Hobbs) at (575)-263-6633** at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

**Company representative will be on location during plugging procedures.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal - commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
8. Produced water will not be used during any part of the plugging operation.
9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
11. Class 'C' cement will be used above 7500 feet.
12. Class 'H' cement will be used below 7500 feet.
13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.

20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops

- A) Fusselman
- B) Devonian
- C) Morrow
- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- I) Glorieta
- J) Yates.
- K) Potash---(In the R-111-P Area (Potash Mine Area),

A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, woe 4 hours and tag, this plug will be SO' below the bottom and 50' above the top of the Formation.

21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, woe and tagged. These plugs will be set SO' below formation bottom to 50' above formation top inside the casing

#### **DRY HOLE MARKER REQ.UIRMENTS**

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least 1/4" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name
2. Lease and Well Number
3. API Number
4. Unit letter
5. Quarter Section (feet from the North, South, East or West)
6. Section, Township and Range
7. Plugging Date
8. County

#### **SPECIAL CASES ----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS**

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

#### **SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION**