

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLI  
(Other instruction:  
verse side)

TEP  
re

Form approved.  
Budget Bureau No. 42-R1424.

3. LEASE DESIGNATION AND SERIAL NO.

NM-0558287  
6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT--" for such proposals.)

1. OIL WELL  GAS WELL  OTHER

7. UNIT AGREEMENT NAME

2. NAME OF OPERATOR  
AMOCO PRODUCTION COMPANY.

8. FARM OR LEASE NAME

MORGAN D Federal  
9. WELL NO.

3. ADDRESS OF OPERATOR  
BOX 367, ANDREWS, TEXAS 79714

3

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

10. FIELD AND POOL, OR WILDCAT

CHAUEROO-SAN ANDRES  
11. SEC., T., R. N., OR BLK. AND  
SUBVLY OR AREA

660' FSL \* 1980' FEL Sec. 13 (Unit D, SW/4 SE/4)

13-7-33 NMPM

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)  
4325.5 GL.

12. COUNTY OR PARISH 13. STATE  
ROOSEVELT N. M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF   
FRACTURE TREAT   
SHOOT OR ACIDIZE   
REPAIR WELL   
(Other)

PULL OR ALTER CASING   
MULTIPLE COMPLETE   
ABANDON\*   
CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF   
FRACTURE TREATMENT   
SHOOTING OR ACIDIZING   
(Other)

REPAIRING WELL   
ALTERING CASING   
ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Zone has been depleted w/ no workover or recompletion possibilities. Propose to P&A as follows:

- 1- Cut & pull 4 1/2" casing from free point (Est TCM 2880')
- 2- Displace hole w/ mud.
- 3 - Spot 35' cement plug from PBD-3850 to cover perp 4025-4275'
- 4 - " 35' " " " " in & out of 4 1/2" casing stub.
- 5 - " 35' " " across B Salt @ 2970'.  
(Remaining where casing is cut steps 4 & 5 may be combined to form one plug of a minimum of 60' x top of salt cap. (A and B salt are within 300' of each other. Cement outline may be increased to provide approx. 100' plug)
- 6 - Spot 35' x cement plug across T Salt @ 1890'.
- 7 - " 35' x in & out of 8 7/8" CSA 352'.
- 8 - " 10' x @ surface and erect P & A marker.
- 9 Make final cleanup and restore ground to contour.

TD-4360 4 1/2" CSA 4360 (TCM 2880')  
PB-4343 8 7/8" CSA 352' Circ

PERFS: 4025-4275' T Salt 1890'  
B " 2970'

18. I hereby certify that the foregoing is true and correct

SIGNED Roy R. Yorkum

TITLE ADMINISTRATIVE ASSISTANT

DATE 9-18-75

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

- 044-USGS-H
- 1-DIV
- 1-SUSA
- 1-RRY

APPROVED  
AS AMENDED  
NOV 6 1975  
ARTHUR R. BROWN  
DISTRICT ENGINEER

\*See Instructions on Reverse Side