

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPL
(Other instructions
verse side)

E*
re-

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 064150

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

7. UNIT AGREEMENT NAME

Maljamar (Grayburg)

8. FARM OR LEASE NAME

Maljamar Unit

9. WELL NO.

52

10. FIELD AND POOL, OR WILDCAT

Maljamar (Grayburg-San And)

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 10, T-17-S, R-32-E, NMPM

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

1. OIL WELL GAS WELL OTHER Water Injection well

2. NAME OF OPERATOR
Chevron Oil Company

3. ADDRESS OF OPERATOR
P. O. Box 1660, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

Unit D, 660' FNL, 690' FWL, Sec. 10, T-17-S, R-32-E, NMPM

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, OR, etc.)

Not Available

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETE

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZE

ABANDON*

SHOOTING OR ACIDIZING

ABANDONMENT*

REPAIR WELL

CHANGE PLANS

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Work to commence before third quarter 1976. Federal office will be notified prior to commencing actual plugging operations.

1. Dig work pit and cellar.
2. Run and set CIBP to 3800', cap w/cement. Load hole w/mud laden fluid. Pull tubing to 2400' and spot 30 sxs cement.
3. Determine free point of 5 1/2" casing.
4. Shoot off casing, pull and lay down casing.
5. Run tubing, open ended to 50' below casing stub and spot 30 sxs cement. Pull tubing to 1211', spot 50 sxs cement.
6. Perforate 8 5/8" casing at 200'. Pump sufficient cement down 8 5/8" casing to circulate via 8 5/8" x open hole annulus leaving 8 5/8" csg full.
7. Cut casing 3' below ground level, weld steel plate w/4' marker. Back fill pit and cellar. Clean up location as per Federal or State requirements.

18. I hereby certify that the foregoing is true and correct

SIGNED J. W. Leonard

TITLE Drilling Supervisor

DATE 3-1-76

(This space for Federal or State office use)

APPROVED BY _____

TITLE _____

CONDITIONS OF APPROVAL, IF ANY:

APPROVED
AS AMENDED

JUL 21 1976

ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side