

UNITED STATES
 DEPARTMENT OF THE INTERIOR
 GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
 (Other instructions on reverse side)

Form approved.
 Budget Bureau No. 42 R1424

COPY TO O. R. &

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>		7. UNIT AGREEMENT NAME ---	
2. NAME OF OPERATOR PETROLEUM DEVELOPMENT CORPORATION		8. FARM OR LEASE NAME Sun McKay Federal	
3. ADDRESS OF OPERATOR 9720 B Candelaria, NE Albuquerque, New Mexico 87112		9. WELL NO. 1	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1730' FWL, 1850' FNL		10. FIELD AND POOL, OR WILDCAT Lusk Morrow	
14. PERMIT NO. --		15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3658 GL	
		12. COUNTY OR PARISH Lea	13. STATE N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) _____	(Other) _____

(Other) Re-complete in Morrow (NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose following work immediately after approval:

1. Install BOP, pull tubing and packer to TA Wolfcamp zone.
2. Run tubing and top half of Otis on-off tool. Latch on packer at 12602, load tubing with 2% KCl water, test tubing, fish Otis plug, swab well in.
3. Test and place well on sales line through compressor.

NSP UNIT #1082 FOR W 1/2 SEC. 10

RECEIVED
 FEB 6 1980

U. S. GEOLOGICAL SURVEY
 HOBBS, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED *Quentin A. Anderson* TITLE Vice President DATE 1-31-80

(This space for Federal or State office use)

APPROVED
 FEB 6 1980
 ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

OIL CONSERVATION

FEB 12 1980

RECEIVED