Office	State State	of New Mexico		Form C-103 <sup>1</sup>					
<u>District I</u> – (575) 393-6161	Energy, Miner	als and Natural Resourc	es	Revised July 18, 2013					
1625 N. French Dr., Hobbs, NM 882	40		WELL API N						
<u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CONSE		30-015-21910						
District III - (505) 334-6178	1220 So		5. Indicate Type of Lease STATE FEE						
1000 Rio Brazos Rd., Aztec, NM 874 District IV – (505) 476-3460	410 Santa		6. State Oil & Gas Lease No.						
1220 S. St. Francis Dr., Santa Fe, NN 87505									
SUNDRY (DO NOT USE THIS FORM FOR P		7. Lease Name or Unit Agreement Name Nix GP							
DIFFERENT RESERVOIR. USE "A	THA OI								
PROPOSALS.)	8. wen Num	8. Well Number							
1. Type of Well: Oil Well	Gas Well		9. OGRID Number						
2. Name of Operator EOG Resources, Inc.			9. OGRID N 7377	imber					
3. Address of Operator			10. Pool nam	e or Wildcat					
104 South Fourth Street, Arte	sia, NM 88210		Atoka; San A	ndres					
4. Well Location Unit Letter O	: 990 feet from the	South line and	2310 feet f	rom the East line					
Section 2		18S Range 26		Eddy County					
	1	whether DR, RKB, RT, G		Eddy County					
		3320'GR	(, <i>cic.)</i>						
12. Che	eck Appropriate Box to	Indicate Nature of No	tice, Report or Otl	ner Data					
	F INTENTION TO:		SUBSEQUENT I						
PERFORM REMEDIAL WOR									
TEMPORARILY ABANDON		_	E DRILLING OPNS.						
PULL OR ALTER CASING									
DOWNHOLE COMMINGLE									
CLOSED-LOOP SYSTEM			Notify OCD 24 hrs.	prior to any work					
OTHER:		□ OTHER:	done						
13. Describe proposed or	completed operations. (Cle	arly state all pertinent deta	ils, and give pertinent	dates, including estimated date					
of starting any propos	ed work). SEE RULE 19.1	5.7.14 NMAC. For Multip	le Completions: Atta	ch wellbore diagram of					
proposed completion	or recompletion.								
EOG Resources, Inc. plans to pl	lug and abandon this well as fo	llows							
EOO Resources, inc. prans to pr	ug and abandon this wen as to	nows.							
1. MIRU all safety equipmen	t as needed. NU BOP. POOH	with production equipment.							
		1642'. WOC and tag. Test	csa after plug - circ N						
2. Set a CIBP at 1677' with 3	5 Class C centent on top to		oby allor plug - oli o l						
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 3</li> </ol>	36 sx Class "C" cement plug fr	om 1271'-928'. This will cov	er 7" casing shoe and top	ILF San Andres. WOC and tag.					
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 3</li> <li>Spot a 10 sx Class "C" cent</li> </ol>	36 sx Class "C" cement plug fr nent plug from 100' up to surfa	om 1271'-928'. This will cov ace. Back fill as needed.	er 7" casing shoe and top	<mark>ILF)</mark> San Andres. WOC and tag.					
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 3</li> <li>Spot a 10 sx Class "C" cen</li> <li>Cut off wellhead and instal</li> </ol>	36 sx Class "C" cement plug fr	om 1271'-928'. This will cov ace. Back fill as needed.	er 7" casing shoe and top	ALF) San Andres. WOC and tag.					
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 3</li> <li>Spot a 10 sx Class "C" cent</li> </ol>	36 sx Class "C" cement plug fr nent plug from 100' up to surfa	om 1271'-928'. This will cov ace. Back fill as needed.	er 7" casing shoe and top	<mark>ALF)</mark> San Andres. WOC and tag.					
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 3</li> <li>Spot a 10 sx Class "C" cen</li> <li>Cut off wellhead and instal</li> </ol>	36 sx Class "C" cement plug fr nent plug from 100' up to surfa	om 1271'-928'. This will cov ace. Back fill as needed.	er 7" casing shoe and top	ALF) San Andres. WOC and tag.					
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 3</li> <li>Spot a 10 sx Class "C" cen</li> <li>Cut off wellhead and instal</li> </ol>	36 sx Class "C" cement plug fr nent plug from 100' up to surfa	om 1271'-928'. This will cov ace. Back fill as needed.	er 7" casing shoe and top	ALF) San Andres. WOC and tag.					
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 3</li> <li>Spot a 10 sx Class "C" cen</li> <li>Cut off wellhead and instal</li> </ol>	36 sx Class "C" cement plug fr nent plug from 100' up to surfa	om 1271'-928'. This will cov ace. Back fill as needed.	er 7" casing shoe and top	ALF) San Andres. WOC and tag.					
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 2</li> <li>Spot a 10 sx Class "C" cen</li> <li>Cut off wellhead and instal</li> <li>Wellbore schematics attached.</li> </ol>	36 sx Class "C" cement plug fr nent plug from 100' up to surfa ll dry hole marker. Clean locati	om 1271'-928'. This will cov ace. Back fill as needed. on as per regulated.	er 7" casing shoe and top	ALF San Andres. WOC and tag.					
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 2</li> <li>Spot a 10 sx Class "C" cen</li> <li>Cut off wellhead and instal</li> <li>Wellbore schematics attached.</li> </ol>	36 sx Class "C" cement plug fr nent plug from 100' up to surfa ll dry hole marker. Clean locati	om 1271'-928'. This will cov ace. Back fill as needed.	er 7" casing shoe and top	ALF) San Andres. WOC and tag.					
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 2</li> <li>Spot a 10 sx Class "C" cen</li> <li>Cut off wellhead and instal Wellbore schematics attached.</li> </ol>	36 sx Class "C" cement plug fr nent plug from 100' up to surfa ll dry hole marker. Clean locati	om 1271'-928'. This will cov ace. Back fill as needed. on as per regulated.	er 7" casing shoe and top	San Andres. WOC and tag.					
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 3</li> <li>Spot a 10 sx Class "C" cen</li> <li>Cut off wellhead and instal</li> </ol>	36 sx Class "C" cement plug fr nent plug from 100' up to surfa Il dry hole marker. Clean locati R IED COA's****	om 1271'-928'. This will cov ace. Back fill as needed. ion as per regulated. ig Release Date:	er 7" casing shoe and top	San Andres. WOC and tag.					
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 3</li> <li>Spot a 10 sx Class "C" cen</li> <li>Cut off wellhead and instal</li> <li>Wellbore schematics attached.</li> </ol> Spud Date: ****SEE ATTACH I hereby certify that the inform	36 sx Class "C" cement plug fr nent plug from 100' up to surfa Il dry hole marker. Clean locati R IED COA's**** ation above is true and com	om 1271'-928'. This will cov ace. Back fill as needed. ion as per regulated. ig Release Date: MUST BE plete to the best of my know	PLUGGED B wledge and belief.	San Andres. WOC and tag.					
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 3</li> <li>Spot a 10 sx Class "C" cen</li> <li>Cut off wellhead and instal Wellbore schematics attached.</li> </ol> Spud Date: <b>****SEE ATTACH</b> I hereby certify that the inform SIGNATURE <u>TINA HUEP</u>	36 sx Class "C" cement plug from 100' up to surfa         nent plug from 100' up to surfa         Il dry hole marker. Clean locati         R         IED COA's****         ation above is true and com         ta       T	om 1271'-928'. This will cov ace. Back fill as needed. on as per regulated. ig Release Date: <u>MUST BE</u> plete to the best of my know TTLE <u>Regulatory Spe</u>	E PLUGGED B wledge and belief. cialist DATE Ja	NoC and tag.					
<ul> <li>2. Set a CIBP at 1677' with 3</li> <li>3. Perforate at 1271'. Spot a 3</li> <li>4. Spot a 10 sx Class "C" cen</li> <li>5. Cut off wellhead and instal</li> <li>Wellbore schematics attached.</li> </ul> Spud Date: <b>****SEE ATTACH</b> I hereby certify that the inform SIGNATURE <u>Tina Huer</u> Type or print name <u>Tin</u>	36 sx Class "C" cement plug from 100' up to surfa         nent plug from 100' up to surfa         Il dry hole marker. Clean locati         R         IED COA's****         ation above is true and com         ta       T	om 1271'-928'. This will cov ace. Back fill as needed. on as per regulated. ig Release Date: <u>MUST BE</u> plete to the best of my know TTLE <u>Regulatory Spe</u>	PLUGGED B wledge and belief.	San Andres. WOC and tag.					
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 3</li> <li>Spot a 10 sx Class "C" cen</li> <li>Cut off wellhead and instal</li> <li>Wellbore schematics attached.</li> </ol> Spud Date: <b>****SEE ATTACH</b> I hereby certify that the inform SIGNATURE <u>Tina Huer</u> Type or print name <u>Tin</u> For State Use Only	36 sx Class "C" cement plug from 100' up to surfa         nent plug from 100' up to surfa         Il dry hole marker. Clean locati         Il dry hole marker. Clean locati         IED COA's****         ation above is true and com         ta         Huerta         E-mail	om 1271'-928'. This will cov ace. Back fill as needed. Ion as per regulated. Ig Release Date: MUST BE plete to the best of my know TTLE <u>Regulatory Spe</u> address: <u>tina huerta@e</u>	EPLUGGED B wledge and belief. cialist DATE Ja	Y 1/8/2022         muary 7, 2021         PHONE: 575-748-4168					
<ol> <li>Set a CIBP at 1677' with 3</li> <li>Perforate at 1271'. Spot a 3</li> <li>Spot a 10 sx Class "C" cen</li> <li>Cut off wellhead and instal</li> <li>Wellbore schematics attached.</li> </ol> Spud Date: <b>****SEE ATTACH</b> I hereby certify that the inform SIGNATURE <u>Tina Huer</u> Type or print name <u>Tin</u> <b>For State Use Only</b> APPROVED BY: <u>Market Artical</u>	36 sx Class "C" cement plug from 100' up to surfa         nent plug from 100' up to surfa         Il dry hole marker. Clean locati         Il dry hole marker. Clean locati	om 1271'-928'. This will cov ace. Back fill as needed. on as per regulated. ig Release Date: <u>MUST BE</u> plete to the best of my know TTLE <u>Regulatory Spe</u>	EPLUGGED B wledge and belief. cialist DATE Ja	NoC and tag.					
2. Set a CIBP at 1677' with 3 3. Perforate at 1271'. Spot a 3 4. Spot a 10 sx Class "C" cen 5. Cut off wellhead and instal Wellbore schematics attached. Wellbore schematics attached. Spud Date: ****SEE ATTACH hereby certify that the inform SIGNATURE Tina Huer Sype or print nameTin For State Use Only	36 sx Class "C" cement plug from 100' up to surfa         nent plug from 100' up to surfa         Il dry hole marker. Clean locati         Il dry hole marker. Clean locati	om 1271'-928'. This will cov ace. Back fill as needed. Ion as per regulated. Ig Release Date: MUST BE plete to the best of my know TTLE <u>Regulatory Spe</u> address: <u>tina huerta@e</u>	EPLUGGED B wledge and belief. cialist DATE Ja	Y 1/8/2022 muary 7, 2021 PHONE: <u>575-748-4168</u>					

•

### **Released to Imaging: 1/11/2021 9:13:33 AM**

# CONDITIONS FOR PLUGGING AND ABANDONMENT

### OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E)Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - I) Glorieta
  - J) Yates.
  - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

### DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name2. Lease and Well Number3. API Number4. Unit Letter5. QuarterSection (feet from the North, South, East or West)6. Section, Township and Range7. Plugging Date8. County(SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

### SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

M	Nix GP #1	Curre	nt			-TWN-RNG: FOOTAGES:					3320	5-21910		
					CACIN									
					#	G DETAIL HOLE SIZE	SIZE	WGHT	GRADE	Тор	Bottom	Sx Cmt	Circ/TOC	TOC Method
					# A	9 1/2	7	23	?	0	1,216	500	Circ	TCC IMethod
					~		4 1/2	9.5	H-40					
					В	6 1/4	5 1/2	14	J-55	0	1,822	175	?	
	A /													
					FORM	ATION TOPS	r						1	
1						Formation	Тор				Formatio	n	Тор	
						San Andres	978							
				TOC ?										
					-									
1														
1														
1														
						1								
					TUBIN	G DETAIL								
					#	Joints	Description	Length	OD	ID	Grade	Wt (lb/ft):	Top (ftKB):	Btm (ftKB):
							2 3/8						1,707	
						1							I.	1
							L							
					Perfor	ation Detail	_	E	1	L .		1		
						Formation	Тор	Bottom		Treatm				
					A	San Andres	1,727	1,752	<u> </u>	60,000	gelied KC	JL, 90,000#	100 mesh and 20/4	iU sand
Perf A														
						1		1						
					-	1	<u> </u>	<u> </u>						
						1		1						
					-	1		+	<u> </u>					
1	В	/				1	I	I		I		-	l	
						Dura	eneral laws 70.1		-					
1	PBTD:	1,822 M	D		-	Prepa	ared by: TH		1					
1	TD:		ND											
	ID.	.,												

Plug 3	Nix GP #1 Proposed		-TWN-RNG: OOTAGES:				API: GL: KB:	30-015-21910 3320			
			DETAIL		r		1		r	1	1
			HOLE SIZE	SIZE	WGHT	GRADE	Тор	Bottom	Sx Cmt	Circ/TOC	TOC Method
		A	9 1/2	7	23	?	0	1,216	500	Circ	
		в	6 1/4	5 1/2	14	J-55	0	1,012	175	Cir	Est
	· · · · · · · · · · · · · · · · · · ·										
		В	6 1/4	4 1/2	9.5	J-55	1012	1,821			
ug 2		FORM	TION TOPS								
		FORMA	Formation	Тор				Formation		Тор	1
				978				Formation		гор	
			San Andres	978							
		Perfora	tion Detail	1						1	
			Formation	Тор	Bottom		Treatm	ent			
		A	San Andres	1,727			60,000	gelled KCL, 90,000# 100	mesh and 20/40 sand		
			-		•						
		Plugs									
		#	SX	Length (ft)	Bottom	Top	Class	DESCRIPTION			
		1	2	35	1677	1642		CIBP @ 1677' w/ 35' of ce	ment dump bailed on top. V	VOC & tag.	
		2	36	343	1271	928		343' cement plug from 1271	' - 928' covering the 7" csg	shoe and San Andres top. W	OC & Tag.
		3	10	100	100	0		100' cement plug from 100'	to surface. Back fill as nee	ded.	
ug 1											
	W W										
erf A									1		
							<u> </u>				
	в			L	L		L	I	L		1
	DDTD: 1822 MD		Prep	ared by: TH		I					
	PBTD: 1,822 MD	1									
	TD: 1,850 MD										

District I 1625 N. French Dr., Hobbs, NM 88240

Phone:(575) 393-6161 Fax:(575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

District III 1000 Rio Brazos Rd., Aztec, NM 87410

District IV

CONDITIO	DNS

Action 14225

## State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. Santa Fe, NM 87505

#### CONDITIONS OF APPROVAL

Operator:				OGRID:	Action Number:	Action Type:
EOG RESOURCES INC	P.O. Box 2267	Midland, TX79702		7377	14225	C-103F
OCD Reviewer			Condition			
gcordero			COA's attached			