** ** *	State of New Mex	xico		Form C-103 ¹ of 6
Office <u>District I</u> – (575) 393-6161	Energy, Minerals and Natur	ral Resources		sed July 18, 2013
1625 N. French Dr., Hobbs, NM 88240 <u>District II</u> – (575) 748-1283		20.0	LL API NO. 015-20504	
811 S. First St., Artesia, NM 88210	OIL CONSERVATION	DIVISION	ndicate Type of Lease	
<u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Fran	cis Dr.	STATE F	
<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM	Santa Fe, NM 87	$\begin{array}{c c} 303 & 6. & 8 \end{array}$	tate Oil & Gas Lease N	0.
87505	TICES AND DEPONTS ON WELLS	7.1	NI	
	TCES AND REPORTS ON WELLS OSALS TO DRILL OR TO DEEPEN OR PLU		ease Name or Unit Agr son Estate BY	eement Name
DIFFERENT RESERVOIR. USE "APPLI PROPOSALS.)	ICATION FOR PERMIT" (FORM C-101) FO	8. V	Vell Number	
1. Type of Well: Oil Well	Gas Well Other	5		
2. Name of Operator EOG Resources, Inc.		9. (737'	OGRID Number	
3. Address of Operator		10.	Pool name or Wildcat	
104 South Fourth Street, Artesia, I	NM 88210	Eag	e Creek; San Andres	
4. Well Location Unit Letter H:	2310 feet from the North	line and 330	feet from the	East line
Section 21	Township 17S Ran		_	unty
Section 21	11. Elevation (Show whether DR,	C	Eddy Co	unty
	3546'0	GR		
12 Ch	Annania Dana Tadia As N	-4 CNI-4: D	Oth D-4-	
	Appropriate Box to Indicate Na	iture of Notice, Repo	ort or Other Data	
	NTENTION TO:		UENT REPORT (
PERFORM REMEDIAL WORK ☐ TEMPORARILY ABANDON ☐		REMEDIAL WORK COMMENCE DRILLING		IG CASING □
TEMPORARILY ABANDON L		CASING/CEMENT JOB	-	
DOWNHOLE COMMINGLE				le alama
CLOSED-LOOP SYSTEM OTHER:		OTHER:	4 hrs before any wor	k done □
	pleted operations. (Clearly state all p		pertinent dates, includir	ng estimated date
	ork). SEE RULE 19.15.7.14 NMAC	. For Multiple Completi	ons: Attach wellbore di	agram of
proposed completion or re-	completion.			
EOG Resources, Inc. plans to plu	g and abandon this well as follows:			
1 MIDII all cofaty agricument of	as needed. NU BOP. POOH with proc	duction agricument		
1. MIRU all safety equipment a	is needed. NU BOP. POOH With broc			
			c MLF before pumping shoe. Very state of the contraction of the contra	ng 25 sx cmt WOC and tag.
 Set a CIBP at 1249' with 19 Spot a 25 sx Class "C" ceme 	ex Class "C" cement on top to 1072'. nt plug from 835'-594'. This will cov	This will cover open per ver top San Andres.	rfs and 7" casing shoe. Yerf @ 506' and	VOC and tag.
 Set a CIBP at 1249' with 49 Spot a 25 sx Class "C" ceme Perforate at 576'. Spot a 25 s 	ex Class "C" cement on top to 1072'. nt plug from 835'-594'. This will cover class "C" cement plug from 576'-3	This will cover open per ver top San Andres. 335'. This will cover 10-	Perf @ 506' and 3/4" casing shoe. WOC	VOC and tag.
 Set a CIBP at 1249' with 49 Spot a 25 sx Class "C" ceme Perforate at 576'. Spot a 25 s Perforate at 96'. Spot a 10 sx 	ex Class "C" cement on top to 1072'. nt plug from 835'-594'. This will cov	This will cover open per ver top San Andres. 335'. This will cover 10- to surface. Back fill as no	Perf @ 506' and 3/4" casing shoe. WOC	VOC and tag.
 Set a CIBP at 1249' with 49. Spot a 25 sx Class "C" ceme Perforate at 576'. Spot a 25 s Perforate at 96'. Spot a 10 sx Cut off wellhead and install of 	sx Class "C" cement on top to 1072'. nt plug from 835'-594'. This will cover cover cover cover the state of	This will cover open per ver top San Andres. 335'. This will cover 10- to surface. Back fill as no	Perf @ 506' and 3/4" casing shoe. WOC	VOC and tag.
 Set a CIBP at 1249' with 49 Spot a 25 sx Class "C" ceme Perforate at 576'. Spot a 25 s Perforate at 96'. Spot a 10 sx 	sx Class "C" cement on top to 1072'. nt plug from 835'-594'. This will cover cover cover cover the state of	This will cover open per ver top San Andres. 335'. This will cover 10- to surface. Back fill as no	Perf @ 506' and 3/4" casing shoe. WOC	VOC and tag.
 Set a CIBP at 1249' with 49. Spot a 25 sx Class "C" ceme Perforate at 576'. Spot a 25 s Perforate at 96'. Spot a 10 sx Cut off wellhead and install of 	sx Class "C" cement on top to 1072'. nt plug from 835'-594'. This will cover cover cover cover the state of	This will cover open per ver top San Andres. 335'. This will cover 10- to surface. Back fill as no	Perf @ 506' and 3/4" casing shoe. WOC	VOC and tag.
 Set a CIBP at 1249' with 49 Spot a 25 sx Class "C" ceme Perforate at 576'. Spot a 25 s Perforate at 96'. Spot a 10 sx Cut off wellhead and install of Wellbore schematics attached. 	sx Class "C" cement on top to 1072'. In the plug from 835'-594'. This will cover class "C" cement plug from 576'-3 a Class "C" cement plug from 96' up dry hole marker. Clean location as per	This will cover open per ver top San Andres. 335'. This will cover 10- to surface. Back fill as no r regulated.	Perf @ 506' and 3/4" casing shoe. WOC	VOC and tag.
 Set a CIBP at 1249' with 49 Spot a 25 sx Class "C" ceme Perforate at 576'. Spot a 25 s Perforate at 96'. Spot a 10 sx Cut off wellhead and install of Wellbore schematics attached. 	sx Class "C" cement on top to 1072'. In the plug from 835'-594'. This will cover the	This will cover open perver top San Andres. 335'. This will cover 10-to surface. Back fill as not regulated.	rfs and 7" casing shoe. Perf @ 506' and 3/4" casing shoe. WOC eeded.	Circ cmt to surf and tag.
 Set a CIBP at 1249' with 49 Spot a 25 sx Class "C" ceme Perforate at 576'. Spot a 25 s Perforate at 96'. Spot a 10 sx Cut off wellhead and install of Wellbore schematics attached. 	sx Class "C" cement on top to 1072'. In the plug from 835'-594'. This will cover the	This will cover open per ver top San Andres. 335'. This will cover 10- to surface. Back fill as no r regulated.	rfs and 7" casing shoe. Perf @ 506' and 3/4" casing shoe. WOC eeded.	Circ cmt to surf and tag.
2. Set a CIBP at 1249' with 49 3. Spot a 25 sx Class "C" ceme 4. Perforate at 576'. Spot a 25 s 5. Perforate at 96'. Spot a 10 sx 6. Cut off wellhead and install of the wellbore schematics attached. Spud Date: ****SEE ATTACHEI	sx Class "C" cement on top to 1072'. In the plug from 835'-594'. This will cover the	This will cover open per yer top San Andres. 335'. This will cover 10-to surface. Back fill as not regulated.	Perf @ 506' and 3/4" casing shoe. WOC seded.	Circ cmt to surf and tag.
2. Set a CIBP at 1249' with 19 3. Spot a 25 sx Class "C" ceme 4. Perforate at 576'. Spot a 25 s 5. Perforate at 96'. Spot a 10 sx 6. Cut off wellhead and install of Wellbore schematics attached. Spud Date: ****SEE ATTACHEI	sx Class "C" cement on top to 1072'. In the plug from 835'-594'. This will cover the cover common state of the cover class "C" cement plug from 96' and the cover class "C" cement plug from 96' up dry hole marker. Clean location as per common state of the cover co	This will cover open per yer top San Andres. 335'. This will cover 10-to surface. Back fill as not regulated.	Perf @ 506' and 3/4" casing shoe. WOC ended.	circ cmt to surf and tag.
2. Set a CIBP at 1249' with 19 3. Spot a 25 sx Class "C" ceme 4. Perforate at 576'. Spot a 25 s 5. Perforate at 96'. Spot a 10 sx 6. Cut off wellhead and install of the wellbore schematics attached. Spud Date: ****SEE ATTACHEI I hereby certify that the information SIGNATURE Tina Huerta Type or print name Tina Hu	sx Class "C" cement on top to 1072'. Int plug from 835'-594'. This will cover the cover the cover the cover the cover the cover the class "C" cement plug from 96' up dry hole marker. Clean location as per the cover	This will cover open per top San Andres. 335'. This will cover 10-to surface. Back fill as not regulated. te: UST BE PLUGG st of my knowledge and	Perf @ 506' and 3/4" casing shoe. WOC seded. BED BY 2/2/202 belief. ATE January 18, 202	circ cmt to surf and tag. 2
2. Set a CIBP at 1249' with 19 3. Spot a 25 sx Class "C" ceme 4. Perforate at 576'. Spot a 25 s 5. Perforate at 96'. Spot a 10 sx 6. Cut off wellhead and install of the wellbore schematics attached. Spud Date: ****SEE ATTACHEI I hereby certify that the information SIGNATURE Tina Huerta	sx Class "C" cement on top to 1072'. nt plug from 835'-594'. This will cover common state of the	This will cover open perver top San Andres. 335'. This will cover 10-to surface. Back fill as not regulated. te: UST BE PLUGG st of my knowledge and gulatory Specialist D	Perf @ 506' and 3/4" casing shoe. WOC seded. SED BY 2/2/202 belief. ATE January 18, 202 com PHONE: 5'	circ cmt to surf and tag. 2

CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- A notice of intent to plug and abandon a wellbore is required to be approved before plugging
 operations are conducted. A cement evaluation tool is required in order to ensure isolation of
 producing formations, protection of water and correlative rights. A cement bond log or other
 accepted cement evaluation tool is to be provided to the division for evaluation if one has not
 been previously run or if the well did not have cement circulated to surface during the original
 casing cementing job or subsequent cementing jobs. Insure all bradenheads have been
 exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E)Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

COMMENTS	on Estate BY	#5 Current			21-17S-25E 2310' FNL & 33	0' FEL		API: GL: KB:	30-015-27356 3546			
			CASING	DETAIL								
			#	HOLE SIZE	SIZE	WGHT	GRADE	Top	Bottom	Sx Cmt	Circ/TOC	TOC by
			Α	13 3/4	10 3/4	32#	J-55	0	456	200	Circ to Surf	
			В	9 7/8	7	23#	J-55	0	1122			
			С	6 1/4	5 1/2	14#	J-55	0	1009	125	CIRC	
					4 1/2	9.5#	J-55	1009	1,495	123	CIRC	
								_				
			FORM A	TION TOPS								
			1 Ortimiz		FORMATION	TOP			Formation	TOP		
						714			Formation	TOP		
					San Andres	/14						
												
	A	_										
								_	1	_		
			Ports	tion Detail	1							
			rertora	tion Detail	Fermation	Тор	D-#		Tourstone		Notes	\vdash
					Formation		Bottom		Treatment			
					San Andres	1299	1461		5000g 15% acid, 40000#, 20	-40 sand, 8	0000 gl treated water	
			Tubing	Detail								
				Joints	Description	Length	OD	ID	Grade	Тор	Btm (FtKB)	
					Tubing	1279	2					
			Rods D	etail								
			_									
								_				
								_		1	1	
										_		\vdash
	B											
	B											
	B											
	В											
	B											
			ADDITIO	ONAL DETAIL								
n Andres Perfs: 12			ADDITIO	DNAL DETAIL								
n Andres Perfs: 12			ADDITIO	DNAL DETAIL								
n Andres Perfs: 12			ADDITIC	ONAL DETAIL								
n Andres Perfs: 12			ADDITIO	ONAL DETAIL								
n Andres Perfs: 12		MM.	ADDITIO	ONAL DETAIL								
n Andres Perfs: 12			ADDITIC	ONAL DETAIL								
in Andres Perfs: 12			ADDITIC	ONAL DETAIL								
n Andres Perfs: 12			ADDITIO	DNAL DETAIL								
n Andres Perfs: 12			ADDITIC	ONAL DETAIL								
n Andres Perfs: 12	99'-1461'		ADDITIO		mandle W							
a Andres Perfs: 12			ADDITIO		repared by: DC		12/23/					

- CONTRACTOR - STRICT	DV #4	Proposed	Sec-T	WN-RNG:	21-17S-25E			API:	30-015-27356			
stere	D1 #8	rroposea	FO	OTAGES:	2310' FNL & 33	0' FEL		GL:	3546			
								KB:				
th Plug: Surface Plug												
	₹	₩.		HOLE SIZE	SIZE		00105	-			0: 700	*****
	-	_	# A	13 3/4	10 3/4	WGHT 32#	GRADE J-55	Top 0	Bottom 456	Sx Cmt 200	Circ/TOC Circ to Surf	TOC by
			В	9 7/8	7	23#	J-55	0	1122	500	Circ to Surf	
			c	6 1/4	5 1/2	14#	J-55	0	1009	125	CIRC	
					4 1/2	9.5#	J-55	1009	1,495	123	CIRC	
			FORMA	TION TOPS						l		
					FORMATION San Andres	TOP 714			Formation	TOP		
					San Andres	/14						
rd Plug: Sur. Csg. Shoe	W											
A												
			PERFO	RATION DETA								
					Formation	Тор	Bottom		Treatment		Notes	
					San Andres	1299	1461		5000g 15% acid, 40000#, 20	-40 sand, 8	0000 gl treated water	
			TUBING	DETAIL		-						
											D: (5:10)	
				Joints	Description Tubing	Length 1279	OD 2	ID	Grade	Тор	Btm (FtKB)	
nd Plug: San Andres Top			Rods D	etail								
			PLUGS #	sx	Class	Top	Bottom	Δ	Notes	Tag		
			1	19	С	1072	1249		SA Perfs & Int. Csg. Shoe	Y		
			2	25	С	594	835		San Andres Top	N		
	/ 3	€ \	3	25	С	335	576	241	Surface Csg. Shoe	Y		
		FL>	4	10	С	0	96	96	Surface Plug	Y		
			+					 				
l l												
st Plug: San Andres Perfs & Int. Cs	g. Shoe											
st Plug: San Andres Perfs & Int. Cs	g. Shoe									_		
			ADDITIO	NAL DETAIL								
	sg. Shoe	AAA	ADDITIO	NAL DETAIL								
			ADDITIO	NAL DETAIL								
			ADDITIO	NAL DETAIL								
			ADDITIO	DNAL DETAIL								
tt Plug: San Andres Perfs & Int. Cs an Andres Perfs: 1299'-1461'			ADDITIO	DNAL DETAIL								
			ADDITIO	DNAL DETAIL								
			ADDITIO	ONAL DETAIL								
an Andres Perfs: 1299'-1461'	WW		ADDITIO									
an Andres Perfs: 1299'-1461'			ADDITIO		epared by: KJP		12/29/2					

<u>District I</u> 1625 N. French Dr., Hobbs, NM 88240 Phone:(575) 393-6161 Fax:(575) 393-0720

811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720 District III
1000 Rio Brazos Rd., Aztec, NM 87410

Phone:(505) 334-6178 Fax:(505) 334-6170 1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. **Santa Fe, NM 87505**

CONDITIONS

Action 14872

CONDITIONS OF APPROVAL

Operator:			OGRID:		Action Type:
EOG RESOURCES INC	P.O. Box 2267 Mid	dland, TX79702	7377	14872	C-103F

OCD Reviewer	Condition
gcordero	None