ceived by CCD: 1/20/2021 11:43:47 Al	M State of New Mexico	Form C ⁻ 183 ¹
Office District I – (575) 393-6161	Energy, Minerals and Natural Reso	
District I - (515) 555-5161 1625 N. French Dr., Hobbs, NM 88240 District II - (575) 748-1283 811 S. First St., Artesia, NM 88210 District III - (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410 District IV - (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM 87505	OIL CONSERVATION DIVIS 1220 South St. Francis Dr. Santa Fe, NM 87505	WELL API NO.
(DO NOT USE THIS FORM FOR PROPOSALS DIFFERENT RESERVOIR. USE "APPLICATION PROPOSALS.)	AND REPORTS ON WELLS TO DRILL OR TO DEEPEN OR PLUG BACK ON FOR PERMIT" (FORM C-101) FOR SUCH Well DOther	 TO A 7. Lease Name or Unit Agreement Name Yates AS Fee 8. Well Number 4
2. Name of Operator EOG Resources, Inc.		9. OGRID Number 7377
3. Address of Operator 104 South Fourth Street, Artesia, NM 8	38210	10. Pool name or Wildcat Penasco Draw; SA-Yeso
4. Well Location Unit Letter <u>L</u> : <u>1650</u>) feet from the <u>South</u> line	and 330 feet from the West line
Section 25	Township 18S Range	25E NMPM Eddy County
11	. Elevation (Show whether DR, RKB, RZ 3468'GR	, GR, etc.)

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF	INT	FENTION TO:	SUBSEQUENT REPORT OF:		
PERFORM REMEDIAL WORK		PLUG AND ABANDON	\boxtimes	REMEDIAL WORK ALTERING CASING [
TEMPORARILY ABANDON		CHANGE PLANS		COMMENCE DRILLING OPNS. P AND A	
PULL OR ALTER CASING		MULTIPLE COMPL		CASING/CEMENT JOB	
DOWNHOLE COMMINGLE				Notify OCD 24 hrs before any work done	
CLOSED-LOOP SYSTEM				Notify COD 24 his before any work done	
OTHER:				OTHER:	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

EOG Resources, Inc. plans to plug and abandon this well as follows:

- 1. MIRU all safety equipment as needed. NU BOP. POOH with production equipment.
- Set a CIBP at 2112' with 110' Class "C" cement on top to 2002'. This will cover Yeso perfs and top Glorieta. WOC and tag.
 Perforate at 1256'. Spot a 25 sx Class "C" cement plug from 1256'-522'. This will cover 7" casing shoe and top San Andres.
- Perforate at 1256'. Spot a 25 sx Class "C" cement plug from 1256'-522'. This will cover 7" casing shoe and top San Andres. WOC and tag. Perf @ 1122'
- 4. Perforate at 370'. Spot a 26 sx Class "C" cement plug from 370' up to surface. Back fill as needed.
- 5. Cut off wellhead and install dry hole marker. Clean location as per regulated.

Wellbore schematics attached.

Spud Date:		Rig Release	Date:				
****SE	E ATTACHED COA's	S ^{****}	MUS	ST BE PL	UGGE	DBY 2	/3/2022
I hereby certif	y that the information above is true a	nd complete to the	best of	my knowledge a	und belief.		
SIGNATURE	Tina Huerta	TITLE	Regulate	ory Specialist	DATE	January 20, 2	2021
Type or print print For State Use		E-mail address:	<u>tina_hu</u>	erta@eogresour	ces.com	PHONE:	575-748-4168
	BY: <u>Approval</u> (if any):	≥TITLE	_St	aff Man	iger	_DATE	2/3/2021

Released to Imaging: 2/3/2021 3:43:19 PM

CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E)Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name2. Lease and Well Number3. API Number4. Unit Letter5. QuarterSection (feet from the North, South, East or West)6. Section, Township and Range7. Plugging Date8. County(SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

Yates AS FEE #4 Current	Se		Sec. L-25-18S-25 1650' FSL & 330'				30-015-21422 3486			
	CAS	NG DETAIL								
			SIZE	WGHT	GRADE	Тор	Bottom	Sx Cmt	Circ/TOC	TOC Method
A	A		10 3/4"	30	K-55	0	320	175	Circ	
	В	9 1/2*	7"	23	J-55	0	1,072	890	Surface	Top Out
	с	6 1/4*	4 1/2	10.5	J-55	0	2406	250	Surface	Calc
	FOR	MATION TOPS	Formation	Тор					Formation	Тор
			San Andres	706					- official off	TOP
			Glorieta	2052						
в										
	10BI #	Joints	Description	Length	OD	ID	Grade	Wt (lb/ft):	Top (ftKB):	Btm (ftKB):
		Jointa	2"	2283	00	D	Giade	we (iovity.	TOP (INCD).	Dan (laxb).
			Ē							1
Yeso 🗾										
Yeso	Perfo	orations								1
Yeso	Perfo	Formation	Depths							
Yeso	Perfc A		Depths 2162' - 2304'							
Yeso	A	Formation								
Yeso	A	Formation								
Yeso	A	Formation								
Yeso	A	Formation								
	A	Formation								
Yeso	A	Formation								

Yates A	S FEE #4	Proposed			Sec. 25-18S-25E 1650' FSL & 330'	FWL			30-015-21422 3486			
			CASIN	G DETAIL								
3rd Plug: Sur. Csg. Shoe & Sur. Plug			#	HOLE SIZE	SIZE	WGHT	GRADE	Тор	Bottom	Sx Cmt	Circ/TOC	TOC Method
	A		A	14 3/4	10 3/4"	30	K-55	0	320	175	Circ	
			В	9 1/2"	7*	23	J-55	0	1,072	890	Surface	Top Out
			С	6 1/4"	4 1/2	10.5	J-55	0	2406	250	Surface	Calc
			FORM	ATION TOPS	F	T			T			-
					Formation San Andres	Top 706						+
					Glorieta	2052						
					Gioneta	2032						
			PERFO	RATION DETAIL				_	1			1
d Plug: Int. Csg. Shoe & SA Top				Formation	Тор	Bottom						
	В			Yeso	2162	2304						
			TURIN	G DETAIL								
			#	Joints	Description	Length	OD	ID	Grade	Wt (lb/ft):	Top (ftKB):	Btm (ftKB)
					2*	2283						(
I	-	-	PLUGS			_	-	-				
st Plug: Yeso Perfs & GL Top	-		#	SX	Class	Тор	Bottom	Δ	Notes	Tag		
eso Perfs: 2162'-2304'	W	~	1	7	с	2002	2112		Yeso Perfs & GL Top	Y		
			2	25	C C	522	1256	368	Int. Csg. Shoe & SA Top			
			3	26	C	0	370	370	Sur. Csg. Shoe & SP	Y		
									1			
									1			
							1					
	с											
	C PBTD: 2,4	06 MD										-

District I 1625 N. French Dr., Hobbs, NM 88240

District II

District IV

Phone:(575) 393-6161 Fax:(575) 393-0720

811 S. First St., Artesia, NM 88210 Phone: (575) 748-1283 Fax: (575) 748-9720

Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

District III 1000 Rio Brazos Rd., Aztec, NM 87410 CONDITIONS

Action 15074

State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. Santa Fe, NM 87505

CONDITIONS OF APPROVAL

Operator:				OGRID:	Action Number:	Action Type:
EOG RESOURCES INC	P.O. Box 2267	Midland, TX79702		7377	15074	C-103F
OCD Reviewer			Cond	ition		
gcordero			None			