

Office  
 District I – (575) 393-6161  
 1625 N. French Dr., Hobbs, NM 88240  
 District II – (575) 748-1283  
 811 S. First St., Artesia, NM 88210  
 District III – (505) 334-6178  
 1000 Rio Brazos Rd., Aztec, NM 87410  
 District IV – (505) 476-3460  
 1220 S. St. Francis Dr., Santa Fe, NM  
 87505

State of New Mexico  
 Energy, Minerals and Natural Resources

Form C-103  
 Revised July 18, 2013

OIL CONSERVATION DIVISION  
 1220 South St. Francis Dr.  
 Santa Fe, NM 87505

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. <b>30-025-34572</b>
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator <b>EOG RESOURCES INC</b>		6. State Oil & Gas Lease No.
3. Address of Operator <b>PO BOX 2267 MIDLAND, TX 79702</b>		7. Lease Name or Unit Agreement Name <b>TRISTE DRAW 34 STATE COM</b>
4. Well Location Unit Letter <b>O</b> : <b>660'</b> feet from the <b>SOUTH</b> line and <b>1883'</b> feet from the <b>EAST</b> line Section <b>34</b> Township <b>24S</b> Range <b>33E</b> NMPM County <b>LEA</b>		8. Well Number <b>2</b>
11. Elevation (Show whether DR, RKB, RT, GR, etc.) <b>3481' GR</b>		9. OGRID Number <b>7377</b>
10. Pool name or Wildcat <b>JOHNSON RANCH; WOLFCAMP(GAS)</b>		

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	P AND A <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPL <input type="checkbox"/>	CASING/CEMENT JOB <input type="checkbox"/>	
DOWNHOLE COMMINGLE <input type="checkbox"/>			
CLOSED-LOOP SYSTEM <input type="checkbox"/>			
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

EOG PROPOSES TO PLUG THIS WELL USING THE ATTACHED PROCEDURE.

**4" diameter 4' tall Above Ground Marker**

**SEE ATTACHED CONDITIONS  
OF APPROVAL**

Spud Date:

05/20/1999

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE KAY MADDOX TITLE Regulatory Analyst DATE 02/19/2021

Type or print name Kay Maddox E-mail address: kay\_maddox@eogresources.com PHONE: 432-638-8475

**For State Use Only**

APPROVED BY: Kerry Fortner TITLE Compliance Officer A DATE 2/22/21

Conditions of Approval (if any):



Triste Draw 34 State #2 – P&A

SEC 34, T24S, R33E

API # 30-025-34572

1. Notify Regulatory Agency 24 hours prior to commencing work. MIRU well service unit and all necessary safety equipment.
2. ND WH, NU BOP, RIH with a GR & JB to ~13,250'. POOH.
3. RIH with free-point tool to determine where to cut TBG. POOH.
4. RIH with 2-7/8" CIBP and set at 13,200'. **Set CIBP 13,500 within 100' of top perf**
5. Circulate plugging mud and spot 30 sx Class H on top of CIBP.
6. RIH and cut TBG ~12,000' based on free point.
7. Spot a 25 sx class H cement plug from 9,310' – 9,110'.
8. Pick up, spot a 25 sx class C cement plug from 7,300' – 7,100'.
9. Pick up, spot a 30 sx class C cement plug from 5,215' – 4,920'; WOC & tag.
10. Pick up, perf @ 2,500' and sqz a 25 sx class C cement plug to 2,370'. **P&S 50 sx Class C 1200' Top of Salt**
11. Pick up, perf @ 730' and sqz a 175 sx class C cement plug to surface.
12. Cut off WH 3' below surface; verify cement to surface & weld on P&A marker.
13. Cut off anchors 3' below surface and clean location.

Well Name: Triste Draw 34 State #2  
 Location: 660' FSL & 1883' FEL Sec. 34-24S-33E  
 County: Lea, NM  
 Lat/Long: 32.1686363, -103.557724 NAD83  
 API #: 30-025-34572  
 Spud Date: 5/20/99  
 Compl. Date: 6/20/99



### Current Wellbore Diagram:

KB: 3,501'  
 GL: 3,481'

14-3/4" Hole

11-3/4" 42# H40 @ 677'  
 Cmt w/ 350 sx (circ)

11" Hole

8-5/8" 32# HCK-55/J-55 @ 4,974'  
 Cmt w/ 1,175 sx (circ)

7-7/8" Hole

5-1/2" 17# P-110 @ 12,856'  
 Cmt w/ 1,100 sx; TOC @ 4,470' (Calc)

4-5/8" Hole

2-7/8" 6.5# P-110/L80 @ 13,900'  
 Cmt w/ 130 sx; TOC @ 12,060' (TS)

PBD @ 13,760'  
 TD @ 13,900'

### Formation Tops

Delaware	5,164
Bone Spring	9,258
Wolfcamp	12,290

Wolfcamp perms: 13,300 - 13,336'

Top of fish @ 13,480'

Wolfcamp perms: 13,553 - 13,691' tag fill @ 11,050 11/2014

Not to Scale  
 By: HJG 2/18/21


Well Name: Triste Draw 34 State #2  
 Location: 660' FSL & 1883' FEL Sec. 34-24S-33E  
 County: Lea, NM  
 Lat/Long: 32.1686363, -103.557724 NAD83  
 API #: 30-025-34572  
 Spud Date: 5/20/99  
 Compl. Date: 6/20/99



### Proposed Wellbore Diagram:

KB: 3,501'  
 GL: 3,481'

14-3/4" Hole  
 11-3/4" 42# H40 @ 677'  
 Cmt w/ 350 sx (circ)  
 11" Hole  
 8-5/8" 32# HCK-55/J-55 @ 4,974'  
 Cmt w/ 1,175 sx (circ)  
 7-7/8" Hole  
 5-1/2" 17# P-110 @ 12,856'  
 Cmt w/ 1,100 sx; TOC @ 4,470' (Calc)  
 4-5/8" Hole  
 2-7/8" 6.5# P-110/L80 @ 13,900'  
 Cmt w/ 130 sx; TOC @ 12,060' (TS)



### Formation Tops

Delaware	5,164
Bone Spring	9,258
Wolfcamp	12,290

Perf @ 730' & sqz 175 sx class C cmt to surface

Perf @ 2,500' & sqz 25 sx class C cmt to 2,370'

Spot 30 sx class C cmt plug @ 5,215 - 4,920'  
 WOC & Tag

Spot 25 sx class C cmt plug @ 7,300 - 7,100'

Spot 25 sx class H cmt plug @ 9,310 - 9,110'

Cut TBG @ ~12,000' after running free-point

Set CIBP w/ 30 sx class H cmt @ 13,200' to 12,240'

Wolfcamp perms: 13,300 - 13,336'

Top of fish @ 13,480'

Wolfcamp perms: 13,553 - 13,691'

Not to Scale  
 By: HJG 2/18/21

**CONDITIONS OF APPROVAL  
FOR PLUGGING AND ABANDONMENT  
OCD - Southern District**

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at (575)-263-6633 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

**Company representative will be on location during plugging procedures.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal - commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
8. Produced water will not be used during any part of the plugging operation.
9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
11. Class 'C' cement will be used above 7500 feet.
12. Class 'H' cement will be used below 7500 feet.
13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
- A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E) Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - I) Glorieta
  - J) Yates.
  - K) Potash---(In the R-111-P Area (Potash Mine Area),

A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, woe 4 hours and tag, this plug will be SO' below the bottom and 50' above the top of the Formation.

21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, woe and tagged. These plugs will be set SO' below formation bottom to 50' above formation top inside the casing.

### **DRY HOLE MARKER REQ.UIRMENTS**

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least 1/4" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name
2. Lease and Well Number
3. API Number
4. Unit letter
5. Quarter Section (feet from the North, South, East or West)
6. Section, Township and Range
7. Plugging Date
8. County

### **SPECIAL CASES -----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS**

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

### **SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION**



Triste Draw 34 State #2 – P&A

SEC 34, T24S, R33E

API # 30-025-34572

1. Notify Regulatory Agency 24 hours prior to commencing work. MIRU well service unit and all necessary safety equipment.
2. ND WH, NU BOP, RIH with a GR & JB to ~13,250'. POOH.
3. RIH with free-point tool to determine where to cut TBG. POOH.
4. RIH with 2-7/8" CIBP and set at 13,200'.
5. Circulate plugging mud and spot 30 sx Class H on top of CIBP.
6. RIH and cut TBG ~12,000' based on free point.
7. Spot a 25 sx class H cement plug from 9,310' – 9,110'.
8. Pick up, spot a 25 sx class C cement plug from 7,300' – 7,100'.
9. Pick up, spot a 30 sx class C cement plug from 5,215' – 4,920'; WOC & tag.
10. Pick up, perf @ 2,500' and sqz a 25 sx class C cement plug to 2,370'.
11. Pick up, perf @ 730' and sqz a 175 sx class C cement plug to surface.
12. Cut off WH 3' below surface; verify cement to surface & weld on P&A marker.
13. Cut off anchors 3' below surface and clean location.

Well Name: Triste Draw 34 State #2  
 Location: 660' FSL & 1883' FEL Sec. 34-24S-33E  
 County: Lea, NM  
 Lat/Long: 32.1686363, -103.557724 NAD83  
 API #: 30-025-34572  
 Spud Date: 5/20/99  
 Compl. Date: 6/20/99



### Current Wellbore Diagram:

KB: 3,501'  
 GL: 3,481'

14-3/4" Hole

11-3/4" 42# H40 @ 677'  
 Cmt w/ 350 sx (circ)

11" Hole

8-5/8" 32# HCK-55/J-55 @ 4,974'  
 Cmt w/ 1,175 sx (circ)

7-7/8" Hole

5-1/2" 17# P-110 @ 12,856'  
 Cmt w/ 1,100 sx; TOC @ 4,470' (Calc)

4-5/8" Hole

2-7/8" 6.5# P-110/L80 @ 13,900'  
 Cmt w/ 130 sx; TOC @ 12,060' (TS)

PBTD @ 13,760'  
 TD @ 13,900'

### Formation Tops

Delaware	5,164
Bone Spring	9,258
Wolfcamp	12,290

Wolfcamp perms: 13,300 - 13,336'

Top of fish @ 13,480'

Wolfcamp perms: 13,553 - 13,691' tag fill @ 11,050 11/2014

Not to Scale	
By: HJG	2/18/21




Well Name: Triste Draw 34 State #2  
 Location: 660' FSL & 1883' FEL Sec. 34-24S-33E  
 County: Lea, NM  
 Lat/Long: 32.1686363, -103.557724 NAD83  
 API #: 30-025-34572  
 Spud Date: 5/20/99  
 Compl. Date: 6/20/99



### Proposed Wellbore Diagram:

KB: 3,501'  
 GL: 3,481'

14-3/4" Hole  
 11-3/4" 42# H40 @ 677'  
 Cmt w/ 350 sx (circ)  
 11" Hole  
 8-5/8" 32# HCK-55/J-55 @ 4,974'  
 Cmt w/ 1,175 sx (circ)  
 7-7/8" Hole  
 5-1/2" 17# P-110 @ 12,856'  
 Cmt w/ 1,100 sx; TOC @ 4,470' (Calc)  
 4-5/8" Hole  
 2-7/8" 6.5# P-110/L80 @ 13,900'  
 Cmt w/ 130 sx; TOC @ 12,060' (TS)



Perf @ 730' & sqz 175 sx class C cmt to surface

Perf @ 2,500' & sqz 25 sx class C cmt to 2,370'

Spot 30 sx class C cmt plug @ 5,215 - 4,920'  
 WOC & Tag

Spot 25 sx class C cmt plug @ 7,300 - 7,100'

Spot 25 sx class H cmt plug @ 9,310 - 9,110'

Cut TBG @ ~12,000' after running free-point

Set CIBP w/ 30 sx class H cmt @ 13,200' to 12,240'

Wolfcamp perms: 13,300 - 13,336'

Top of fish @ 13,480'

Wolfcamp perms: 13,553 - 13,691'

### Formation Tops

Delaware	5,164
Bone Spring	9,258
Wolfcamp	12,290

Not to Scale

By: HJG 2/18/21

**District I**  
1625 N. French Dr., Hobbs, NM 88240  
Phone:(575) 393-6161 Fax:(575) 393-0720  
**District II**  
811 S. First St., Artesia, NM 88210  
Phone:(575) 748-1283 Fax:(575) 748-9720  
**District III**  
1000 Rio Brazos Rd., Aztec, NM 87410  
Phone:(505) 334-6178 Fax:(505) 334-6170  
**District IV**  
1220 S. St Francis Dr., Santa Fe, NM 87505  
Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico**  
**Energy, Minerals and Natural Resources**  
**Oil Conservation Division**  
**1220 S. St Francis Dr.**  
**Santa Fe, NM 87505**

CONDITIONS  
  
Action 18331

CONDITIONS OF APPROVAL

Operator:	EOG RESOURCES INC	P.O. Box 2267	Midland, TX79702	OGRID:	7377	Action Number:	18331	Action Type:	C-103F
OCD Reviewer	Condition								
kfortner	See attached conditions of approval Note changes and additions to procedure								