

cefield by GCD. 6/2929247 Piezis1 PM					Form Cage 3 of		
<u>District I</u> – (575) 393-6161	Energy, Minerals and Natural Resources		***************************************	Revised	July 18, 2013		
1625 N. French Dr., Hobbs, NM 88240 District II – (575) 748-1283				WELL API NO. 30-015-32363			
811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIVISION			5. Indicate Type	of Lease		
District III - (505) 334-6178	1220 South St. Francis Dr.			STATE	FEE FEE	\bowtie	
1000 Rio Brazos Rd., Aztec, NM 87410 <u>District IV</u> – (505) 476-3460 Santa Fe, NM 87505				6. State Oil & G			
1220 S. St. Francis Dr., Santa Fe, NM 87505							
SUNDRY NOTICE (DO NOT USE THIS FORM FOR PROPOSA.	7. Lease Name of PARKWAY WE		ient Name				
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)				8. Well Number			
1. Type of Well: Oil Well Gas Well Other				15			
2. Name of Operator	9. OGRID Num	per					
Devon Energy Production Company, LP				6137			
3. Address of Operator				10. Pool name o			
333 W. Sheridan Avenue, Oklahoma	PARKWAY; BC	NE SPRING					
4. Well Location							
Unit Letter_A_:1310 feet		line and	lfe	et from theEas	tline		
Section 28	Township 19		Range 29E	NMPM	Eddy Count	y, NM	
	11. Elevation (Show whet	ther DR,	RKB, RT, GR, etc.				
	3335' GR						
10 01 1 4							
12. Check Ap	propriate Box to Indi	icate N	ature of Notice,	Report or Other	Data		
NOTICE OF INTE	ENTION TO:		QLID	SEQUENT RE	DODT OF		
		\boxtimes	REMEDIAL WOR		ALTERING C		
					P AND A		
			CASING/CEMEN		1 711071	ш	
DOWNHOLE COMMINGLE		_	G. 10.110.702.1112.11	_			
CLOSED-LOOP SYSTEM				Notify OCD 24 hrs.	prior to any wo	<mark>ork </mark>	
OTHER:			OTHER:	done			
13. Describe proposed or complete	ed operations. (Clearly st	tate all p	pertinent details, an	d give pertinent dat	es, including e	stimated date	
of starting any proposed work) proposed completion or recom). SEE RULE 19.15.7.14 pletion.	NMAC	C. For Multiple Co	mpletions: Attach	vellbore diagra	am of	
1 MIDU DO A Unit DOOL on district	- de transcribe - mon	• •					
 MIRU P&A Unit. POOH rod string Tag cmt @ 10415'. Spot 25 sx Cl F 			E'. T Ctraum @ 1027	20			
3. Spot 90 sx Cl H from 9250'-8520'.	WOC & tag. (T. Wolfcamn)	@ 10413 @ 9184'•	5 ; 1. Strawn @ 1027(DV tool 8600')	,,			
4. Set CIBP @ 6900'. Tag. Circ 10# sa	ilt gel. Spot 25 sx Cl C from	6900'-66	50'. Leak test. (Open	perfs @ 6950') \\\\C	C & Tag		
Perf @ 4955'. Sqz 30 sx Cl C in/ou	t from 4955'-4840'. <i>(T. Bone</i>	e Spring (@ 4900')				
6. Perf @ 3400'. Sqz 65 sx Cl C in/ou	t from 3400'-3150'. WOC &	tag. (T. L	Delaware @ 3346'; SI	noe @ 3200') Perf	@ 3250'		
Perf @ 1400'. Saz 65 sx Cl C in/ou	t from 1400'-1150', WOC &	tag. (B. 5	Salt @ 1214')				
 Perf @ 400'. Sqz 105 sx Cl C in/ou Cut wellhead off 3' BGL, set dry he 	t from 400' to surface. <i>(Sho</i>	e @ 265	Perf @ 315'				
5. Gut Weimeau on 5 Bot, Set dry III	sie marker.						
Spud Date:	ii.						
I hereby certify that the information about	ove is true and complete t	to the be	est of my knowledg	e and belief.			
	OUT IN THE PARTY OF THE PARTY O		,				
2/ >	7/						
SIGNATURE //	TITLE	Proc	luction Engineer_	DATE	6-1-0	٧ 1	
	E-mail address:armo	n.radfar	@dvn.com_PHC	ONE: <u>405-552-50</u>	14		
For State Use Only							
APPROVED BY:	TITLE		StallMa	NAGON. DA	_{TE} 6/14/	2021	
Conditions of Approval (if any):	HILE		Staff Ma	DA DA	.115		
****SEE ATTACHED CO	OA's****		Must be plu	aged by 6/14	1/2022		



Devon - General



CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- A notice of intent to plug and abandon a wellbore is required to be approved before plugging
 operations are conducted. A cement evaluation tool is required in order to ensure isolation of
 producing formations, protection of water and correlative rights. A cement bond log or other
 accepted cement evaluation tool is to be provided to the division for evaluation if one has not
 been previously run or if the well did not have cement circulated to surface during the original
 casing cementing job or subsequent cementing jobs. Insure all bradenheads have been
 exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E)Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410

Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. **Santa Fe, NM 87505**

CONDITIONS

Action 30383

CONDITIONS

Operator:	OGRID:		
DEVON ENERGY PRODUCTION COMPANY, LP	6137		
333 West Sheridan Ave.	Action Number:		
Oklahoma City, OK 73102	30383		
	Action Type:		
	[C-103] NOI Plug & Abandon (C-103F)		

CONDITIONS

Created By Cond	ndition	Condition Date
gcordero None	ne	6/14/2021