
estred by OCP: 2/28/2022 5:07:03 Pl Office	M State of New M Energy, Minerals and Na		Form C-103 <sup>1</sup> Revised July 18, 2013				
<u>District I</u> – (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240 <u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210 <u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410 <u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM	OIL CONSERVATIO 1220 South St. Fra Santa Fe, NM 8	N DIVISION ancis Dr.	WELL API NO. 30-015-24096 5. Indicate Type of Lease STATE FEE 6. State Oil & Gas Lease No.				
(DO NOT USE THIS FORM FOR PROPOSAI DIFFERENT RESERVOIR. USE "APPLICAT PROPOSALS.)	FION FOR PERMIT" (FORM C-101)	LUG BACK TO A	<ol> <li>Lease Name or Unit Agreement Name Emma QE Com</li> <li>Well Number</li> </ol>				
1. Type of Well: Oil Well       Ga         2. Name of Operator       EOG Resources, Inc.	as Well 🛛 Other		2 9. OGRID Number 7377				
<ol> <li>Address of Operator</li> <li>104 South Fourth Street, Artesia, NM</li> </ol>	88210		10. Pool name or Wildcat Penasco Draw; Permo Penn				
4. Well Location Unit Letter <u>O</u> : <u>66</u> Section 21	0 feet from the <u>Sout</u>	Range 24E	1980 feet from the <u>East</u> line NMPM Eddy County				
12 Check An	371 propriate Box to Indicate	2'GR Nature of Notice 1	Report or Other Data				
TEMPORARILY ABANDON	ENTION TO: PLUG AND ABANDON 🛛 CHANGE PLANS 🗌 MULTIPLE COMPL 🔲	SUBS REMEDIAL WORK COMMENCE DRIL CASING/CEMENT	LLING OPNS. P AND A				
CLOSED-LOOP SYSTEM OTHER: 13. Describe proposed or complete			Notify OCD 24 hrs. prior to any work done				
CLOSED-LOOP SYSTEM OTHER: 13. Describe proposed or complete of starting any proposed work proposed completion or recom	). SEE RULE 19.15.7.14 NMA ppletion.	l pertinent details, and	Notify OCD 24 hrs. prior to any work done				
<ul> <li>CLOSED-LOOP SYSTEM </li> <li>OTHER:</li> <li>13. Describe proposed or complete of starting any proposed work proposed completion or recorr</li> <li>EOG Resources, Inc. plans to plug and al</li> <li>MIRU all safety equipment as needed.</li> <li>Spot 25 sx Class "H" cement on top</li> <li>Set a CIBP at 7937'. Spot 25 sx Clast</li> <li>Set a CIBP at 7429'. Spot 25 sx Clast</li> <li>Set a CIBP at 6220'. Spot 25 sx Clast</li> <li>Set a CIBP at 5822'. Spot 62 sx Clast</li> <li>Spot a 25 sx Class "C" cement plug</li> <li>Perforate at 1815'. Attempt injection</li> <li>Perforate at 1150'. Attempt injection</li> </ul>	). SEE RULE 19.15.7.14 NMA apletion. bandon this well as follows: ed. NU BOP. POOH with producti of existing CIBP at 8650' to 8300 ss "H" cement on top of CIBP to 7 ss "H" cement on top of CIBP to 7 ss "C" cement on top of CIBP to 5 ss "C" cement on top of CIBP to 4 from 3875'-3505'. This will cover n rate. Squeeze with 29 sx Class "C /circulation. Squeeze with 106 sx C	on equipment. Remove t o'. This will cover Morro '587'. WOC and tag. Thi '079'. WOC and tag. Thi '079'. WOC and tag. Thi '850'. WOC and tag. Thi '915'. WOC and tag. Thi r Abo top. C'' cement from 1815'-16 C'' cement from 1150'-10 Class "C'' cement from 4	Notify OCD 24 hrs. prior to any work done				
<ul> <li>CLOSED-LOOP SYSTEM D</li> <li>OTHER:</li> <li>13. Describe proposed or complete of starting any proposed work proposed completion or recorr</li> <li>EOG Resources, Inc. plans to plug and al</li> <li>MIRU all safety equipment as needed.</li> <li>Spot 25 sx Class "H" cement on top</li> <li>Set a CIBP at 7937'. Spot 25 sx Clast</li> <li>Set a CIBP at 7429'. Spot 25 sx Clast</li> <li>Set a CIBP at 6220'. Spot 25 sx Clast</li> <li>Set a CIBP at 5822'. Spot 62 sx Clast</li> <li>Spot a 25 sx Class "C" cement plug</li> <li>Perforate at 1815'. Attempt injection</li> <li>Perforate at 441'. Attempt injection/surface. Back fill as needed.</li> </ul>	). SEE RULE 19.15.7.14 NMA apletion. bandon this well as follows: ed. NU BOP. POOH with producti of existing CIBP at 8650' to 8300 ss "H" cement on top of CIBP to 7 ss "H" cement on top of CIBP to 7 ss "C" cement on top of CIBP to 5 ss "C" cement on top of CIBP to 4 from 3875'-3505'. This will cover n rate. Squeeze with 29 sx Class "C /circulation. Squeeze with 106 sx C	on equipment. Remove t o'. This will cover Morro '587'. WOC and tag. Thi '079'. WOC and tag. Thi '079'. WOC and tag. Thi '850'. WOC and tag. Thi '915'. WOC and tag. Thi r Abo top. C'' cement from 1815'-16 C'' cement from 1150'-10 Class "C'' cement from 4	Notify OCD 24 hrs. prior to any work done				
<ul> <li>CLOSED-LOOP SYSTEM D</li> <li>OTHER:</li> <li>13. Describe proposed or complete of starting any proposed work proposed completion or recorr</li> <li>EOG Resources, Inc. plans to plug and al</li> <li>MIRU all safety equipment as needed.</li> <li>Spot 25 sx Class "H" cement on top</li> <li>Set a CIBP at 7937'. Spot 25 sx Clas</li> <li>Set a CIBP at 7429'. Spot 25 sx Clas</li> <li>Set a CIBP at 6220'. Spot 25 sx Clas</li> <li>Set a CIBP at 5822'. Spot 62 sx Clas</li> <li>Spot a 25 sx Class "C" cement plug</li> <li>Perforate at 1815'. Attempt injection</li> <li>Perforate at 441'. Attempt injection/surface. Back fill as needed.</li> <li>Cut off wellhead and install dry hole</li> </ul>	). SEE RULE 19.15.7.14 NMA npletion. bandon this well as follows: ed. NU BOP. POOH with producti of existing CIBP at 8650' to 8300 ss "H" cement on top of CIBP to 7 ss "H" cement on top of CIBP to 7 ss "C" cement on top of CIBP to 5 ss "C" cement on top of CIBP to 4 from 3875'-3505'. This will cover n rate. Squeeze with 29 sx Class "C circulation. Squeeze with 106 sx C e marker. Clean location as per reg	I pertinent details, and AC. For Multiple Con On equipment. Remove t O'. This will cover Morro 7587'. WOC and tag. Thi 7079'. WOC and tag. Thi 1915'. WOC and tag. Thi 1915'. WOC and tag. Thi r Abo top. C" cement from 1815'-16 C" cement from 1815'-16 C" cement from 1150'-10 Class "C" cement from 4 gulated. Must be	Notify OCD 24 hrs. prior to any work done				
CLOSED-LOOP SYSTEM       □         OTHER:       13. Describe proposed or complete of starting any proposed work proposed completion or record         EOG Resources, Inc. plans to plug and al         1. MIRU all safety equipment as needed         2. Spot 25 sx Class "H" cement on top         3. Set a CIBP at 7937'. Spot 25 sx Clas         4. Set a CIBP at 7429'. Spot 25 sx Clas         5. Set a CIBP at 6220'. Spot 25 sx Clas         6. Set a CIBP at 5822'. Spot 62 sx Clas         7. Spot a 25 sx Class "C" cement plug         8. Perforate at 1815'. Attempt injection         9. Perforate at 441'. Attempt injection/ surface. Back fill as needed.         11. Cut off wellhead and install dry hole         Wellbore schematics attached	). SEE RULE 19.15.7.14 NMA npletion. bandon this well as follows: ed. NU BOP. POOH with producti of existing CIBP at 8650' to 8300 ss "H" cement on top of CIBP to 7 ss "C" cement on top of CIBP to 7 ss "C" cement on top of CIBP to 4 from 3875'-3505'. This will cover n rate. Squeeze with 29 sx Class "C circulation. Squeeze with 106 sx C e marker. Clean location as per reg DCOA's**** Rig Release I	I pertinent details, and AC. For Multiple Com on equipment. Remove t y'. This will cover Morro 7587'. WOC and tag. Thi 7079'. WOC and tag. Thi 850'. WOC and tag. Thi 915'. WOC and tag. Thi 915'. WOC and tag. Thi r Abo top. C" cement from 1815'-16 C" cement from 1815'-16 C" cement from 1150'-10 Class "C" cement from 4 gulated. Must be Date:	Notify OCD 24 hrs. prior to any work done				

.

APPROVED BY: APP CONTINUE TITLE	Staff Manager	DATE	3/1/2022
Conditions of Approval (if any): Released to Imaging: 3/7/2022 8:28:34 AM	00 0		



Page 2 of 8

•

Emma (	З.	2 Propose	ed			Sec. 21-19S-24E 660' FSL & 1980				30-015-24096 3712'			
@ surface. San Andres top +				CASING									
Surface shoe + Surface plug						0.75		00405	<b>T</b>	D. H.		0. 700	
1				#	HOLE SIZE	SIZE	WGHT	GRADE	Тор	Bottom	Sx Cmt	Circ/TOC	TOC Methe
				A	17 1/2	13 3/8	48	?	0	275	300	Circ	
				B	12 1/4 7 7/8	8 5/8 4 1/2	24 11.6 & 10.5	? K-55	0	1,099 8,975	800 1200	Circ 3510	CBL
						=			-	-,			
lug 8: Perf @ 1150. 1030-1150. ag. Intermediate shoe	NOC &												
<b>3</b>				FORMAT	ION TOPS								
						FORMATION	TOP			Fromation	TOP		
						San Andres	391			Morrow	8653		
lug 7: Perf @ 1815. 1695-1815.	NOC & tag. 🔤					Glorieta	1765						
lorieta top						Abo	3825						
						Wolfcamp	4965						
						Cisco	6228						
						Canyon	7296						
						Strawn	7754						
						Atoka	8388						
TOC = 3510'				Perforatio	on Detail								
ig 6: 3505-3875. Abo top					Formation	Тор	Bottom			Т	eatment		
ug 5: CIBP @ 5822. 4915-5822.	WOC 8 tog			А	Morrow	8,711	8,744	2500 gals	3 7 5%	% MSA, N2 and 8 balls			
olfcamp perfs and top	woo a lag.			в	Strawn	7,987	8,002	2500 gals	00 gals. 7.5% MSA, N2 and 24 balls. Frac'd w/5000# 100 mesh +				
MUK	-			0	0	7.479	7.567		20/40 sand. 1000gal 7.5% MSA + 15000gal gelled KCL & CO2				
Wolfcamp perfs 5872-5876	N N		~	C	Canyon	1 .			500gal 15% NEFE acid and 11 ball sealers				
lug 4: CIBP @ 6220. 5850-6220. isco perfs & top	WOC & tag.	Contractal		E	Cisco Wolfcamp	6270 5872	6940 5876	4500gal 15% MCA, N2 + ball sealers. 3000gal. 15% NE acid, N2 + balls 1000gal 15% MCA + 6 ball sealers				Dalls	
			MMA										
Cisco perfs 6270-6940 -				#	SX	Class	Тор	Bottom	Δ	Notes			Tag
I		e garegaren			UX.	01000	TOP	Dottoini	-	Remove 2 existing F	PD'a		rug
ug 3: CIBP @ 7429. 7079-7429.	WOC & tag.							0050	0.50	Spot 25sx on existin	g CIBP @ 8	650. Morrow	
nyon perfs & top				1	25	Н	8300	8650	350	perfs + Morrow & At CIBP @ 7937. Spot	UKA TOP 25sx, WOC	& tag, Strawn	N
Canyon perfs 7479-7567			$\leq$	2	25	н	7587	7937	350	perfs and top		-	Y
				3	25	н	7079	7429	350	CIBP @ 7429. Spot perfs and top	25sx. WOC	& tag. Canyon	Y
ug 2: CIBP @ 7937. 7587-7937.	WOC & tag.	A CARE M		4	25	С	5850	6220	370	CIBP @ 6220. Spot perfs and top	25sx. WOC	& tag. Cisco	Y
rawn perfs & top				4	20	U U	3830	0220	370	CIBP @ 5822. Spot	62sx. WOC	& tag. Wolfcamp	
Strawn perfs 7987-8002	VVV			5	62	С	4915	5822	907	perfs and top		5	Y
				6	25	С	3505	3875	370	Spot 25sx. Abo top			Ν
ug 1: 8300-8650. Morrow perfs prrow/Atoka tops				7	29	с	1695	1815	120	Perf @ 1815. Attem Glorieta top		÷	Y
	-		$\geq$	_		-				Perf @ 1150. Attem		9sx. WOC & tag.	
Morrow perfs 8711-8744	W	3	$\geq$	8	29	С	1030	1150	120	Intermediate casing Perf @ 441. Attemp	t Inj/Circ. Sq		P Y
				9	106	С	0	441	441	surface. San Andres Surface plug	s top + Surfa	ce shoe +	N
	с 🖌							I					

# CONDITIONS FOR PLUGGING AND ABANDONMENT

## OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E)Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - I) Glorieta
  - J) Yates.
  - K)Potash---(In the R-111-P Area (Page 3 & 4), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

## DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name2. Lease and Well Number3. API Number4. Unit Letter5. QuarterSection (feet from the North, South, East or West)6. Section, Township and Range7. Plugging Date8. County(SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

### SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

## R-111-P Area

#### T 18S – R 30E

Sec 10 Unit P. Sec 11 Unit M,N. Sec 13 Unit L,M,N. Sec 14 Unit C -P. Sec 15 Unit A G,H,I,J,K,N,O,P. Sec 22 Unit All except for M. Sec 23, Sec 24 Unit C,D,E,L, Sec 26 Unit A-G, Sec 27 Unit A,B,C

#### T 19S – R 29E

Sec 11 Unit P. Sec 12 Unit H-P. Sec 13. Sec 14 Unit A,B,F-P. Sec 15 Unit P. Sec 22 Unit A,B,C,F,G,H,I,J K,N,O,P. Sec 23. Sec 24. Sec 25 Unit D. Sec 26 Unit A- F. Sec 27 Unit A,B,C,F,G,H.

#### T 19S – R 30E

Sec 2 Unit K,L,M,N. Sec 3 Unit I,L,M,N,O,P. Sec 4 Unit C,D,E,F,G,I-P. Sec 5 Unit A,B,C,E-P. Sec 6 Unit I,O,P. Sec 7 – Sec 10. Sec 11 Unit D, G—P. Sec 12 Unit A,B,E-P. Sec 13 Unit A-O. Sec 14-Sec 18. Sec 19 Unit A-L, P. Sec 20 – Sec 23. Sec 24 Unit C,D,E,F,L,M,N. Sec 25 Unit D. Sec 26 Unit A-G, I-P. Sec 27, Sec 28, Sec 29 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 32 Unit A,B,G,H,I,J,N,O,P. Sec 33. Sec 34. Sec 35. Sec 36 Unit D,E,F,I-P.

#### T 19S – R 31E

Sec 7 Unit C,D,E,F,L. Sec 18 Unit C,D,E,F,G,K,L. Sec 31 Unit M. Sec 34 Unit P. Sec 35 Unit M,N,O. Sec 36 Unit O,P.

#### T 20S – R 29E

Sec 1 Unit H,I,P. Sec 13 Unit E,L,M,N. Sec 14 Unit B-P. Sec 15 Unit A,H,I,J,N,O,P. Sec 22 Unit A,B,C,F,G,H,I,J,O,P. Sec 23. Sec 24 Unit C,D,E,F,G,J-P. Sec 25 Unit A-O. Sec 26. Sec 27 Unit A,B,G,H,I,J,O,P. Sec 34 Unit A,B,G,H. Sec 35 Unit A-H. Sec 36 Unit B-G.

#### T 20S – R 30E

Sec 1 – Sec 4. Sec 5 Unit A,B,C,E-P. Sec 6 Unit E,G-P. Sec 7 Unit A-H,I,J,O,P. Sec 8 – 17. Sec 18 Unit A,B,G,H,I,J,O,P. Sec 19 Unit A,B,G,H,I,J,O,P. Sec 20 – 29. Sec 30 Unit A-L,N,O,P. Sec 31 Unit A,B,G,H,I,P. Sec 32 – Sec 36.

#### T 20S – R 31E

Sec 1 Unit A,B,C,E-P. Sec 2. Sec 3 Unit A,B,G,H,I,J,O,P. Sec 6 Unit D,E,F,J-P. Sec 7. Sec 8 Unit E-P. Sec 9 Unit E,F,J-P. Sec 10 Unit A,B,G-P. Sec 11 – Sec 36.

#### T 21S – R 29E

Sec 1 – Sec 3. Sec 4 Unit L1 – L16,I,J,K,O,P. Sec 5 Unit L1. Sec 10 Unit A,B,H,P. Sec 11 – Sec 14. Sec 15 Unit A,H,I. Sec 23 Unit A,B. Sec 24 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 25 Unit A,O,P. Sec 35 Unit G,H,I,J,K,N,O,P. Sec 36 A,B,C,F – P.

#### T 21S – R 30E

Sec 1 – Sec 36

#### T 21S – R 31E

Sec 1 – Sec 36

### T 22S – R 28E

Sec 36 Unit A,H,I,P.

## T 22S – R 29E

Sec 1. Sec2. Sec 3 Unit I,J,N,O,P. Sec 9 Unit G – P. Sec 10 – Sec 16. Sec 19 Unit H,I,J. Sec 20 – Sec 28. Sec 29 Unit A,B,C,D,G,H,I,J,O,P. Sec 30 Unit A. Section 31 Unit C – P. Sec 32 – Sec 36

## T 22S – R 30E

Sec 1 – Sec 36

## T 22S – R 31E

Sec 1 – Sec 11. Sec 12 Unit B,C,D,E,F,L. Sec 13 Unit E,F,K,L,M,N. Sec 14 – Sec 23. Sec 24 Unit C,D,E,F,K,L,M,N. Sec 25 Unit A,B,C,D. Sec 26 Unit A,B,C,D,G,H. Sec 27 – Sec 34.

## T 23S – R 28E

Sec 1 Unit A

## T 23S – R 29E

Sec 1 – Sec 5. Sec 6 Unit A – I, N,O,P. Sec 7 Unit A,B,C,G,H,I,P. Sec 8 Unit A – L, N,O,P. Sec 9 – Sec 16. Sec 17 Unit A,B,G,H,I,P. Sec 21 – Sec 23. Sec 24 Unit A – N. Sec 25 Unit D,E,L. Sec 26. Sec 27. Sec 28 Unit A – J, N,O,P. Sec 33 Unit A,B,C. Sec 34 Unit A,B,C,D,F,G,H. Sec 35. Sec 36 Unit B,C,D,E,F,G,K,L.

## T 23S – R 30E

Sec 1 – Sec 18. Sec 19 Unit A – I,N,O,P. Sec 20, Sec 21. Sec 22 Unit A – N, P. Sec 23, Sec 24, Sec 25. Sec 26 Unit A,B,F-P. Sec 27 Unit C,D,E,I,N,O,P. Sec 28 Unit A – H, K,L,M,N. Sec 29 Unit A – J, O,P. Sec 30 Unit A,B. Sec 32 A,B. Sec 33 Unit C,D,H,I,O,P. Sec 34, Sec 35, Sec 36.

## T 23S – R 31E

Sec 2 Unit D,E,J,O. Sec 3 – Sec 7. Sec 8 Unit A – G, K – N. Sec 9 Unit A,B,C,D. Sec 10 Unit D,P. Sec 11 Unit G,H,I,J,M,N,O,P. Sec 12 Unit E,L,K,M,N. Sec 13 Unit C,D,E,F,G,J,K,L,M,N,O. Sec 14. Sec 15 Unit A,B,E – P. Sec 16 Unit I, K – P. Sec 17 Unit B,C,D,E, I – P. Sec 18 – Sec 23. Sec 24 Unit B – G, K,L,M,N. Sec 25 Unit B – G, J,K,L. Sec 26 – Sec 34. Sec 35 Unit C,D,E.

## T 24S – R 29E

Sec 2 Unit A, B, C, D. Sec 3 Unit A

## T 24S – R 30E

Sec 1 Unit A – H, J – N. Sec 2, Sec 3. Sec 4 Unit A,B,F – K, M,N,O,P. Sec 9 Unit A – L. Sec 10 Unit A – L, O,P. Sec 11. Sec 12 Unit D,E,L. Sec 14 Unit B – G. Sec 15 Unit A,B,G,H.

## T 24S – R 31E

Sec 3 Unit B – G, J – O. Sec 4. Sec 5 Unit A – L, P. Sec 6 Unit A – L. Sec 9 Unit A – J, O,P. Sec 10 Unit B – G, K – N. Sec 35 Unit E – P. Sec 36 Unit E,K,L,M,N.

## T 25S – R 31E

Sec 1 Unit C,D,E,F. Sec 2 Unit A – H.

District I 1625 N. French Dr., Hobbs, NM 88240 Phone: (575) 393-6161 Fax: (575) 393-0720 District II

811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III

1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

District IV 1220 S. St Francis Dr., Santa Fe, NM 87505 Phone: (505) 476-3470 Fax: (505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. Santa Fe, NM 87505

CONDITIONS

Operator:	OGRID:
EOG RESOURCES INC	7377
P.O. Box 2267	Action Number:
Midland, TX 79702	84977
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

#### CONDITIONS

Created By		Condition Date
gcordero	None	3/1/2022

Page 8 of 8

.

Action 84977