Cesyed by Ocp 3/6/2022 Historic Office			Form C-103
<u>District I</u> – (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240	Energy, Minerals and Nat	ural Resources	Revised July 18, 2013 WELL API NO.
<u>District II</u> – (575) 748-1283			30-015-23961
811 S. First St., Artesia, NM 88210	OIL CONSERVATION		5. Indicate Type of Lease
<u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Fra		STATE STATE
District IV - (505) 476-3460	Santa Fe, NM 8	7505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM			LG-1198
87505 SUNDRY NO	TICES AND REPORTS ON WELLS	S	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PRO	POSALS TO DRILL OR TO DEEPEN OR PL	LUG BACK TO A	Anderson CS State
DIFFERENT RESERVOIR. USE "APF PROPOSALS.)	LICATION FOR PERMIT" (FORM C-101) F	OR SUCH	8. Well Number
1. Type of Well: Oil Well	Gas Well 🛛 Other		2
2. Name of Operator			9. OGRID Number
EOG Resources, Inc.			7377
3. Address of Operator			10. Pool name or Wildcat
104 South Fourth Street, Artesia	, NM 88210		Penasco Draw; Permo Penn
4. Well Location			
Unit Letter J :	1650 feet from the South	line and	1980 feet from the East line
Section 14	Township 18S Ra	ange 24E	NMPM Eddy County
	11. Elevation (Show whether DR	R, RKB, RT, GR, etc	
12. Checl	Appropriate Box to Indicate N	9'GR Nature of Notice.	. Report or Other Data
			-
PERFORM REMEDIAL WORK [	INTENTION TO:	REMEDIAL WOR	
TEMPORARILY ABANDON			RILLING OPNS. P AND A
		CASING/CEMEN	
		CASING/CEWEN	
	<b>⊿</b>		Notify OCD 24 hrs. prior to any work
OTHER:		OTHER:	done
13. Describe proposed or con	npleted operations. (Clearly state all	pertinent details, an	na give pertinent dates, including estimated dat
		C. For Multiple Co	ompletions: Attach wellbore diagram of
proposed completion or	ecompletion.		
EOG Resources, Inc. plans to plug	and abandon this well as follows:		
	needed. NU BOP. POOH with production on top of existing packer at 8175'. WOC		
			916'. WOC and tag. This will cover DV tool and
Canyon top.			
	sx Class "C" cement on top of CIBP to 59		
	sx Class "C" cement on top of CIBP to 46		
			3825'. WOC and tag. This will cover Abo top. 981'. WOC and tag. This will cover casing shoe and
San Andres top.	centin rate. Squeeze with 28 sx Class C	cement 110111 1093 -	. woo and tag. This will cover casing shoe and
	ction rate. Squeeze with 155 sx Class "C	" cement at 606' and	circulate up to surface. Verify cement at surface.
Back fill as needed.	-		
9. Cut off wellhead and install d	ry hole marker. Clean location as per regu	ılated.	
Wellbore schematics attached			
in encore senemanes anaonea			
Spud Date:	Rig Release D	ate:	
hereby certify that the information	n above is true and complete to the b	est of my knowled	ge and belief
• •	-	•	-
SIGNATURE / ma gy wer	TA	egulatory Specialist	t DATE <u>March 6, 2022</u>
I hereby certify that the information SIGNATURE <i>Time Huses</i> Type or print name <u>Tina H</u> For State Use Only		•	t DATE <u>March 6, 2022</u>

APPROVED BY:	
Conditions of Approval (if any):	
Conditions of Approval (if any): Released to Imaging: 3/16/2022 11:15:53 AM	

DATE\_\_\_\_

•

Anders	on CS Stat	te 2 Currer	nt	S	ec-TWN-RNG FOOTAGES			L		30-015-23961 3679.5			
									4				
				CASING D		1		1				1	T
					OLE SIZE	SIZE	WGHT	GRADE	Тор	Bottom	Sx Cmt	Circ/TOC	TOC Me
				A	17 1/2	13 3/8	48	J-55	0	396	600	1" to surface	
	A			в	12 1/4	8 5/8	24	K-55	0	1,043	300	Circ	
	~			C	7 7/8	4 1/2	10.5/11.6	J-55	0	8,276	1000	4310	CBI
					,.					DV tool @ 7017			
				FORMATIO	ON TOPS								
	В				ormation	Top (MD)		Formation	Top (MD)		Formation	Top (MD)	
	-				an Andres	556		Atoka	8061				
				Ab		3916		Morrow	8276				
					olfcamp	5034			0210				
					sco	6259							
				Ca	anyon	7234							
C 4310 CBL					DETAIL g 5001 pkr @ 5001								
4310 CBL					g 5001 pkr @ 5001	Class	Тор	Bottom	Δ	Notes			Та
4310 CBL				2 3/8 tubing PLUGS #		Class	Тор	Bottom	Δ	Notes			Та
4310 CBL				2 3/8 tubing	g 5001 pkr @ 5001	Class	Тор	Bottom	Δ	Notes			Та
1310 CBL				2 3/8 tubing PLUGS #	g 5001 pkr @ 5001	Class	Тор	Bottom	Δ	Notes			Ta
4310 CBL				2 3/8 tubing PLUGS # 1 2	g 5001 pkr @ 5001	Class	Тор	Bottom	Δ	Notes			Ta
4310 CBL				2 3/8 tubing PLUGS # 1 2 3	g 5001 pkr @ 5001	Class	Тор	Bottom	Δ	Notes			Ta
4310 CBL				2 3/8 tubing PLUGS # 1 2	g 5001 pkr @ 5001	Class	Тор	Bottom	Δ	Notes			Ta
1310 CBL				2 3/8 tubing PLUGS # 1 2 3	g 5001 pkr @ 5001	Class	Тор	Bottom	Δ	Notes			Ta
310 CBL				2 3/8 tubing PLUGS # 1 2 3 4	g 5001 pkr @ 5001	Class	Тор	Bottom	Δ	Notes			Ta
4310 CBL				2 3/8 tubing PLUGS # 1 2 3 4 5	g 5001 pkr @ 5001	Class	Тор	Bottom	Δ	Notes			Tag
				2 3/8 tubin PLUGS # 1 2 3 4 5 6	g 5001 pkr @ 5001	Class	Тор	Bottom	Δ	Notes			Taş
				2 3/8 tubing PLUGS # 1 2 3 4 5	g 5001 pkr @ 5001	Class	Тор	Bottom		Notes			Ta
amp perfs 5049-5097				2 3/8 tubin PLUGS # 1 2 3 4 5 6	g 5001 pkr @ 5001	Class	Тор	Bottom		Notes			Ta
amp perfs 5049-5097 2 6339		× × × ×		2 3/8 tubin PLUGS # 1 2 3 4 5 6	g 5001 pkr @ 5001	Class	Тор	Bottom		Notes			Ta
camp perfs 5049-5097 2) 6339		× × × ×		2 3/8 tubin PLUGS # 1 2 3 4 5 6 7	g 5001 pkr @ 5001		Top	Bottom		Notes			Tat
camp perfs 5049-5097 9 6339 9 perfs 6387-6792		X X		2 3/8 tubin PLUGS # 1 2 3 4 5 6 7 Fo	g 5001 pkr @ 5001	Гор	Bottom						
camp perfs 5049-5097 @ 6339 o perfs 6387-6792		× ×		2 3/8 tubin PLUGS # 1 2 3 4 5 6 7 Fo Ca	g 5001 pkr @ 5001	Тор 6,960	Bottom	Acidized w/250	0 gals 15% NE a	nitrogen plus i			
fcamp perfs 5049-5097 @ 6339 :co perfs 6387-6792 ? @ 6820				2 3/8 tubin PLUGS # 1 2 3 4 5 6 7 Fo Ca Atc	g 5001 pkr @ 5001	Тор 6,960 8,218	Bottom 6,996 8,242	Acidized w/250	0 gals 15% NE a 0 gals 15% DS-3	ncid & nitrogen plus 1	8 balls ealers.		
C 4310 CBL Ifcamp perfs 5049-5097 @ 6339 co perfs 6387-6792 P @ 6820 iyon perfs (sqz'd) 6960-695 Tool @ 7017 Tool @ 7017	96			2 3/8 tubin PLUGS # 1 2 3 4 5 6 7 6 7 Ca Atte	g 5001 pkr @ 5001	Тор 6,960	Bottom 6,99 8,242 6,792	Acidized w/250 Acidized w/250 Acidized w/250 Acidized w/50	0 gais 15% NE a 0 gais 15% NE a 0 gais 15% NE s	nitrogen plus i	8 balls ealers. ball sealers		s 15% NE 2
fcamp perfs 5049-5097 @ 6339 co perfs 6387-6792 2 @ 6820 iyon perfs (sqz'd) 6960-695 Tool @ 7017 3 @ 8175' w/SV	96			2 3/8 tubin PLUGS # 1 2 3 4 5 6 7 6 7 Ca Atte	g 5001 pkr @ 5001	Top 6,960 8,218 6,387	Bottom 6,99 8,242 6,792	Acidized w/250 Acidized w/250 Acidized w/250 Acidized w/50	0 gais 15% NE a 0 gais 15% NE a 0 gais 15% NE s	acid & nitrogen plus 30 acid and N2 with TE acid and N2 plus	8 balls ealers. ball sealers		s 15% NE 2
fcamp perfs 5049-5097 @ 6339 co perfs 6387-6792 2 @ 6820 yon perfs (sqz'd) 6960-695 Tool @ 7017		x x		2 3/8 tubin PLUGS # 1 2 3 4 5 6 7 6 7 6 7 6 7 6 7 6 7 6 7 6 7 6 7 6 7 6 7 6 7 7 7 8 7 8 8 9 8 9 8 9 8 9 8 9 8 9 8 9 8 9 9 9 9 9 9 9 9 9 9 9 9 9	g 5001 pkr @ 5001	Top 6,960 8,218 6,387 5,049	Bottom 6,996 8,242 6,792 5,097	Acidized w/250 Acidized w/250 Acidized w/250 Acidized w/300	0 gals 15% NE a 0 gals 15% NE a 0 gals 15% NE a	tcid & nitrogen plus t 30 acid and N2 with TE acid and N2 with 12 t acid and N2 with 12 t	8 balls ealers. ball sealers ball sealers. R	eacidized w/1000	s 15% NE a
fcamp perfs 5049-5097 @ 6339 *o perfs 6387-6792 *@ 6820 yon perfs (sqz'd) 6960-695 fool @ 7017 * @ 8175* w/SV	96	x x		2 3/8 tubin PLUGS # 1 2 3 4 5 6 7 6 7 6 7 6 7 6 7 6 7 6 7 6 7 6 7 7 7 8 7 8 8 8 9 8 8 8 8 8 8 8 8 8 8 8 8 8	g 5001 pkr @ 5001	Top 6,960 8,218 6,387 5,049 w/75sx cement	Bottom 6,990 8,242 6,792 5,091 and drilled out	Acidized w/250 Acidized w/250 Acidized w/50 Acidized w/300 cement retainer	0 gals 15% NE a 0 gals 15% NE a 0 gals 15% NE a	tcid & nitrogen plus t 30 acid and N2 with TE acid and N2 with 12 t acid and N2 with 12 t	8 balls ealers. ball sealers ball sealers. R	eacidized w/1000	s 15% NE a

Anderson CS State 2 Proposed		Sec-TWN-RNG FOOTAGES			L		30-015-23961 3679.5			
surface. San Andres top +		0.05744								
Inface csg shoe + Surface plug	#	G DETAIL HOLE SIZE	SIZE	WGHT	GRADE	Тор	Bottom	Sx Cmt	Circ/TOC	TOC Meth
	# A	17 1/2	13 3/8	48	J-55	0	396	600	1" to surface	TOC Meth
	В	12 1/4	8 5/8	24	K-55	0	1,043	300	Circ	
	C	7 7/8	4 1/2	10.5/11.6	J-55	0	8,276	1000	4310	CBL
		1 110	4 1/2	10.3/11.0	0-00	0	DV tool @ 7017	1000	4310	OBL
			<u>.                                    </u>							
	FORMA	TION TOPS								
ug 6: Perf @ 1093. 981-1093. WOC &		Formation	Top (MD)		Formation	Top (MD)		Formation	Top (MD)	
g. Int csg shoe + San Andres top B		San Andres	556		Atoka	8061				L
		Abo	3916		Morrow	8276				L
		Wolfcamp	5034							
		Cisco	6259							
		Canyon	7234							L
	TURING	G DETAIL								
		bing 5001 pkr @ 5001								
ug 5: Perf @ 3966. 3825-3966. WOC & tag.	2 0/0 14									
bo top	PLUGS	;								
	#	SX	Class	Тор	Bottom	Δ	Notes			Tag
							Remove exisiting R	BP@ 6339 an	nd nkr @ 6820	
							Spot 25sx on existin			
	1	25	Н	7839	8168	329	Atoka perfs + Atoka			Y
DC 4310 CBL	2	25	с	6916	7284	368	Perf @ 7067. Attem DV tool + Canyon to	pt Inj. Spot 25	isx. WOC & tag.	Y
	-			0010	7204	000	CIBP @ 6337. Spot		k tag. Cisco perfs	-
ug 4: CIBP @ 4999. 4631-4999. WOC	3	25	С	5969	6337	368	+ Cisco top CIBP @ 4999. Pres	cure test. Sno	A 25 CX MOC 8	Y
tag. Wolfcamp perfs + Wolfcamp top	4	25	С	4631	4999	368	tag. Wolfcamp perfs			Y
	_						Perf @ 3966. Attem			
olfcamp perfs 5049-5097	5	35	С	3825	3966	141	Abo top Perf @ 1093. attem	nt Ini Saz 28s	sx WOC & tag	Y
	6	28	С	981	1093	112	Int csg shoe + San	Andres top	-	Y
ug 3: CIBP @ 6337. 5969-6337. WOC & tag. sco perfs + Cisco top Existing Pkr @ 6339	7	155	с	0	606	606	Perf @ 396. Attemp surface. San Andre			Y
Existing PKi @ 6539	1	155	U	0	000	000	surface. San Andre	is top + Suriac	e csg shoe +	T
sco perfs 6387-6792										
Existing RBP @ 6820	0	1					1	1		
		Formation	Тор	Bottom	Treatment					
ug 2: Perf @ 7067. 6916-7284. WOC & tag.										
/ tool + Canyon top	-	Canyon (squeezed)	6,960				acid & nitrogen plus		E (1000 1	4500 NE
anyon perfs (sqz'd) 6960-6996 DV Tool @ 7017		Atoka Cisco	8,218 6,387				30 acid and N2 with FE acid and N2 plus		. Frac w/1000 gais	15% INE acid
		Wolfcamp	5,049			-			Popoidized w/1000	aala gollod oo
		Trioncamp	5,049	5,09	r produžed w/30	oo yala 10% INE	acid and N2 with 12	Dali SedielS. R	eaciuized w/ 1000	yais yelleu ac
ug 1: 7839-8168. Spot sx on existing pkr.										
OC & tag. Atoka perfs + Atoka top PKR @ 8175' w/SV		ONAL DETAIL								
	ADDITI									
								(0000 D (		0.40
	3/1982-	squeezed perforations forated 6387-6792 and				, cement and DV	tool cleaned to TD o	of 8280. Perfo	rated Atoka 8218-8	3242

.

# CONDITIONS FOR PLUGGING AND ABANDONMENT

# OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E)Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - I) Glorieta
  - J) Yates.
  - K)Potash---(In the R-111-P Area (Page 3 & 4), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. **If cement does not exist behind casing strings at recommended formation depths,** the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

# DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name2. Lease and Well Number3. API Number4. Unit Letter5. QuarterSection (feet from the North, South, East or West)6. Section, Township and Range7. Plugging Date8. County(SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

# SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

# R-111-P Area

### T 18S – R 30E

Sec 10 Unit P. Sec 11 Unit M,N. Sec 13 Unit L,M,N. Sec 14 Unit C -P. Sec 15 Unit A G,H,I,J,K,N,O,P. Sec 22 Unit All except for M. Sec 23, Sec 24 Unit C,D,E,L, Sec 26 Unit A-G, Sec 27 Unit A,B,C

### T 19S – R 29E

Sec 11 Unit P. Sec 12 Unit H-P. Sec 13. Sec 14 Unit A,B,F-P. Sec 15 Unit P. Sec 22 Unit A,B,C,F,G,H,I,J K,N,O,P. Sec 23. Sec 24. Sec 25 Unit D. Sec 26 Unit A- F. Sec 27 Unit A,B,C,F,G,H.

### T 19S – R 30E

Sec 2 Unit K,L,M,N. Sec 3 Unit I,L,M,N,O,P. Sec 4 Unit C,D,E,F,G,I-P. Sec 5 Unit A,B,C,E-P. Sec 6 Unit I,O,P. Sec 7 – Sec 10. Sec 11 Unit D, G—P. Sec 12 Unit A,B,E-P. Sec 13 Unit A-O. Sec 14-Sec 18. Sec 19 Unit A-L, P. Sec 20 – Sec 23. Sec 24 Unit C,D,E,F,L,M,N. Sec 25 Unit D. Sec 26 Unit A-G, I-P. Sec 27, Sec 28, Sec 29 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 32 Unit A,B,G,H,I,J,N,O,P. Sec 33. Sec 34. Sec 35. Sec 36 Unit D,E,F,I-P.

### T 19S – R 31E

Sec 7 Unit C,D,E,F,L. Sec 18 Unit C,D,E,F,G,K,L. Sec 31 Unit M. Sec 34 Unit P. Sec 35 Unit M,N,O. Sec 36 Unit O,P.

### T 20S – R 29E

Sec 1 Unit H,I,P. Sec 13 Unit E,L,M,N. Sec 14 Unit B-P. Sec 15 Unit A,H,I,J,N,O,P. Sec 22 Unit A,B,C,F,G,H,I,J,O,P. Sec 23. Sec 24 Unit C,D,E,F,G,J-P. Sec 25 Unit A-O. Sec 26. Sec 27 Unit A,B,G,H,I,J,O,P. Sec 34 Unit A,B,G,H. Sec 35 Unit A-H. Sec 36 Unit B-G.

### T 20S – R 30E

Sec 1 – Sec 4. Sec 5 Unit A,B,C,E-P. Sec 6 Unit E,G-P. Sec 7 Unit A-H,I,J,O,P. Sec 8 – 17. Sec 18 Unit A,B,G,H,I,J,O,P. Sec 19 Unit A,B,G,H,I,J,O,P. Sec 20 – 29. Sec 30 Unit A-L,N,O,P. Sec 31 Unit A,B,G,H,I,P. Sec 32 – Sec 36.

### T 20S – R 31E

Sec 1 Unit A,B,C,E-P. Sec 2. Sec 3 Unit A,B,G,H,I,J,O,P. Sec 6 Unit D,E,F,J-P. Sec 7. Sec 8 Unit E-P. Sec 9 Unit E,F,J-P. Sec 10 Unit A,B,G-P. Sec 11 – Sec 36.

### T 21S – R 29E

Sec 1 – Sec 3. Sec 4 Unit L1 – L16,I,J,K,O,P. Sec 5 Unit L1. Sec 10 Unit A,B,H,P. Sec 11 – Sec 14. Sec 15 Unit A,H,I. Sec 23 Unit A,B. Sec 24 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 25 Unit A,O,P. Sec 35 Unit G,H,I,J,K,N,O,P. Sec 36 A,B,C,F – P.

### T 21S – R 30E

Sec 1 – Sec 36

### T 21S – R 31E

Sec 1 – Sec 36

### T 22S – R 28E

Sec 36 Unit A,H,I,P.

# T 22S – R 29E

Sec 1. Sec2. Sec 3 Unit I,J,N,O,P. Sec 9 Unit G – P. Sec 10 – Sec 16. Sec 19 Unit H,I,J. Sec 20 – Sec 28. Sec 29 Unit A,B,C,D,G,H,I,J,O,P. Sec 30 Unit A. Section 31 Unit C – P. Sec 32 – Sec 36

### T 22S – R 30E

Sec 1 – Sec 36

### T 22S – R 31E

Sec 1 – Sec 11. Sec 12 Unit B,C,D,E,F,L. Sec 13 Unit E,F,K,L,M,N. Sec 14 – Sec 23. Sec 24 Unit C,D,E,F,K,L,M,N. Sec 25 Unit A,B,C,D. Sec 26 Unit A,B,C,D,G,H. Sec 27 – Sec 34.

### T 23S – R 28E

Sec 1 Unit A

### T 23S – R 29E

Sec 1 – Sec 5. Sec 6 Unit A – I, N,O,P. Sec 7 Unit A,B,C,G,H,I,P. Sec 8 Unit A – L, N,O,P. Sec 9 – Sec 16. Sec 17 Unit A,B,G,H,I,P. Sec 21 – Sec 23. Sec 24 Unit A – N. Sec 25 Unit D,E,L. Sec 26. Sec 27. Sec 28 Unit A – J, N,O,P. Sec 33 Unit A,B,C. Sec 34 Unit A,B,C,D,F,G,H. Sec 35. Sec 36 Unit B,C,D,E,F,G,K,L.

### T 23S – R 30E

Sec 1 – Sec 18. Sec 19 Unit A – I,N,O,P. Sec 20, Sec 21. Sec 22 Unit A – N, P. Sec 23, Sec 24, Sec 25. Sec 26 Unit A,B,F-P. Sec 27 Unit C,D,E,I,N,O,P. Sec 28 Unit A – H, K,L,M,N. Sec 29 Unit A – J, O,P. Sec 30 Unit A,B. Sec 32 A,B. Sec 33 Unit C,D,H,I,O,P. Sec 34, Sec 35, Sec 36.

# T 23S – R 31E

Sec 2 Unit D,E,J,O. Sec 3 – Sec 7. Sec 8 Unit A – G, K – N. Sec 9 Unit A,B,C,D. Sec 10 Unit D,P. Sec 11 Unit G,H,I,J,M,N,O,P. Sec 12 Unit E,L,K,M,N. Sec 13 Unit C,D,E,F,G,J,K,L,M,N,O. Sec 14. Sec 15 Unit A,B,E – P. Sec 16 Unit I, K – P. Sec 17 Unit B,C,D,E, I – P. Sec 18 – Sec 23. Sec 24 Unit B – G, K,L,M,N. Sec 25 Unit B – G, J,K,L. Sec 26 – Sec 34. Sec 35 Unit C,D,E.

# T 24S – R 29E

Sec 2 Unit A, B, C, D. Sec 3 Unit A

# T 24S – R 30E

Sec 1 Unit A – H, J – N. Sec 2, Sec 3. Sec 4 Unit A,B,F – K, M,N,O,P. Sec 9 Unit A – L. Sec 10 Unit A – L, O,P. Sec 11. Sec 12 Unit D,E,L. Sec 14 Unit B – G. Sec 15 Unit A,B,G,H.

# T 24S – R 31E

Sec 3 Unit B – G, J – O. Sec 4. Sec 5 Unit A – L, P. Sec 6 Unit A – L. Sec 9 Unit A – J, O,P. Sec 10 Unit B – G, K – N. Sec 35 Unit E – P. Sec 36 Unit E,K,L,M,N.

# T 25S – R 31E

Sec 1 Unit C,D,E,F. Sec 2 Unit A – H.

District I 1625 N. French Dr., Hobbs, NM 88240 Phone:(575) 393-6161 Fax:(575) 393-0720 District II

811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III

1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

District IV 1220 S. St Francis Dr., Santa Fe, NM 87505 Phone: (505) 476-3470 Fax: (505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. Santa Fe, NM 87505

CONDITIONS

Operator:	OGRID:
EOG RESOURCES INC	7377
P.O. Box 2267	Action Number:
Midland, TX 79702	87364
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

#### CONDITIONS

Created By		Condition Date
gcordero	None	3/14/2022

Page 8 of 8

.

Action 87364