
ecestication by Copy to Appropriate District 39 PM	State of New Mexico	Form C-103			
Office District I – (575) 393-6161 Energy,	Minerals and Natural Resources	Revised July 18, 2013			
1625 N. French Dr., Hobbs, NM 88240		WELL API NO.			
<u>District II</u> – (575) 748-1283	ONSERVATION DIVISION	30-025-36873			
511 5. 1 list 5t., Artesia, 1414 66210		5. Indicate Type of Lease			
District III – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	20 South St. Francis Dr.	STATE FEE			
<u>District IV</u> – (505) 476-3460	Santa Fe, NM 87505	6. State Oil & Gas Lease No.			
1220 S. St. Francis Dr., Santa Fe, NM		VO-5716			
87505					
SUNDRY NOTICES AND RE		7. Lease Name or Unit Agreement Name			
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL DIFFERENT RESERVOIR. LISE "APPLICATION FOR PER		Elvis BOV State Com			
DIFFERENT RESERVOIR. USE "APPLICATION FOR PER PROPOSALS.)	IMIT (FORM C-101) FOR SUCIT	8. Well Number			
1. Type of Well: Oil Well Gas Well	Other	1			
2. Name of Operator		9. OGRID Number			
EOG Resources, Inc.		7377			
3. Address of Operator		10. Pool name or Wildcat			
104 South Fourth Street, Artesia, NM 88210		X-4 Ranch; Atoka			
4. Well Location		1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -			
	om the Couth line and	1700 feet from the West line			
Unit Letter N : 990 feet from	om the South line and	1700 feet from the West line			
Section 22 Towns	hip 10S Range 34E	NMPM Lea County			
11. Elevation	(Show whether DR, RKB, RT, GR, etc.	.)			
	4193'GR				
12. Check Appropriate I	Box to Indicate Nature of Notice	Report or Other Data			
11 1		1			
NOTICE OF INTENTION 7	<mark>FO:</mark> SUE	SSEQUENT REPORT OF:			
PERFORM REMEDIAL WORK (PLUG AND A	ABANDON 🛛 REMEDIAL WOR	RK			
TEMPORARILY ABANDON ☐ CHANGE PL	ANS 🔲 COMMENCE DF	RILLING OPNS. P AND A			
PULL OR ALTER CASING ☐ MULTIPLE C	OMPL CASING/CEMEN	IT JOB 🔲			
DOWNHOLE COMMINGLE	_	<del>_</del>			
CLOSED-LOOP SYSTEM					
OTHER:	☐ OTHER:				
		nd give pertinent dates, including estimated date			
of starting any proposed work). SEE RUL					
proposed completion or recompletion.	1				
EOG Resources, Inc. plans to plug and abandon this	well as follows:				
200 resources, me. plans to plag and doubten the	well as follows.				
1. MIRU all safety equipment as needed. NU BO	P. POOH with production equipment.				
		OC and tag. This will cover Atoka perfs and top.			
3. Spot a 25 sx Class "H" cement plug from 9192					
4. Spot a 25 sx Class "H" cement plug from 7866					
5. Spot a 25 sx Class "C" cement plug from 5585	'-5333'. This will cover Glorieta top.				
6. Perforate at 4265'. Attempt injection rate. Spot	a 25 sx Class "C" cement plug from 426	5'-4013'. WOC and tag. This will cover casing			
shoe and San Andres top.					
7. Spot a 25 sx Class "C" cement plug from 2869					
8. Spot a 25 sx Class "C" cement plug from 2250	'-1998'. This will cover Rustler top.				
<ul><li>8. Spot a 25 sx Class "C" cement plug from 2250</li><li>9. Perforate at 481'. Attempt injection rate. Spot 5</li></ul>	'-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circu	late up to surface. Back fill as needed.			
8. Spot a 25 sx Class "C" cement plug from 2250	'-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circu	late up to surface. Back fill as needed.			
<ul> <li>8. Spot a 25 sx Class "C" cement plug from 2250</li> <li>9. Perforate at 481'. Attempt injection rate. Spot 5</li> <li>10. Cut off wellhead and install dry hole marker. C</li> </ul>	'-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circulean location as per regulated.	•			
<ul> <li>8. Spot a 25 sx Class "C" cement plug from 2250</li> <li>9. Perforate at 481'. Attempt injection rate. Spot 5</li> <li>10. Cut off wellhead and install dry hole marker. C</li> </ul>	'-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circu	•			
<ul> <li>8. Spot a 25 sx Class "C" cement plug from 2250</li> <li>9. Perforate at 481'. Attempt injection rate. Spot 5</li> <li>10. Cut off wellhead and install dry hole marker. C</li> </ul>	'-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circulean location as per regulated.	•			
<ul> <li>8. Spot a 25 sx Class "C" cement plug from 2250</li> <li>9. Perforate at 481'. Attempt injection rate. Spot 3</li> <li>10. Cut off wellhead and install dry hole marker. C</li> <li>Wellbore schematics attached</li> </ul> LPC Area Below	?-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circulean location as per regulated.  ground marker send pics before to the second	•			
<ul> <li>8. Spot a 25 sx Class "C" cement plug from 2250</li> <li>9. Perforate at 481'. Attempt injection rate. Spot 5</li> <li>10. Cut off wellhead and install dry hole marker. C</li> </ul>	'-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circulean location as per regulated.	packfilling hole  SEE ATTACHED CONDITIONS			
<ul> <li>8. Spot a 25 sx Class "C" cement plug from 2250</li> <li>9. Perforate at 481'. Attempt injection rate. Spot 3</li> <li>10. Cut off wellhead and install dry hole marker. C</li> <li>Wellbore schematics attached</li> </ul> LPC Area Below	?-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circulean location as per regulated.  ground marker send pics before to the second	packfilling hole			
8. Spot a 25 sx Class "C" cement plug from 2250 9. Perforate at 481'. Attempt injection rate. Spot 3 10. Cut off wellhead and install dry hole marker. C Wellbore schematics attached LPC Area Below Spud Date:	?-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circular lean location as per regulated.  ground marker send pics before k  Rig Release Date:	SEE ATTACHED CONDITIONS OF APPROVAL			
<ul> <li>8. Spot a 25 sx Class "C" cement plug from 2250</li> <li>9. Perforate at 481'. Attempt injection rate. Spot 3</li> <li>10. Cut off wellhead and install dry hole marker. C</li> <li>Wellbore schematics attached</li> </ul> LPC Area Below	?-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circular lean location as per regulated.  ground marker send pics before k  Rig Release Date:	SEE ATTACHED CONDITIONS OF APPROVAL			
8. Spot a 25 sx Class "C" cement plug from 2250 9. Perforate at 481'. Attempt injection rate. Spot 3 10. Cut off wellhead and install dry hole marker. C Wellbore schematics attached LPC Area Below  Spud Date:	2-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circulean location as per regulated.  ground marker send pics before k  Rig Release Date:	SEE ATTACHED CONDITIONS OF APPROVAL ge and belief.			
8. Spot a 25 sx Class "C" cement plug from 2250 9. Perforate at 481'. Attempt injection rate. Spot 3 10. Cut off wellhead and install dry hole marker. C Wellbore schematics attached LPC Area Below Spud Date:	?-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circular lean location as per regulated.  ground marker send pics before k  Rig Release Date:	SEE ATTACHED CONDITIONS OF APPROVAL ge and belief.			
8. Spot a 25 sx Class "C" cement plug from 2250 9. Perforate at 481'. Attempt injection rate. Spot 3 10. Cut off wellhead and install dry hole marker. C Wellbore schematics attached LPC Area Below  Spud Date:  I hereby certify that the information above is true at SIGNATURE Tina Huerta	2-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circulan location as per regulated.  ground marker send pics before to the Rig Release Date:  nd complete to the best of my knowled.  TITLE Regulatory Specialist	SEE ATTACHED CONDITIONS OF APPROVAL  ge and belief.  DATE March 17, 2022			
8. Spot a 25 sx Class "C" cement plug from 2250 9. Perforate at 481'. Attempt injection rate. Spot 3 10. Cut off wellhead and install dry hole marker. C Wellbore schematics attached LPC Area Below  Spud Date:  I hereby certify that the information above is true at SIGNATURE Tina Huerta  Type or print name Tina Huerta	2-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circulean location as per regulated.  ground marker send pics before k  Rig Release Date:	SEE ATTACHED CONDITIONS OF APPROVAL  ge and belief.  DATE March 17, 2022			
8. Spot a 25 sx Class "C" cement plug from 2250 9. Perforate at 481'. Attempt injection rate. Spot 3 10. Cut off wellhead and install dry hole marker. C Wellbore schematics attached LPC Area Below  Spud Date:  I hereby certify that the information above is true at SIGNATURE Tina Huerta  Type or print name Tina Huerta  For State Use Only	2-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circulan location as per regulated.  ground marker send pics before to the Rig Release Date:  nd complete to the best of my knowled.  TITLE Regulatory Specialist	SEE ATTACHED CONDITIONS OF APPROVAL  ge and belief.  DATE March 17, 2022			
8. Spot a 25 sx Class "C" cement plug from 2250 9. Perforate at 481'. Attempt injection rate. Spot 3 10. Cut off wellhead and install dry hole marker. C Wellbore schematics attached LPC Area Below  Spud Date:  I hereby certify that the information above is true at SIGNATURE Tina Huerta  Type or print name Tina Huerta  For State Use Only	2-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circulan location as per regulated.  ground marker send pics before to the Rig Release Date:  TITLE Regulatory Specialis  E-mail address: tina_huerta@eogres	SEE ATTACHED CONDITIONS OF APPROVAL  ge and belief.  DATE March 17, 2022  Durces.com PHONE: 575-748-4168			
8. Spot a 25 sx Class "C" cement plug from 2250 9. Perforate at 481'. Attempt injection rate. Spot 3 10. Cut off wellhead and install dry hole marker. C Wellbore schematics attached LPC Area Below  Spud Date:  I hereby certify that the information above is true at SIGNATURE Tina Huerta  Type or print name Tina Huerta	2-1998'. This will cover Rustler top. 50 sx Class "C" cement at 481' and circulan location as per regulated.  ground marker send pics before to the Rig Release Date:  nd complete to the best of my knowled.  TITLE Regulatory Specialist	SEE ATTACHED CONDITIONS OF APPROVAL  ge and belief.  DATE March 17, 2022  Durces.com PHONE: 575-748-4168			

Received by OCD: 3/17/2022 3:48:39 PM

Elvis BOV State Com 1 Current	Se	c-TWN-RNG: Surface	22-10S-34E 990' FSL & 1700'	FWL			: 30-025-3687 : 4193'	3		
COMMENTS							1100			
	CASING #	DETAIL Hole Size	O Si	Wt.	Grade	T	Bottom	Sx Cmt	TOC	TOC by
	# A	17 1/2	Csg. Size 13 3/8	48	H-40	Top 0	431	440	Surface	Circ.
	В	12 1/4	9 5/8	36/40	J-55	0	4215	1425	Surface	Circ.
A	С	8 3/4	5 1/2	17	HCP-110	0	12718	3205	Surface	Circ.
	FORMA	TION TOPS								
		Formation	Top (MD)		Formation	Top (MD)		Formation	Top (MD)	
		Rustler	2,200							
		Yates	2,819							
		San Andres	4,086							
	-	Glorieta Abo	5,535 7,816							+
		Wolfcamp LM.	9,142							+
		Atoka	11,618							+
		Atoka	11,010							1
В	No.	OD OD	Description	Longth		1	T			
	357	2 7/8"	Description 6.5# L-80 tbg. jts.	Length 11,757						+
	1	-	On/off tool	2						
	1	5 1/2"	Arrowset Packer	8						
										+
	ROD DE	TAIL [iDC]								
	No rods:	specified.								
										-
										+
										+
		,			*	*				
	PERFOR	RATION DETAIL	T	D-#		Farm -#:	T	Do#		
		Formation Atoka	Top 12,100	Bottom 12,117		Formation	Тор	Bottom		
		Atoka	12,100	11,948						+
		Atoka	11,810	11,822						
			,	,						
	ADDITIO	NAL DETAIL								
Existing Atoka Perfs: 11810' - 11822'										
Existing CIBP w/ 35; cmt: 11875' - 11910' Existing Atoka Perfs: 11938' - 11948'										
Existing Atoka Perfs: 11938' - 11948'										
Existing CIBP w/ 35' cmt: 12046' - 12081'										
Existing Atoka Perfs: 12100' - 12117'										
PBTD: 11,875 MD					KJP 3/16/2	022				
TD: 12,718 MD					NJF 3/10/2	U22				
· · · · · · · · · · · · · · · · · · ·	_				· ·					· ·

Received by OCD: 3/17/2022 3:48:39 PM



# CONDITIONS OF APPROVAL FOR PLUGGING AND ABANDONMENT OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at (575)-263-6633 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

# Company representative will be on location during plugging procedures.

- **1.** A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- **2.** Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- **3.** Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- **5.** A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can +be released.
- **6.** If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- **8.** Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- **10.** All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- **13.** A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- **14.** All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
- **16.** When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- **18.** A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
- A) Fusselman
- B) Devonian
- C) Morrow
- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- I) Glorieta
- J) Yates.
- K) Potash---(In the R-111-P Area (Potash Mine Area),

A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.

**21.** If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing.

# DRY HOLE MARKER REQ.UIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and Well Number
- 3. API Number
- 4. Unit letter
- 5. Quarter Section (feet from the North, South, East or West)
- 6. Section, Township and Range
- 7. Plugging Date
- 8. County

# SPECIAL CASES ----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

## SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

# **State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505**

COMMENTS

Action 91177

## **COMMENTS**

Operator:	OGRID:
EOG RESOURCES INC	7377
P.O. Box 2267	Action Number:
Midland, TX 79702	91177
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

### COMMENTS

Created By	Comment	Comment Date
plmartinez	DATA ENTRY PM.	5/3/2022

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

CONDITIONS

Action 91177

# **CONDITIONS**

Operator:	OGRID:
EOG RESOURCES INC	7377
P.O. Box 2267	Action Number:
Midland, TX 79702	91177
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

### CONDITIONS

Created By		Condition Date
kfortner	See attached conditions of approval	5/2/2022