Office	Sta	ite of New Mex	xico		For	rm C-103 <sup>1</sup> of 8
<u>District I</u> – (575) 393-6161	Energy, Min	nerals and Natur	al Resources	WELL API NO	Revised J	uly 18, 2013
1625 N. French Dr., Hobbs, NM 88240 <u>District II</u> – (575) 748-1283	OIL CON	SERVATION	DIVISION	30-025-30753		
811 S. First St., Artesia, NM 88210 <u>District III</u> – (505) 334-6178		South St. Fran		5. Indicate Ty		
1000 Rio Brazos Rd., Aztec, NM 87410 <u>District IV</u> – (505) 476-3460		nta Fe, NM 87		STATE 6 State Oil &	Gas Lease No.	
1220 S. St. Francis Dr., Santa Fe, NM		,		o. state on &	Gus Leuse 110.	
87505 SUNDRY NO	ΓICES AND REPOR	RTS ON WELLS		7. Lease Name	e or Unit Agreeme	ent Name
(DO NOT USE THIS FORM FOR PROP DIFFERENT RESERVOIR. USE "APPI				LOVINGTO	N SAN ANDF	RES LINIT
PROPOSALS.)  1. Type of Well: Oil Well	Gas Well  Otl			8. Well Numb		
2. Name of Operator	<del>_</del>	iici		9. OGRID Nu		
3. Address of Operator	L.P.			241333 10. Pool name	or Wildcat	
6301 Deauville BLVD, Mid	dland TX 79706				ΓΟΝ; GRAYBURG-S	SAN ANDRES
4. Well Location Unit Letter	. 2545 feet fro	m the NORTH	line and _10	O foots	from the WEST	line
Section 6	icci iio		nne and <u>10</u> nge <b>37E</b>	NMPM	County LE	
Section 0		•	RKB, RT, GR, etc.		county <u>L</u>	-/-
12. Check	Appropriate Box	to Indicate Na	nture of Notice	Report or Oth	er Data	
				•		
PERFORM REMEDIAL WORK	NTENTION TO  PLUG AND ABA		SUB REMEDIAL WOR		REPORT OF: ] ALTERING CA	ASING □
TEMPORARILY ABANDON	CHANGE PLAN		COMMENCE DR			
PULL OR ALTER CASING		IPL 🗌	CASING/CEMEN	T JOB 🔲		
DOWNHOLE COMMINGLE CLOSED-LOOP SYSTEM						
OTHER:			OTHER:			
13. Describe proposed or com						
of starting any proposed v proposed completion or re		9.15.7.14 NMAC	. For Multiple Co	mpletions: Attac	n wellbore diagra	т от
Move in, rig up lay-dov	vn rig.					
Remove injection equiportion equiportion equiportion equiportion in the Remove injection equiportion e	oment from well	bore and esta	ablish mechan	lical barrier a	t packer set d	lepth.
MIRU coiled tubing uni				•		
Spot 57 sacks Class C	cement from 4	800' to 4240'.				
Spot 26 sacks Class C						
Spot 27 sacks Class C If bubble test fails, plar						anding results
Proceed to spot 41 sad						
Confirm cement return				5		
4" diameter 4' tall Above	Ground Marker					
				TTACHED CC	NDITIONS	
Spud Date:		Rig Release Dat		INOVAL		
I hereby certify that the information	n above is true and c	omplete to the be	st of my knowledg	e and belief.		
,						
SIGNATURE Hayes 7.  Type or print name Hayes Thik	hibodeaux	_ <sub>TITLE</sub> Engin	eer		<sub>DATE</sub> 5/10/202	22
Type or print name Hayes Thik	odeaux	_ E-mail address:	Hayes.Thibodeaux	@chevron.com	PHONE: 281-7	26-9683
For State Use Only						
APPROVED BY:	tintale	TITLE Com	oliance Officer A	ī	DATE 5/25/22	
Conditions of Approval (if ar ):	1 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	_111LL			DATE SIZUIZZ	

# CONDITIONS OF APPROVAL FOR PLUGGING AND ABANDONMENT OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at (575)-263-6633 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

# Company representative will be on location during plugging procedures.

- **1.** A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- **2.** Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- **3.** Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- **5.** A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can +be released.
- **6.** If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- **8.** Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- **10.** All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- **13.** A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- **14.** All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
- **16.** When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- **18.** A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
- A) Fusselman
- B) Devonian
- C) Morrow
- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- I) Glorieta
- J) Yates.
- K) Potash---(In the R-111-P Area (Potash Mine Area),

A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.

**21.** If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing.

# DRY HOLE MARKER REQ.UIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and Well Number
- 3. API Number
- 4. Unit letter
- 5. Quarter Section (feet from the North, South, East or West)
- 6. Section, Township and Range
- 7. Plugging Date
- 8. County

# SPECIAL CASES ----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

## SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

# Plugging Plan – Lovington San Andres Unit #61

API: 30-025-30753

#### Note:

- Producer rods & tubing.
- TAC set at 4591'

### Proposed procedure - Lay down rig + CTU

- 1. Move in Axis 34 Lay Down rig package
- 2. N/U BOPE and pressure test same to 250 psi low for 5 minutes / 2500 psi high for 10 minutes.
- 3. Gauge ring run will be required unless the TAC is removed from the wellbore
- 4. RIH with CIBP and set at proposed depth in C-103
- 5. Pressure test mech. barrier + casing to 500 psi for 15 minutes. Document results in WellView.
- 6. Conduct bubble tests on all annuli. If bubble test fails, communicate to coiled tubing WSR for planning purposes. Cement is calculated to surface in all strings, so a CBL should be scheduled offline to gather cement top behind 5-1/2" to allow for forward planning.
- 7. Rig down Axis 34 lay down rig


# **Proposed procedure - Coiled Tubing Unit**

- 8. R/U coiled tubing P&A package
- 9. N/U BOPE and pressure test same to 250 psi low for 5 minutes / 2500 psi high for 10 minutes.
- 10. RIH with coiled tubing to tag existing mechanical barrier in wellbore
- 11. Spot 57 sacks Class C cement from 4800' to 4240'.
- 12. Spot 26 sacks Class C cement from 3891' to 3641'.
- 13. Spot 27 sacks Class C cement from 2058' to 1800'.
- 14. Conduct bubble test on 5-1/2" x 8-5/8", 8-5/8" x 13-3/8"
  - a. If bubble test fails, plan to run CBL to confirm TOC and identify depth to perforate OR cut/pull casing if was not previously run.
  - b. Cut casing will require a stub plug 50' inside of cut casing extending 50' above the cut portion at a minimum. WOC, tag, pressure test barrier. Proceed with approved C-103 if passing bubble test is achieved.
- 15. Ensure passing bubble test in all annuli prior to proceeding to final cement plug
- 16. Spot 41 sacks Class C cement from 400' to 0'.
- 17. Confirm cement returns at surface
- 18. Rig down move off location

# **Wellbore Diagram**

Created: 04/24/19 Ву: Updated: By: Lease: Lovington San Andres Unit Field: Lovington Surf. Loc.: 2545 FNL & 100 FWL Bot. Loc.: County: Lea St.: NM Status:


Well #: 61 St. Lse: API 30-025-3075<del>3</del> Unit Ltr.: Ε Section: 6 TSHP/Rng: 17S-37E Section: Unit Ltr.: TSHP/Rng: Directions: Lovington, NM Chevno: IZ1883



# **Proposed Wellbore Diagram**

Created:	04/24/19	By:		
Updated:		By:		_
Lease:	Loving	ton San Andre	s Unit	_
Field:		Lovington		_
Surf. Loc.:	2545 FNL & 100 FWL			_
Bot. Loc.:				
County:	Lea	St.:	NM	_
Status:				_

Well #:	61	St. Lse:	
API		30-025-30753	
Unit Ltr.:	E	Section:	6
TSHP/Rng:		17S-37E	
Unit Ltr.:		Section:	
TSHP/Rng:			
Directions:		Lovington, NM	
Chevno:		IZ1883	



District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

COMMENTS

Action 105783

#### **COMMENTS**

Operator:	OGRID:
CHEVRON U S A INC	4323
6301 Deauville Blvd	Action Number:
Midland, TX 79706	105783
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

#### COMMENTS

Created	ed By	Comment	Comment Date
plma	artinez	DATA ENTRY PM	5/26/2022

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

CONDITIONS

Action 105783

# **CONDITIONS**

Operator:	OGRID:
CHEVRON U S A INC	4323
6301 Deauville Blvd	Action Number:
Midland, TX 79706	105783
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

#### CONDITIONS

Created By		Condition Date
kfortner	See attached COA	5/25/2022