

	State of	New Me	exico		Form	- 100
Office District I – (575) 393-6161	Energy, Minerals	s and Natu	ural Resources		Revised July 1	8, 2013
1625 N. French Dr., Hobbs, NM 88240				WELL API NO.		
District II – (575) 748-1283 811 S. First St., Artesia, NM 88210 OIL CONSERVATION DIVISION				30-015-33482	CY	
District III – (505) 334-6178 1220 South St. Francis Dr.			5. Indicate Type of STATE			
1000 Rio Brazos Rd., Aztec, NM 87410	Λ	e, NM 8		6. State Oil & Gas		
<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM		0, 11111 0	7505	0. State Off & Gas	s Lease No.	
87505						
SUNDRY NO		Unit Agreement N	lame			
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH				PARKWAY WES	T UNIT	
PROPOSALS.)	TEICATION FOR FERMIT (FO	(WI C-101) IN	OK SOCII	8. Well Number		
1. Type of Well: Oil Well	Gas Well 🛛 Other			21		
2. Name of Operator				9. OGRID Number	er	
Devon Energy Production Company, LP				6137		
3. Address of Operator	. 2. 20. 20.1			10. Pool name or		~
333 W. Sheridan Avenue, Oklal	homa City, OK 73102			PARKWAY; MO	RROW WEST GA	S
4. Well Location						
Unit Letter_O_:960	feet from theSouth	_ line and	1780fee	et from theEast_	line	
Section 22	Township	19S	Range 29E	NMPM	Eddy County, NN	1
<b>原料的运动的</b>	11. Elevation (Show w	hether DR				VA COM
	3280' GR					
12. Chec	k Appropriate Box to In	ndicate N	lature of Notice	Report or Other	Data	
				report or ourse.		
NOTICE OF	INTENTION TO:		SUB	SEQUENT REF	PORT OF:	
PERFORM REMEDIAL WORK	☐ PLUG AND ABANDON	V 🛛	REMEDIAL WOR	K 🗆	ALTERING CASIN	IG 🗌
TEMPORARILY ABANDON	☐ CHANGE PLANS		COMMENCE DRI	LLING OPNS.□	P AND A	
PULL OR ALTER CASING	☐ MULTIPLE COMPL		CASING/CEMENT	г ЈОВ 🔲		
	<del></del>		I.			
DOWNHOLE COMMINGLE				Notify OCD 24 hrs.	prior to any work	
CLOSED-LOOP SYSTEM				Notify OCD 24 hrs.   done	prior to any work	
CLOSED-LOOP SYSTEM OTHER:			OTHER:	done		
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co	mpleted operations. (Clearl		pertinent details, and	done d give pertinent date	s, including estima	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed	mpleted operations. (Clearl work). SEE RULE 19.15.7		pertinent details, and	done d give pertinent date	s, including estima	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co	mpleted operations. (Clearl work). SEE RULE 19.15.7		pertinent details, and	done d give pertinent date npletions: Attach w	s, including estima ellbore diagram of	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.	7.14 NMAC	pertinent details, and C. For Multiple Cor	done d give pertinent date	s, including estima ellbore diagram of	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.	7.14 NMAC	pertinent details, and C. For Multiple Cor	done digive pertinent date npletions: Attach w R-111-P Ar	s, including estima rellbore diagram of	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot	7.14 NMAC	pertinent details, and C. For Multiple Cor	done digive pertinent date npletions: Attach w R-111-P Ar	s, including estima rellbore diagram of	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot	7.14 NMAC tubing string 120 sx Cl H	g from 11,150'. from 11145'-10185'.	done digive pertinent date npletions: Attach w R-111-P Ar	s, including estima rellbore diagram of	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot WOC & Tag	7.14 NMAC tubing string 120 sx Cl H	g from 11,150'. from 11145'-10185'.	done digive pertinent date npletions: Attach w R-111-P Ar	s, including estima rellbore diagram of	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 5250-5	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (66') WOC & Tag 0-8900'. WOC & tag. (T. Wolfco 0-7350'. WOC & tag. (T. Bone Spot 5000'. WOC & tag. (T. Bone Spot 5000'. WOC & tag. (T. Bone Spot 5000'.)	7.14 NMAC tubing string 120 sx Cl H amp @ 9050 07493) ring @ 5190	pertinent details, and C. For Multiple Corg from 11,150'. from 11145'-10185'. (	done digive pertinent date npletions: Attach w R-111-P Ar	s, including estima rellbore diagram of	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 5250-5 6. Spot 35 sx CI C from 3540-3	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion. of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot 66') WOC & Tag 0-8900'. WOC & tag. (T. Wolfco 0-7350'. WOC & tag. (T. Bone Sp. 3190'. WOC & tag. (T. Delawar	7.14 NMAC tubing string 120 sx Cl H nmp @ 9050 17493) ring @ 5190 re @ 3490; S	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (c)')	done d give pertinent date mpletions: Attach w  R-111-P Ar  Perfs @ 11,234'; T. Ma	s, including estima ellbore diagram of ea orrow @ 11,155'; T. A	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 5250-5 6. Spot 35 sx CI C from 3540-5 7. Perf @ 1740'. Sqz 585 sx CI	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (56') WOC & Tag (DV Tool @ 5.000'. WOC & tag. (T. Wolfco 5.000'. WOC & tag. (T. Bone Sp. 3190'. WOC & tag. (T. Delawar I C in/out from 1740' to surface	7.14 NMAC tubing string 120 sx Cl H nmp @ 9050 17493) ring @ 5190 re @ 3490; S	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (c)')	done d give pertinent date mpletions: Attach w  R-111-P Ar  Perfs @ 11,234'; T. Ma	s, including estima ellbore diagram of ea orrow @ 11,155'; T. A	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 5250-5 6. Spot 35 sx CI C from 3540-3	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (56') WOC & Tag (DV Tool @ 5.000'. WOC & tag. (T. Wolfco 5.000'. WOC & tag. (T. Bone Sp. 3190'. WOC & tag. (T. Delawar I C in/out from 1740' to surface	7.14 NMAC tubing string 120 sx Cl H nmp @ 9050 17493) ring @ 5190 re @ 3490; S	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (c)')	done d give pertinent date mpletions: Attach w  R-111-P Ar  Perfs @ 11,234'; T. Ma	s, including estima ellbore diagram of ea orrow @ 11,155'; T. A	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 5250-5 6. Spot 35 sx CI C from 3540-5 7. Perf @ 1740'. Sqz 585 sx CI	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (56') WOC & Tag (DV Tool @ 5.000'. WOC & tag. (T. Wolfco 5.000'. WOC & tag. (T. Bone Sp. 3190'. WOC & tag. (T. Delawar I C in/out from 1740' to surface	7.14 NMAC tubing string 120 sx Cl H nmp @ 9050 17493) ring @ 5190 re @ 3490; S	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (c)')	done d give pertinent date mpletions: Attach w  R-111-P Ar  Perfs @ 11,234'; T. Ma	s, including estima ellbore diagram of ea orrow @ 11,155'; T. A	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 3540-5 6. Spot 35 sx CI C from 3540-5 7. Perf @ 1740'. Sqz 585 sx CI 8. Cut wellhead off 3' BGL, set	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (56') WOC & Tag (DV Tool @ 5.000'. WOC & tag. (T. Wolfco 5.000'. WOC & tag. (T. Bone Sp. 3190'. WOC & tag. (T. Delawar I C in/out from 1740' to surface	7.14 NMAC tubing string 120 sx Cl H nmp @ 9050 17493) ring @ 5190 re @ 3490; S	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (c)')	done d give pertinent date mpletions: Attach w  R-111-P Ar  Perfs @ 11,234'; T. Ma	s, including estima ellbore diagram of ea orrow @ 11,155'; T. A	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 3540-5 6. Spot 35 sx CI C from 3540-5 7. Perf @ 1740'. Sqz 585 sx CI 8. Cut wellhead off 3' BGL, set	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (56') WOC & Tag (DV Tool @ 5.000'. WOC & tag. (T. Wolfco 5.000'. WOC & tag. (T. Bone Sp. 3190'. WOC & tag. (T. Delawar I C in/out from 1740' to surface	7.14 NMAC tubing string 120 sx Cl H nmp @ 9050 17493) ring @ 5190 re @ 3490; S	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (c)')	done d give pertinent date mpletions: Attach w  R-111-P Ar  Perfs @ 11,234'; T. Ma	s, including estima ellbore diagram of ea orrow @ 11,155'; T. A	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 5250-5 6. Spot 35 sx CI C from 3540-3 7. Perf @ 1740'. Sqz 585 sx CI 8. Cut wellhead off 3' BGL, set	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (56') WOC & Tag (DV Tool @ 5000'. WOC & tag. (T. Bone Sp. 3190'. WOC & tag. (T. Delawar Cin/out from 1740' to surface t dry hole marker.	7.14 NMAC tubing string 120 sx Cl H nmp @ 9050 17493) ring @ 5190 re @ 3490; S	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (1)') Shoe @ 3240') @ 1690'; B. Salt @ 125	done d give pertinent date mpletions: Attach w  R-111-P Ar  Perfs @ 11,234'; T. Ma	s, including estima ellbore diagram of ea orrow @ 11,155'; T. A	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 3540-3 7. Perf @ 1740'. Sqz 585 sx CI 8. Cut wellhead off 3' BGL, set  Spud Date:  ****SEE ATTACHE	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (66') WOC & Tag (DV Tool @ 5000'. WOC & tag. (T. Bone Spot (T. Bo	tubing string 120 sx Cl H 170 sx Cl H 17493) 17493) 1769 @ 5190 1969 @ 3490; S	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (c)') Shoe @ 3240') @ 1690'; B. Salt @ 125	done digive pertinent date mpletions: Attach w R-111-P Ar Perfs @ 11,234'; T. Ma  11'; T. Salt @ 336'; Shooties	s, including estima ellbore diagram of ea orrow @ 11,155'; T. A	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 3540-3 7. Perf @ 1740'. Sqz 585 sx CI 8. Cut wellhead off 3' BGL, set  Spud Date:  ****SEE ATTACHE	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (66') WOC & Tag (DV Tool @ 5000'. WOC & tag. (T. Bone Spot (T. Bo	tubing string 120 sx Cl H 170 sx Cl H 17493) 17493) 1769 @ 5190 1969 @ 3490; S	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (c)') Shoe @ 3240') @ 1690'; B. Salt @ 125	done digive pertinent date mpletions: Attach w R-111-P Ar Perfs @ 11,234'; T. Ma  11'; T. Salt @ 336'; Shooties	s, including estima ellbore diagram of ea orrow @ 11,155'; T. A	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 5250-5 6. Spot 35 sx CI C from 3540-3 7. Perf @ 1740'. Sqz 585 sx CI 8. Cut wellhead off 3' BGL, set	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (66') WOC & Tag (DV Tool @ 5000'. WOC & tag. (T. Bone Spot (T. Bo	tubing string 120 sx Cl H 170 sx Cl H 17493) 17493) 1769 @ 5190 1969 @ 3490; S	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (c)') Shoe @ 3240') @ 1690'; B. Salt @ 125	done digive pertinent date mpletions: Attach w R-111-P Ar Perfs @ 11,234'; T. Ma  11'; T. Salt @ 336'; Shooties	s, including estima ellbore diagram of ea orrow @ 11,155'; T. A	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or coof starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of the starting of the starting of the starting out of the starting of the starting out of the	impleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (6') WOC & Tag (D-8900'. WOC & tag. (T. Wolfco (D-7350'. WOC & tag. (T. Bone Sp. (3190'. WOC & tag. (T. Delawar (Cin/out from 1740' to surface t dry hole marker.	tubing string 120 sx Cl H amp @ 9050 07493) ring @ 5190 re @ 3490; Se. (DV Tool @	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (c)') Shoe @ 3240') @ 1690'; B. Salt @ 125  Must be plugest of my knowledge	done digive pertinent date mpletions: Attach w  R-111-P Ar Perfs @ 11,234'; T. Ma  11'; T. Salt @ 336'; Show  12'; T. Salt @ 336'; Show  12'; T. Salt @ 336'; Show  13'; T. Salt @ 336'; Show  14'; T. Salt @ 336'; Show  15'; T. Salt @ 35'; Show  15	s, including estima ellbore diagram of ea orrow @ 11,155'; T. A	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 3540-3 7. Perf @ 1740'. Sqz 585 sx CI 8. Cut wellhead off 3' BGL, set  Spud Date:  ****SEE ATTACHE	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (66') WOC & Tag (DV Tool @ 5000'. WOC & tag. (T. Bone Spot (T. Bo	tubing string 120 sx Cl H amp @ 9050 07493) ring @ 5190 re @ 3490; Se. (DV Tool @	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (c)') Shoe @ 3240') @ 1690'; B. Salt @ 125	done digive pertinent date mpletions: Attach w R-111-P Ar Perfs @ 11,234'; T. Ma  11'; T. Salt @ 336'; Shooties	s, including estima ellbore diagram of ea orrow @ 11,155'; T. A	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 5250-5 6. Spot 35 sx CI C from 3540-3 7. Perf @ 1740'. Sqz 585 sx CI 8. Cut wellhead off 3' BGL, set  Spud Date:  ****SEE ATTACHE I hereby certify that the information SIGNATURE	impleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (6') WOC & Tag (D-8900'. WOC & tag. (T. Wolfco (D-7350'. WOC & tag. (T. Bone Sp. (3190'. WOC & tag. (T. Delawar (Cin/out from 1740' to surface t dry hole marker.	tubing string 120 sx Cl H 1mp @ 9050 17493) ring @ 5190 re @ 3490; Se. (DV Tool @	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (1)')  Shoe @ 3240') @ 1690'; B. Salt @ 125  Must be plugest of my knowledged duction Engineer	done digive pertinent date mpletions: Attach w R-111-P Ar Perfs @ 11,234'; T. Ma T'; T. Salt @ 336'; Shoot ged by 6/28/2023 e and belief.  DATE	s, including estima rellbore diagram of ea  orrow @ 11,155'; T. A  e @ 1300') R-111P	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 5250-5 6. Spot 35 sx CI C from 3540-3 7. Perf @ 1740'. Sqz 585 sx CI 8. Cut wellhead off 3' BGL, set  Spud Date:  ****SEE ATTACHE I hereby certify that the information SIGNATURE	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (6') WOC & Tag (D. WOC & tag. (T. Wolfco (D. 7350'). WOC & tag. (T. Bone Sp. (3190'). WOC & tag. (T. Delawar (C) to Tool (D. WOC (D) (T) (T) (T) (T) (T) (T) (T) (T) (T) (T	tubing string 120 sx Cl H 1mp @ 9050 17493) ring @ 5190 re @ 3490; Se. (DV Tool @	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (1)')  Shoe @ 3240') @ 1690'; B. Salt @ 125  Must be plugest of my knowledged duction Engineer	done digive pertinent date mpletions: Attach w R-111-P Ar Perfs @ 11,234'; T. Ma T'; T. Salt @ 336'; Shoot ged by 6/28/2023 e and belief.  DATE	s, including estima rellbore diagram of ea  orrow @ 11,155'; T. A  e @ 1300') R-111P	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 5250-5 6. Spot 35 sx CI C from 3540-3 7. Perf @ 1740'. Sqz 585 sx CI 8. Cut wellhead off 3' BGL, set  Spud Date:  ****SEE ATTACHE I hereby certify that the information SIGNATURE  Type or print name Bryson W For State Use Only	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot 56') WOC & Tag 0-8900'. WOC & tag. (T. Wolfco 5000'. WOC & tag. (T. Bone Sp. 3190'. WOC & tag. (T. Delawar Cin/out from 1740' to surface t dry hole marker.	tubing string 120 sx Cl H 120	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (17)  Shoe @ 3240') @ 1690'; B. Salt @ 125  Must be plugest of my knowledged duction Engineer  e@dvn.com PHC	done digive pertinent date impletions: Attach with R-111-P Art R-1	s, including estima rellbore diagram of ea  orrow @ 11,155'; T. A  e @ 1300') R-111P	
CLOSED-LOOP SYSTEM OTHER:  13. Describe proposed or co of starting any proposed proposed completion or  1. MIRU P&A Unit. Sting out of 2. Set CIBP @ 11,145'. Tag. Ci 10,595'; T. Strawn @ 10,26 3. Pump 25 sx CI H from 9100 4. Pump 25 sx CI H from 7550 5. Spot 25 sx CI C from 5250-5 6. Spot 35 sx CI C from 3540-3 7. Perf @ 1740'. Sqz 585 sx CI 8. Cut wellhead off 3' BGL, set  Spud Date:  ****SEE ATTACHE I hereby certify that the information  SIGNATURE  Type or print name Bryson W	mpleted operations. (Clearl work). SEE RULE 19.15.7 recompletion.  of On/Off tool and TOOH with a firc 10# salt gel. Leak test. Spot (6') WOC & Tag (D. WOC & tag. (T. Wolfco (D. 7350'). WOC & tag. (T. Bone Sp. (3190'). WOC & tag. (T. Delawar (C) to Tool (D. WOC (D) (T) (T) (T) (T) (T) (T) (T) (T) (T) (T	tubing string 120 sx Cl H 120	pertinent details, and C. For Multiple Cor g from 11,150'. from 11145'-10185'. (1)')  Shoe @ 3240') @ 1690'; B. Salt @ 125  Must be plugest of my knowledged duction Engineer	done digive pertinent date impletions: Attach with R-111-P Art R-1	s, including estima rellbore diagram of ea  orrow @ 11,155'; T. A  e @ 1300') R-111P	





# CONDITIONS FOR PLUGGING AND ABANDONMENT

#### OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- A notice of intent to plug and abandon a wellbore is required to be approved before plugging
  operations are conducted. A cement evaluation tool is required in order to ensure isolation of
  producing formations, protection of water and correlative rights. A cement bond log or other
  accepted cement evaluation tool is to be provided to the division for evaluation if one has not
  been previously run or if the well did not have cement circulated to surface during the original
  casing cementing job or subsequent cementing jobs. Insure all bradenheads have been
  exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E)Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - I) Glorieta
  - J) Yates.
  - K)Potash---(In the R-111-P Area (Page 3 & 4), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

## **DRY HOLE MARKER REQUIRMENTS**

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

# R-111-P Area

#### T 18S - R 30E

Sec 10 Unit P. Sec 11 Unit M,N. Sec 13 Unit L,M,N. Sec 14 Unit C -P. Sec 15 Unit A G,H,I,J,K,N,O,P. Sec 22 Unit All except for M. Sec 23, Sec 24 Unit C,D,E,L, Sec 26 Unit A-G, Sec 27 Unit A,B,C

## T 19S - R 29E

Sec 11 Unit P. Sec 12 Unit H-P. Sec 13. Sec 14 Unit A,B,F-P. Sec 15 Unit P. Sec 22 Unit A,B,C,F,G,H,I,J K,N,O,P. Sec 23. Sec 24. Sec 25 Unit D. Sec 26 Unit A-F. Sec 27 Unit A,B,C,F,G,H.

#### T 19S - R 30E

Sec 2 Unit K,L,M,N. Sec 3 Unit I,L,M,N,O,P. Sec 4 Unit C,D,E,F,G,I-P. Sec 5 Unit A,B,C,E-P. Sec 6 Unit I,O,P. Sec 7 – Sec 10. Sec 11 Unit D, G—P. Sec 12 Unit A,B,E-P. Sec 13 Unit A-O. Sec 14-Sec 18. Sec 19 Unit A-L, P. Sec 20 – Sec 23. Sec 24 Unit C,D,E,F,L,M,N. Sec 25 Unit D. Sec 26 Unit A-G, I-P. Sec 27, Sec 28, Sec 29 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 32 Unit A,B,G,H,I,J,N,O,P. Sec 33. Sec 34. Sec 35. Sec 36 Unit D,E,F,I-P.

## T 19S - R 31E

Sec 7 Unit C,D,E,F,L. Sec 18 Unit C,D,E,F,G,K,L. Sec 31 Unit M. Sec 34 Unit P. Sec 35 Unit M,N,O. Sec 36 Unit O,P.

#### T 20S - R 29E

Sec 1 Unit H,I,P. Sec 13 Unit E,L,M,N. Sec 14 Unit B-P. Sec 15 Unit A,H,I,J,N,O,P. Sec 22 Unit A,B,C,F,G,H,I,J,O,P. Sec 23. Sec 24 Unit C,D,E,F,G,J-P. Sec 25 Unit A-O. Sec 26. Sec 27 Unit A,B,G,H,I,J,O,P. Sec 34 Unit A,B,G,H. Sec 35 Unit A-H. Sec 36 Unit B-G.

## T 20S - R 30E

Sec 1 – Sec 4. Sec 5 Unit A,B,C,E-P. Sec 6 Unit E,G-P. Sec 7 Unit A-H,I,J,O,P. Sec 8 – 17. Sec 18 Unit A,B,G,H,I,J,O,P. Sec 19 Unit A,B,G,H,I,J,O,P. Sec 30 Unit A-L,N,O,P. Sec 31 Unit A,B,G,H,I,P. Sec 32 – Sec 36.

# T 20S - R 31E

Sec 1 Unit A,B,C,E-P. Sec 2. Sec 3 Unit A,B,G,H,I,J,O,P. Sec 6 Unit D,E,F,J-P. Sec 7. Sec 8 Unit E-P. Sec 9 Unit E,F,J-P. Sec 10 Unit A,B,G-P. Sec 11 – Sec 36.

## T 21S - R 29E

Sec 1 – Sec 3. Sec 4 Unit L1 – L16,I,J,K,O,P. Sec 5 Unit L1. Sec 10 Unit A,B,H,P. Sec 11 – Sec 14. Sec 15 Unit A,H,I. Sec 23 Unit A,B. Sec 24 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 25 Unit A,O,P. Sec 35 Unit G,H,I,J,K,N,O,P. Sec 36 A,B,C,F – P.

## T 21S - R 30E

Sec 1 – Sec 36

# T 21S - R 31E

Sec 1 – Sec 36

# T 22S - R 28E

Sec 36 Unit A,H,I,P.

#### T 22S - R 29E

Sec 1. Sec 2. Sec 3 Unit I,J,N,O,P. Sec 9 Unit G – P. Sec 10 – Sec 16. Sec 19 Unit H,I,J. Sec 20 – Sec 28. Sec 29 Unit A,B,C,D,G,H,I,J,O,P. Sec 30 Unit A. Section 31 Unit C – P. Sec 32 – Sec 36

## T 22S - R 30E

Sec 1 – Sec 36

## T 22S - R 31E

Sec 1 – Sec 11. Sec 12 Unit B,C,D,E,F,L. Sec 13 Unit E,F,K,L,M,N. Sec 14 – Sec 23. Sec 24 Unit C,D,E,F,K,L,M,N. Sec 25 Unit A,B,C,D. Sec 26 Unit A,BC,D,G,H. Sec 27 – Sec 34.

## T 23S - R 28E

Sec 1 Unit A

## T 23S - R 29E

Sec 1 – Sec 5. Sec 6 Unit A – I, N,O,P. Sec 7 Unit A,B,C,G,H,I,P. Sec 8 Unit A – L, N,O,P. Sec 9 – Sec 16. Sec 17 Unit A,B,G,H,I,P. Sec 21 – Sec 23. Sec 24 Unit A – N. Sec 25 Unit D,E,L. Sec 26. Sec 27. Sec 28 Unit A – J, N,O,P. Sec 33 Unit A,B,C. Sec 34 Unit A,B,C,D,F,G,H. Sec 35. Sec 36 Unit B,C,D,E,F,G,K,L.

#### T 23S - R 30E

Sec 1 – Sec 18. Sec 19 Unit A – I,N,O,P. Sec 20, Sec 21. Sec 22 Unit A – N, P. Sec 23, Sec 24, Sec 25. Sec 26 Unit A,B,F-P. Sec 27 Unit C,D,E,I,N,O,P. Sec 28 Unit A – H, K,L,M,N. Sec 29 Unit A – J, O,P. Sec 30 Unit A,B. Sec 32 A,B. Sec 33 Unit C,D,H,I,O,P. Sec 34, Sec 35, Sec 36.

## T 23S - R 31E

Sec 2 Unit D,E,J,O. Sec 3 – Sec 7. Sec 8 Unit A – G, K – N. Sec 9 Unit A,B,C,D. Sec 10 Unit D,P. Sec 11 Unit G,H,I,J,M,N,O,P. Sec 12 Unit E,L,K,M,N. Sec 13 Unit C,D,E,F,G,J,K,L,M,N,O. Sec 14. Sec 15 Unit A,B,E – P. Sec 16 Unit I, K – P. Sec 17 Unit B,C,D,E, I – P. Sec 18 – Sec 23. Sec 24 Unit B – G, K,L,M,N. Sec 25 Unit B – G, J,K,L. Sec 26 – Sec 34. Sec 35 Unit C,D,E.

## T 24S – R 29E

Sec 2 Unit A, B, C, D. Sec 3 Unit A

### T 24S - R 30E

Sec 1 Unit A – H, J – N. Sec 2, Sec 3. Sec 4 Unit A,B,F – K, M,N,O,P. Sec 9 Unit A – L. Sec 10 Unit A – L, O,P. Sec 11. Sec 12 Unit D,E,L. Sec 14 Unit B – G. Sec 15 Unit A,B,G,H.

#### T 24S - R 31E

Sec 3 Unit B – G, J – O. Sec 4. Sec 5 Unit A – L, P. Sec 6 Unit A – L. Sec 9 Unit A – J, O,P. Sec 10 Unit B – G, K – N. Sec 35 Unit E – P. Sec 36 Unit E,K,L,M,N.

## T 25S - R 31E

Sec 1 Unit C,D,E,F. Sec 2 Unit A – H.

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

CONDITIONS

Action 118555

# **CONDITIONS**

Operator:	OGRID:
DEVON ENERGY PRODUCTION COMPANY, LP	6137
333 West Sheridan Ave.	Action Number:
Oklahoma City, OK 73102	118555
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

#### CONDITIONS

Created By	Condition	Condition Date
gcordero	None	6/28/2022