Conversion of the Appropriate District 29 PM	State of New Mex	xico	Form C-103
Office District I – (575) 393-6161	Energy, Minerals and Natur	al Resources	Revised July 18, 2013
1625 N. French Dr., Hobbs, NM 88240			WELL API NO.
<u>District II</u> – (575) 748-1283	OIL CONSERVATION	DIVISION	30-025-10473
811 S. First St., Artesia, NM 88210			5. Indicate Type of Lease
<u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Fran		STATE FEE S
District IV – (505) 476-3460	Santa Fe, NM 87	505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM			
87505			
	AND REPORTS ON WELLS		7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS			Langlie Mattix Penrose Sand Unit
DIFFERENT RESERVOIR. USE "APPLICATIO PROPOSALS.)	N FOR PERMIT" (FORM C-101) FO	K SUCH	8. Well Number #192
1. Type of Well: Oil Well Gas	Well Other		
2. Name of Operator			9. OGRID Number
Legacy Reserves Operating LP			240974
3. Address of Operator			10. Pool name or Wildcat
15 Smith Road, Suite 3000, Midland, T	X 79705		Langlie Mattix;7 Rvrs-Queen-Grayburg
	12 17100		Langue Mattix,7 RV13 Queen Grayburg
4. Well Location			
Unit Letter P: 6	60 feet from the S	line and	990 feet from the <u>E</u> line
Section 27	Township 22S Range	37E	NMPM County <b>Lea</b>
	Elevation (Show whether DR,		
	3091'		
12 Charle Amou	amieta Day ta Indiaeta Na	tura of Notice	Domant on Other Data
12. Check Appro	opriate Box to Indicate Na	iture of Notice,	Report or Other Data
NOTICE OF INTEN	ITION TO:	SLIB	SEQUENT REPORT OF:
	JG AND ABANDON 🛛	REMEDIAL WOR	
<del></del>	ANGE PLANS	COMMENCE DR	
PULL OR ALTER CASING MU	LTIPLE COMPL	CASING/CEMEN	T JOB
DOWNHOLE COMMINGLE			
CLOSED-LOOP SYSTEM			
OTHER:		OTHER:	П
	operations. (Clearly state all p	ertinent details, an	d give pertinent dates, including estimated dat
			mpletions: Attach wellbore diagram of
proposed completion or recomple			
rr			
1. MIRU. Load with fluid to kill we	ll. Load 7" & 8 5/8" annulus y	with mud as needed	to stop surface flow.
2. Release pkr (3507') and pull 2 3/9		Tim maa as neede	to stop surface now.
3. Set 4 1/2" CIBP @ 3500'.	tuomg.		
4. Pressure test casing.			
	unt and igalata halos Saz 100	av amt then halas	WOC & Drill out. Pressure test casing.
	unt and isolate holes. Sqz 100		edure up to casing leak then squeeze leak
Repeat if req'd.  6. Fill cellar with cmt as necessary.		ronow ra proce	edure up to casing leak then squeeze leak
	. 25	(D. )	
7. Circ. Hole w/ MLF. Tag CIBP. S			
8. Perf w/ deep perf charges & Sqz			
9. Perf w/ deep perf charges & Sqz			
		e. Note: 15 1/2 csg	not visible at surface(?) - 200 sx (of 250)
required to fill annular from 8 5/8	8- 15 1/2 to surface.		
11. Cut off well head, verify cmt at s	urface, weld on dry hole marke		
4" Diameter 4' tall above ground	marker	See attache	d Conditions of Approval
4 Diameter 4 tan anove ground	- IIIai kei		
Spud Date:	Rig Release Dat	te:	
		1 1 1	11 1' 6
I hereby certify that the information above	is true and complete to the be	st of my knowledg	e and belief.
Malaria Pa		D 1	DATE: 5/01/0000
SIGNATURE Melanie Re	yes TITLE	Regulatory Tec	hDATE7/21/2022
V		~.	
Type or print nameMelanie Rey	<u>res</u> E-mail address:	<u>mreyes@legacyr</u>	eserves.com PHONE: _(432) 221-6358
For State Use Only			
V 1.1	ī., .	0, -0	a
APPROVED BY: Kerry Forth	TITLE Co	mpliance of	ficer A _DATE_ <u>7/25/22</u>


Conditions of Approv. Released to Imaging: //25/2022 2:13:52 PM

Тор

1135

Legacy Reserves Operating			PROPOSED
Author:	C. Greene		
· ·	Langlie Mattix Penrose		
Well Name	Sand Unit	Well No.	#192
Field/Pool	LM; 7Rvrs-Qn-Grbg	API#:	30-025-10473
County	Lea	Location:	Sec 27, T22S, R37E
State	NM		660' FSL & 990' FEL
Spud Date	8/3/1938	GL:	3322'
1		-	

Description	O.D.	Grade	Weight	Depth	Hole	Cmt Sx	TOC
Surface Csg	15 1/2	-	60#	125	17	75	Circ'd
Inter Csg	8 5/8	-	24#	1,164	10	100	365 (calc)
Prod Csg	7	-	22#	3,347	8	150	1,250 (calc)
Prod Liner #1	5 1/2	-	-	3,255- 3,676	6	425(?)	Circ'd
Prod Csg	4 1/2	J55	11.6#	3,762	6	180	5'



11. Cut off well head, verify cmt at surface, weld on dry hole marker.

CSG@ 15.5 60#

10. Perf w/ deep perf charges & sqz 250 sx cmt from 200' to surface. Note: 15 1/2 csg not visible at surface(?) - 200 sx (of 250) required to fill annular from 8 5/8- 15 1/2 to surface.

8.625 24# CSG @ 1,164

9. Perf w/ deep perf charges & Sqz 50 sx cmt @ 1250'-1050'. WOC

& Tag. (T Salt & 8 5/8" shoe)

T Salt 1230 B Salt 2125 Penrose 3535

Follow PA procedure up to casing leak

32.357609

-103.145546

then squeeze leak

Formation

Anhydrite

8. Perf w/ deep perf charges & Sqz 50 sx cmt @ 2175'-1875'. WOC & Tag. (B Salt)

- 7. Circ. Hole w/ MLF. Tag CIBP. Spot 25 sx cmt @ 3500'-3200'. (Penrose)
- 6. Fill cellar with cmt as necessary.

5. Upon failure, RIH with pkr and hunt and isolate holes. Sqz 100 sx cmt thru holes.

WOC & Drill out. Pressure test casing. Repeat if req'd.

- 4. Pressure test casing.
- 3. Set 4 1/2" CIBP @ 3500'.

2. Release pkr (3507') and pull 2 3/8" tubing.

1. MIRU. Load with fluid to kill well. Load 7" & 8 5/8" annulus with mud as needed to stop surface flow.

7 22# CSG@ 3,347 Perfs @ 3540-3648

5 1/2 Liner @ 3,255-3,676 4 1/2 11.6# Liner @ 3,762

PBTD @ 3671 3676 TD@

# CONDITIONS OF APPROVAL FOR PLUGGING AND ABANDONMENT OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at (575)-263-6633 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

## Company representative will be on location during plugging procedures.

- **1.** A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- **2.** Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- **3.** Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- **5.** A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can +be released.
- **6.** If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- **8.** Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- **10.** All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- **13.** A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- **14.** All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
- **16.** When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- **18.** A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
- A) Fusselman
- B) Devonian
- C) Morrow
- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- I) Glorieta
- J) Yates.
- K) Potash---(In the R-111-P Area (Potash Mine Area),

A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.

**21.** If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing.

# DRY HOLE MARKER REQ.UIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and Well Number
- 3. API Number
- 4. Unit letter
- 5. Quarter Section (feet from the North, South, East or West)
- 6. Section, Township and Range
- 7. Plugging Date
- 8. County


## SPECIAL CASES ----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

#### SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

Legacy Res	serves Operating		CURRENT
Author:	C. Greene		
-	Langlie Mattix Penrose		
Well Name	Sand Unit	Well No.	#192
Field/Pool	LM; 7Rvrs-Qn-Grbg	API #:	30-025-10473
County	Lea	Location:	Sec 27, T22S, R37E
State	NM		660' FSL & 990' FEL
Spud Date	8/3/1938	GL:	3322'
l .			

Description	O.D.	Grade	Weight	Depth	Hole	Cmt Sx	TOC
Surface Csg	15 1/2	1	60#	125	17	75	Circ'd
Inter Csg	8 5/8	-	24#	1,164	10	100	365 (calc)
Prod Csg	7	-	22#	3,347	8	150	1,250 (calc)
Prod Liner #1	5 1/2	1	-	3,255- 3,676	6	425(?)	Circ'd
Prod Csg	4 1/2	J55	11.6#	3,762	6	180	5'



Formation	Тор
Anhydrite	1135
T Salt	1230
B Salt	2125
Penrose	3535

32.357609 -103.145546

PBTD @ 3671 TD @ 3676

Тор

32.357609

-103.145546

1135

1230

2125

3535

Legacy Reserves Operating			PROPOSED
Author:	C. Greene		
l -	Langlie Mattix Penrose		
Well Name	Sand Unit	Well No.	#192
Field/Pool	LM; 7Rvrs-Qn-Grbg	API#:	30-025-10473
County	Lea	Location:	Sec 27, T22S, R37E
State	NM		660' FSL & 990' FEL
Spud Date	8/3/1938	GL:	3322'
1			

Description	O.D.	Grade	Weight	Depth	Hole	Cmt Sx	TOC
Surface Csg	15 1/2	-	60#	125	17	75	Circ'd
Inter Csg	8 5/8	-	24#	1,164	10	100	365 (calc)
Prod Csg	7	-	22#	3,347	8	150	1,250 (calc)
Prod Liner #1	5 1/2	-	-	3,255- 3,676	6	425(?)	Circ'd
Prod Csg	4 1/2	J55	11.6#	3,762	6	180	5'


Formation

Anhydrite

T Salt

B Salt

Penrose



11. Cut off well head, verify cmt at surface, weld on dry hole marker.

15.5 60# CSG @ 125

10. Perf w/ deep perf charges & sqz 250 sx cmt from 200' to surface. Note:  $15\ 1/2\ csg$  not visible at surface(?) - 200 sx (of 250) required to fill annular from 8 5/8- 15 1/2 to surface.

8.625 24# CSG @ 1,164

9. Perf w/ deep perf charges & Sqz 50 sx cmt @ 1250'-1050'. WOC

& Tag. (T Salt & 8 5/8" shoe)

8. Perf w/ deep perf charges & Sqz 50 sx cmt @ 2175'-1875'. WOC & Tag. (B Salt)

- 7. Circ. Hole w/ MLF. Tag CIBP. Spot 25 sx cmt @ 3500'-3200'. (Penrose)
- 6. Fill cellar with cmt as necessary.
- 5. Upon failure, RIH with pkr and hunt and isolate holes. Sqz 100 sx cmt thru holes. WOC & Drill out. Pressure test casing. Repeat if req'd.
- 4. Pressure test casing.
- 3. Set 4 1/2" CIBP @ 3500'.
- 2. Release pkr (3507') and pull 2 3/8" tubing.
- 1. MIRU. Load with fluid to kill well. Load 7" & 8 5/8" annulus with mud as needed to stop surface flow.

7 22# CSG @ 3,347

Perfs @ 3540-3648

5 1/2 - Liner @ 3,255-3,676 4 1/2 11.6# Liner @ 3,762

PBTD @ 3671 TD @ 3676

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

COMMENTS

Action 127938

#### **COMMENTS**

Operator:	OGRID:
LEGACY RESERVES OPERATING, LP	240974
15 Smith Road	Action Number:
Midland, TX 79705	127938
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

#### COMMENTS

Created By	Comment	Comment Date
plmartine	z DATA ENTRY PM.	7/25/2022

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

CONDITIONS

Action 127938

## **CONDITIONS**

Operator:	OGRID:
LEGACY RESERVES OPERATING, LP	240974
15 Smith Road	Action Number:
Midland, TX 79705	127938
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

#### CONDITIONS

Created By		Condition Date
kfortner	See attached COA Note changes to procedure	7/25/2022