

Well Name: MCKITTRICK 24 FEDERAL	Well Location: T22S / R24E / SEC 13 / SWSE / 32.3859367 / -104.448761	County or Parish/State: EDDY / NM
Well Number: 1	Type of Well: OIL WELL	Allottee or Tribe Name:
Lease Number: NMNM97855	Unit or CA Name:	Unit or CA Number:
US Well Number: 3001533648	Well Status: Gas Well Shut In	Operator: OXY USA WTP LP

Accepted for record –NMOCD gc2/27/2024

Notice of Intent

Sundry ID: 2714875

Type of Submission: Notice of Intent Type of Action: Plug and Abandonment

Date Sundry Submitted: 02/09/2023 Time Sundry Submitted: 07:09

Date proposed operation will begin: 03/09/2023

Procedure Description: THE CURRENT WELLBORE, PROPOSED WELLBORE, AND PLUGGING PROCEDURE ARE ATTACHED.

Approval Subject to
General Requirements and
Special Stipulations
Attached

Surface Disturbance

Is any additional surface disturbance proposed?: No

NOI Attachments

Procedure Description

MCKITTRICK_24_FED_1_PA_NOI_SUB_PACKET_2.9.23_20230209070854.pdf

Received by OCD: 2/15/2024 11:59:04 AM

Page 2 of 15

Well Name: MCKITTICK 24 FEDERAL	Well Location: T22S / R24E / SEC 13 / SWSE / 32.3859367 / -104.448761	County or Parish/State: EDDY / NM
Well Number: 1	Type of Well: OIL WELL	Allottee or Tribe Name:
Lease Number: NMNM97855	Unit or CA Name:	Unit or CA Number:
US Well Number: 3001533648	Well Status: Gas Well Shut In	Operator: OXY USA WTP LP

Operator

I certify that the foregoing is true and correct. Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction. Electronic submission of Sundry Notices through this system satisfies regulations requiring a

Operator Electronic Signature: STEPHEN JANACEK

Signed on: FEB 09, 2023 07:09 AM

Name: OXY USA WTP LP

Title: Regulatory Engineer

Street Address: 5 Greenway Plaza, Suite 110

City: HoustonState: TX

Phone: (713) 497-2417

Email address: stephen_janacek@oxy.com

Field

Representative Name:

Street Address:

City:State:Zip:

Phone:

Email address:

Spud date: 11/27/2004

Completion Date: 1/20/2005

Last ESP Installation Date: 9/24/2011

OXY USA WTP
McKittrick 24 Federal #1
30-015-33648
CURRENT WELLBORE 2/9/23

6/16/11: Found hole 4042'-4073'

6/20/11: Ran CBL. Good cement from 7,980' to 7,850.


Rest was spread or no cement to surface. Csg inspection log found bad casing from 4410' to 3900'

6/24/11: Cement squeeze

6/28/11: Test casing to 500 psi

6/30/11: Acidize formation with 8,000 glns with 17.5%HCL with Fercheck dropping 200 bio-balls. Maximum pressure 60 psi at 5 bpm

Ran two SS 3/8" CT lines. One to the top of the shroud and other to the top of the pump



09/22/2011: FILL at 8,382' bail out to 8,453'

Spud date: 11/27/2004

Completion Date: 1/20/2005

Last ESP Installation Date: 9/24/2011

PERF AND CIRCULATE 155 SX CMT
500'-SURFACE. VERIFY CMT TO
SURFACE.

PERF AND SQZ 95 SX CMT 1847'-
1550'. WOC AND TAG.

6/16/11: Found hole 4042'-4073'

6/20/11: Ran CBL. Good cement from 7,980' to 7,850.
Rest was spread or no cement to surface. Csg inspection
log found bad casing from 4410' to 3900'

6/24/11: Cement squeeze

6/28/11: Test casing to 500 psi

6/30/11: Acidize formation with 8,000 glns with 17.5%HCL
with Fercheck dropping 200 bio-balls. Maximum pressure
60 psi at 5 bpm


PERF AND SQZ 35 SX CMT 3082'-
2982'.

PERF AND SQZ 35 SX CMT 5000'-
4900' (SPACER PLUG).

SPOT 25 SX CMT 7744'-7608'. WOC
AND TAG.

SET CIBP AT 8254'. LEAK TEST CIBP.
DUMP BAIL 35 FT CMT. WOC AND
TAG.

09/22/2011: FILL at 8,382' bail out to 8,453'



OXY USA WTP
McKittrick 24 Federal #1
30-015-33648
PROPOSED WELLBORE 2/9/23

9-5/8", 36#, J-55 @ 1600'
w/1830sx-TOC-Surf-Circ

Approval Subject to
General Requirements and
Special Stipulations
Attached

Upper Penn Perforations
8304'-8339' (35') ; 4 spf

7", 23-26#, N-80 & J-55 at 8584'
w/450sx-TOC-6200' by Temp Survey
TD 8584' (MD)/8326' (TVD)

MCKITTRICK 24 FEDERAL #001

30-015-33648

PROPOSED PLUGGING PLAN

PROCEDURE

1. SET CIBP AT 8254'. LEAK TEST CIBP. DUMP BAIL 35 FT CMT. WOC AND TAG.
2. SPOT 38 SX CMT 8044' to 7864'. WOC AND TAG. (Wolfcamp)
3. PERF AND attempt SQZ 46 SX CMT 5955' to 5795' (Bone Spring). (In 27 sxs/
Out 19 sxs)
 - a. If no injection move up to 5795' and perforate.
 - b. Test for communication between perforations at 5955' and 5795'.
 - c. Establish injection and squeeze between perforations behind casing. (In/Out)
 - d. If no injection rate spot cement inside casing instead. WOC and Tag.
4. Spot 100 SX CMT from 4410' to 3811'. WOC and Tag. (Bad Casing)
5. PERF AND SQZ 739 SX CMT 2550' to surface. Verify at surface. (In 427 sxs/
Out 312 sxs) (Fresh water/Karst, Shoe, Surface Plug)

FORMATION TOPS

37. SUMMARY OF POROUS ZONES: (Show all important zones of porosity and content thereof; cored intervals; and all drill-stem tests, including depth interval tested, cushion used, time tool open, flowing shut-in pressures, and recoveries):			
FORMATION	TOP	BOTTOM	DESCRIPTION, CONTENTS, ETC.
Delaware Mtn Group	1526	3032	Sand, Shale, Limestone
Bone Spring	3032	-	Limestone, Sand, Shale
3rd Bone Spring Sand	7587	7694	Sand
Wolfcamp	7694	8036	Shale, Limestone
Cisco/Canyon	8036	TD	Dolomite

**BUREAU OF LAND MANAGEMENT
Carlsbad Field Office
620 East Greene Street
Carlsbad, New Mexico 88220
575-234-5972**

**Permanent Abandonment of Federal Wells
Conditions of Approval**

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within **ninety (90)** days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

2. **Notification:** Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-689-5981.

3. **Blowout Preventers:** A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.

4. **Mud Requirement:** Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of brine water. Minimum nine (9) pounds per gallon.

5. **Cement Requirement:** Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. **Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.**

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. Dry Hole Marker: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). **The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10th day, the BLM is to be contacted with justification to receive an extension for completing the cut off.**

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds). A weep hole shall be left if a metal plate is welded in place.

7. Subsequent Plugging Reporting: Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**

8. Trash: All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation objectives.



United States Department of the Interior

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office
620 E. Greene St.
Carlsbad, New Mexico 88220-6292
www.blm.gov/nm



In Reply Refer To: 1310

Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo “interim” reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo “final” reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its pre-disturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any/all contaminants, scrap/trash, equipment, pipelines and powerlines **(Contact service companies, allowing plenty of time to have the risers and power lines and poles removed prior to reclamation, don't wait till the last day and try to get them to remove infrastructure)**. Strip and remove caliche, contour the location to blend with the surrounding landscape, re-distribute the native soils, provide erosion control as needed, rip (across the slope and seed as specified in the original APD COA. **This will apply to well pads, facilities, and access roads.** Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

1. The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands. Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD process as per Onshore Oil and Gas Order No. 1.
2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.
3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you

- have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.
5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
 6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
 7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Jim Amos
Supervisory Petroleum Engineering Tech/Environmental Protection Specialist
575-234-5909 (Office), 575-361-2648 (Cell)

Arthur Arias
Environmental Protection Specialist
575-234-6230

Crisha Morgan
Environmental Protection Specialist
575-234-5987

Jose Martinez-Colon
Environmental Protection Specialist
575-234-5951

Mark Mattozzi
Environmental Protection Specialist
575-234-5713

Robert Duenas
Environmental Protection Specialist
575-234-2229

Trishia Bad Bear, Hobbs Field Station
Natural Resource Specialist
575-393-3612

Sundry ID

2714875

Plug Type	Top	Bottom	Length	Tag	Sacks	Cement Class	Notes
Surface Plug	0.00	100.00	100.00	Tag/Verify			
Shoe Plug	1534.00	1650.00	116.00	Tag/Verify			
				If solid base no need to Tag (CIBP present and/or Mechanical Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforations			Perf and squeeze from 2550' to surface. (In 427 sxs/Out 312 sxs) Verify at surface.
Fresh Water @ 2500	2425.00	2550.00	125.00	ns	739.00	C	
Bad Casing @ 3900	3811.00	3950.00	139.00	If solid			
				If solid base no need to Tag (CIBP present and/or Mechanical Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforations			Spot cement from 4410' to 3811'. WOC and Tag
Bad Casing @ 4410	4315.90	4460.00	144.10	ns	100.00	C	

				If solid base no need to Tag (CIBP present and/or Mechanical Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforations			Perf and attempt Squeeze from 5955' to 5795'. WOC and Tag. (In 27 sxs/Out 19 sxs), Otherwise move up up to 5795' and perf. Test for communication between the perforations. Establish injection and squeeze between perforations. If no injection rate spot cement inside casing instead. WOC and Tag.
Bonesprings @ 5905	5795.95	5955.00	159.05	ns	46.00	C	
				If solid base no need to Tag (CIBP present and/or Mechanical Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforations			
Wolfcamp @ 7994	7864.06	8044.00	179.94	ns	38.00	H	Spot cement from 8044' to 7864'.
Perforations Plug (If No CIBP)	8205.61	8389.00	183.39	Tag/Verify			
				If solid base no need to Tag (CIBP present and/or Mechanical Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforations			
CIBP Plug	8219.00	8254.00	35.00	ns	8.00	H	Set CIBP at 8254'. Dump bail 35'. Leak Test CIBP. WOC and Tag.

Shoe Plug	8448.16	8634.00	185.84	Tag/Verify			
-----------	---------	---------	--------	------------	--	--	--

No more than 2000' is to be allowed between plugs in open hole, and no more than 3000' between plugs in cased hole.

Class H >7500'

Class C <7500'

Fluid used to mix the cement in R111P shall be saturated with the salts common to the section penetrated, and in suitable proportions, but not more than 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible.

Medium, Secretary: Top of salt to surface If no salt take the deepest fresh water or Karst Depth

High, Critical: Bottom of Karst to surface or Deepest fresh water, whichever is greater

R111P: 50 Feet from Base of Salt to surface.

Class C: 1.32 ft³/sx

Class H: 1.06 ft³/sx

Onshore Order 2.III.G Drilling Abandonment Requirements: "All formations bearing usable-quality water, oil, gas, or geothermal resources, and/or a prospectively valuable deposit of minerals shall be protected.

Cave Karst/Potash Cement		Critical		Bottom of Karst/take deepest fresh water/top of salt whichever is greater to surface	
Shoe @		1600.00			
Shoe @		8584.00	TOC @		7850.00
Perforatons Top @		8304.00	Perforations		8339.00
			CIBP @		8254.00

District I
1625 N. French Dr., Hobbs, NM 88240
Phone:(575) 393-6161 Fax:(575) 393-0720
District II
811 S. First St., Artesia, NM 88210
Phone:(575) 748-1283 Fax:(575) 748-9720
District III
1000 Rio Brazos Rd., Aztec, NM 87410
Phone:(505) 334-6178 Fax:(505) 334-6170
District IV
1220 S. St Francis Dr., Santa Fe, NM 87505
Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

CONDITIONS

Action 314772

CONDITIONS

Operator: OXY USA WTP LIMITED PARTNERSHIP P.O. Box 4294 Houston, TX 772104294	OGRID: 192463
	Action Number: 314772
	Action Type: [C-103] NOI Plug & Abandon (C-103F)

CONDITIONS

Created By	Condition	Condition Date
gcordero	After setting CIBP you must run a CBL to surface.	2/27/2024