Received by OCD in 7/1/2025 2:14:56 PM

Phone: (505) 476-3441 General Information Phone: (505) 629-6116 State of New Mexico Energy, Minerals and Natural Resources Form C-103 of 4
Revised July 18, 2013

WELL API NO.

Online Phone Directory Visit: https://www.emnrd.nm.gov/ocd/contact-us/  SUNDRY NOTICE (DO NOT USE THIS FORM FOR PROPOSAL DIFFERENT RESERVOIR. USE "APPLICAT PROPOSALS.)  1. Type of Well: Oil Well  Ga  2. Name of Operator  3. Address of Operator  4. Well Location Unit Letter :	5. Indicate Type of Lease STATE FEE  6. State Oil & Gas Lease No.  7. Lease Name or Unit Agreement Name  8. Well Number  9. OGRID Number  10. Pool name or Wildcat			
Section	feet from the Township F	Range	NMPM	County
	11. Elevation (Show whether D			
NOTICE OF INTE PERFORM REMEDIAL WORK  P TEMPORARILY ABANDON  O PULL OR ALTER CASING  M DOWNHOLE COMMINGLE	oropriate Box to Indicate I ENTION TO: PLUG AND ABANDON  CHANGE PLANS  MULTIPLE COMPL	SUE REMEDIAL WOF	SSEQUENT RE	
CLOSED-LOOP SYSTEM  OTHER:		OTHER:		
13. Describe proposed or complete of starting any proposed work) proposed completion or recomp	. SEE RULE 19.15.7.14 NMA pletion.	C. For Multiple Co		
Spud Date:	Rig Release I	Date:		
I hereby certify that the information abo	ove is true and complete to the	best of my knowledg	ge and belief.	
SIGNATURE Alicia Fult	onTITLE		D.	ATE
Type or print name  For State Use Only	E-mail addre	ss:	PI	HONE:
APPROVED BY:  Conditions of Approval (if any):	TITLE		DA	ATE



Post Office Box 61229 Houston, TX 77208-1229

1111 Travis St Houston, TX 77002

Phone: 713/209-2400

### PROPOSED PROCEDURE TO REPAIR

NORTHEAST DRINKARD UNIT #605 (30-025-06613)

- 1. MIRU
- 2. NM WELLHEAD. NU BOPD. TEST BOP.
- PULL TUBING OUT OF THE HOLE WHILE SCANNING. ENSURE THAT THE SCANNER IS CALIBRATED FOR LINED TUBING. LAY DOWN ALL RED BAND AND GREEN BAND JOINTS.
- 4. PICK AND RUN IN THE HOLE WITH PACKER AND RBP. SET RBP AT LEAST 500' ABOVE TOP PERFS. SET PACKER. LOAD AND TEST CASING TO 550 PSI.
- PULL OUT OF THE HOLE WITH TOOLS AND RUN BACK IN THE HOLE WITH A BIT AND BAILER. CLEAN OUT THE WELLBORE TO THE PBTD. PULL OUT OF THE HOLE AND LAY DOWN ALL TOOLS.
- PICK UP WORK STRING AND RUN IN HOLE WITH AN INJECTION PACKER WITH PUMP OUT PLUG. SET PACKER WITHIN 100' OF TOP PERFORMATIONS.
- 7. LOAD AND TEST CASING TO 550 PSI FOR 30 MINUTES. PULL OUT OF THE HOLE AND LAY DOWN WORK STRING.
- RIG UP TUBING TESTERS AND TEST INJECTION TUBING WHILE RUNNING IN THE HOLE. CIRCULATE PACKER FLUID. LATCH ONTO PACKER. PUMP OUT PLUG.
- 9. CONTACT NMOCD WITH AT LEAST 24 HOURS NOTICE, TO SCHEDULE MIT TEST. RUN MIT AT 550 PSI FOR 30 MINUTES AND SUBMIT PASSING TEST AS SOON AS POSSIBLE.
- 10. RDMO



## **Current/Proposed WBD**


### Well Name: NORTHEAST DRINKARD UNIT 605W

	Surface Legal Location 760' FNL, 1980' FWL, Unit C, Sec 15, T-2				Well Configuration Type Vertical
Original KB/RT Elevation (ft) 3,460.00		Original Spud Date 8/13/1951 00:00	Rig Release Date	PBTD (All)	Total Depth All (TVD)

Most Recent Job

Job Category
Other Capital

Primary Job Type
Secondary Job Type
Actual Start Date
Brid Date
8/13/1951
8/13/1951



Sante Fe Main Office Phone: (505) 476-3441

General Information Phone: (505) 629-6116

Online Phone Directory https://www.emnrd.nm.gov/ocd/contact-us

# State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. Santa Fe, NM 87505

CONDITIONS

Action 480777

### **CONDITIONS**

Operator:	OGRID:
APACHE CORPORATION	873
303 Veterans Airpark Ln	Action Number:
Midland, TX 79705	480777
	Action Type:
	[C-103] NOI Workover (C-103G)

### CONDITIONS

Created By		Condition Date
gcordero	If the workover requires tubing change same tube size shall be replaced as prescribed by the respective order and the packer shall not be set more than 100 ft above the top of the injection interval.	7/10/2025
gcordero	Passing MIT test in accordance with 19.15.26.11 NMAC.	7/10/2025