

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		✓
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - A" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>		<p>5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/></p> <p>5. State Oil & Gas Lease No.</p>
<p>1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input checked="" type="checkbox"/> Dry Hole</p> <p>2. Name of Operator Bennett Petroleum Corp.</p> <p>3. Address of Operator Suite 630, 1580 Lincoln St., Denver, CO 80203</p> <p>4. Location of Well UNIT LETTER I, 1645 FEET FROM THE South LINE AND 4216 FEET FROM THE West LINE, SECTION 9 TOWNSHIP 28N RANGE 21E NMPM.</p>	<p>7. Unit Agreement Name</p> <p>8. Farm of Lease Name Phelps Dodge</p> <p>9. Well No. 3-Y</p> <p>10. Field and Pool, or Wildcat Wildcat</p>	
<p>15. Elevation (Show whether DF, RT, GR, etc.) 6573" GR, 6586' KB</p>		<p>12. County Colfax</p>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

On or about Jan. 15, 1981, move in and rig up wireline unit and mast truck. Make gauge run in 7" casing to PBTD. Set cast iron bridge plug at approx. 1900'. Using dump bailer, cap bridge plug with 5' of cement. Rig up pump truck and tank. Mix approx. 60 Bbl 9.2 lb/gal mud. Fill casing with mud. Install 7" x 2" swage and 2" 2000 psi WP valve. Clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *R.E. Bennett* TITLE President DATE 12/26/80

APPROVED BY *Carl Ulvog* TITLE SENIOR PETROLEUM GEOLOGIST DATE 1-23-81

CONDITIONS OF APPROVAL, IF ANY: