

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	✓
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/>	GAS WELL <input type="checkbox"/>	OTHER- Dry
2. Name of Operator McClellan Oil Corporation		
3. Address of Operator P.O. Drawer 730, Roswell, NM 88202		
4. Location of Well UNIT LETTER <u>F</u> , <u>2310</u> FEET FROM THE <u>North</u> LINE AND <u>2310</u> FEET FROM THE <u>West</u> LINE, SECTION <u>19</u> TOWNSHIP <u>11-N</u> RANGE <u>22-E</u> NMPM.		

7. Unit Agreement Name
8. Farm or Lease Name Burner Fee
9. Well No. 3
10. Field and Pool, or Wildcat Wildcat
12. County Guadalupe

15. Elevation (Show whether DF, RT, GR, etc.)  
4904' G.L.

### Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

### SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon as follows:  
Pick up tubing and tag CIBP at 2680'. Set 25 sx Class C with 2% CaCl<sub>2</sub> plug across perfs from 2616' to 2658'.  
Pull tubing to 1450' and set 25 sx Class C with 2% CaCl<sub>2</sub> cement plug to cover 8-5/8" shoe.  
Pull tubing to 730' and set 25 sx Class C plug to cover 10-3/4" shoe.  
Pull tubing to surface and set 10 sx surface plug. Clean location and install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Paul Ragidale TITLE Operations Manager DATE 1/15/86  
APPROVED BY Kory E. Johnson TITLE DISTRICT SUPERVISOR DATE 1-21-86  
CONDITIONS OF APPROVAL, IF ANY: