

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO OPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -1" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> CO ₂ OTHER-	7. Unit Agreement Name
2. Name of Operator Amoco Production Company	8. Farm or Lease Name Heimann
3. Address of Operator P.O. Box 68 Hobbs, NM 88240	9. Well No. 5
4. Location of Well UNIT LETTER M 660 FEET FROM THE South LINE AND 1315 FEET FROM West LINE, SECTION 3 TOWNSHIP 19-N RANGE 33-E N.M.P.M.	10. Field and Pool, or Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 4957.7 GR	12. County Harding

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to squeeze behind 4 1/2" casing per the following:

Kill well and pull tubing. Set a cast iron bridge plug at 2200'. Run a pipe recovery log to determine top of cement. Cement top is estimated to be at 1900'. Perforate 4 1/2" casing approx. 20' above top of cement. Establish circulation to check perfs. Run tubing and cement retainer. Set retainer 50' above perfs. Pump calculated amount of Western Lite cement and 50 sx Class C cement. Will use 120% of open hole volume for calculations. Pull tubing and WOC. Drill out cement retainer, cement and cast iron bridge plug.

0+2-NMOCD-SF, 1-Hou, 1-Susp, 1-LBG

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Bob Davis</u>	TITLE <u>Admin. Analyst</u>	DATE <u>9-2-80</u>
APPROVED BY <u>Carl Lilling</u>	TITLE <u></u>	DATE <u>9/3/80</u>
CONDITIONS OF APPROVAL, IF ANY		