Submit 3 Copies	State of New Mexico Energy, Minerals, and Natural Resources Department		Form C-103 Revised 1-1-89
to Appropriate District Office	Energy, remorals, and reading resources Department		
<u>DISTRICT I</u> P.O. Box 1980, Hobbs, NM 88240	OIL CONSERVATION DIVISION P.O. Box 2088		WELL API NO. 30-021-20133
DISTRICT II P.O. Drawer DD, Artesia, NM 88210	Santa Fe, New Mexico 87504-2088		5. Indicate Type of Lease STATE FEE
DISTRICT III 1000 Rio Brazos Rd., Aztec, NM 87410			6. State Oil & Gas Lease No.
SUNDRY NOTICES AND REPORTS ON WELLS			
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A OFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"			7. Lease Name or Unit Agreement Name
1. Time EWA	(FORM C-101) FOR SUCH PROPOSALS.)		BRAVO DOME CO2 GAS UNIT
1. Type of Well	GAS WELL OTHER	CO2	SHAVE BUILD SOZ SAO SHIT
2. Name of Operator			8. Well No. 1933-091J
AMOCO PRODUCTION COMPANY			9. Pool name or Wildcat
3. Address of Operator P.O. Box 303, AMISTAD,	NEW MEXICO 88410		BRAVO DOME CO2 GAS UNIT
4 Well Location			
Unit Letter I 1980 Feet From The SOUTH Line and 1980 Feet From The EAST Line Section 3 Township 19N Range 33E NMPM UNION County			
Decition 3	*	ether DF, RKB, RT, GR, etc.)	
Check Appropriets Pourts Indicate Nature of Notice Penert or Other Date			
Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:			
PERFORM REMEDIAL WORK	PLUG AND ABANDON	REMEDIAL WORK	ALTERING CASING
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLING OPNS.	PLUG AND ABANDONMENT X
PULL OR ALTER CASING		CASING TEST AND CEMENT JOB	
OTHER:		OTHER:	
12. Describe Proposed or Completed Operations (Clearly state all pertinent datais, and give pertinent dates, including estimated date of starting any proposed work)			
SEE RULE 1103. 5/12/98			
Move in, rig up service unit. Kill well with fresh water. Nipple up BOP. Pull and lay down 2-3/8" production tbg. and packer. Pick up and run 2-3/8" workstring to 2449'. Spot 25 sacks Class C cement @ 2449'. Wait on cement.			
Tag top of cement @ 2280'. Circulate mud laiden fluid with inhibitor. Pressure test to 500 psi. Spot 10 sacks of Class C			
cement @ 2000' - 1902'. Spot 5 sacks of class C cement @ 30' - 3'. Cut off wellhead and anchors 3' below ground level. Cap well with steel plate. Rig down, move out service unit. Install dry hole marker.			
		OK 8-9	4-98
		DR O	
1	e and camplete to the best of my knowledge end belief.	Field Team Leeder	DATE 5/15/98
TYPE OR PRINT NAME D. J. Holcom			TELEPHONE NO. (505) 374-3010
(This space for State Use)	E John Ine :	STRICT SUPERV	ISOR DATE 8/10/98
CONDITIONS OF APPROVAL, IF ANY:			