

Submit 3 Copies To Appropriate District Office

District I

1625 N. French Dr., Hobbs, NM 88240

District II

811 South First, Artesia, NM 87210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

Form C-103  
Revised March 25, 1999

WELL API NO. <b>30-015-23119</b>
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. LG 3216
7. Lease Name or Unit Agreement Name: Siegrist State #1
8. Well No. #1
9. Pool name or Wildcat Wildcat Wolfcamp
10. Elevation (Show whether DR, RKB, RT, GR, etc.) 3847 GR

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
Oil Well ☐ Gas Well ☐ Other ☐

2. Name of Operator  
I. T. Properties

3. Address of Operator  
3502 Yachtclub Ct. Arlington, TX 76016

4. Well Location  
Unit Letter H : 1980 feet from the North line and 990 feet from the East line  
Section 25 Township 19 Range 23 NMPM County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)  
3847 GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

T.O.C.-4948'

Well will be plugged and abandoned. Current plug back T.D. is 6245'. Tubing (2(3/8") 6109' will be removed. Open perms are at 6218-6224'. Set cement plug from 6000' to 6300'. Pull casing from cement top. (4 1/2" casing). Fill hole with mud. Set cement plug 344' to surface. Cap at 3' below grade! Clean up location.

TA9 → 50' in? out of Stub - TA9

★ 100' Plug 4730'-4830' (Wolfcamp) if csq. is present at this depth - csq. must be perforated & cnt. be placed in? out of csq. 4730'-4830'

★ 100' plug 3601'-3701' (ABO) if csq. is present at this depth - csq. must be perforated & cnt. be placed in? out of csq. 3601'-3701'

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE W. Chen TITLE President DATE 3/11/04

Type or print name [Signature] Telephone No. 817 572 1955  
(This space for State use)

APPROVED BY [Signature] TITLE Wild Sup ID DATE MAR 18 2004

Conditions of approval, if any:

★ 100' Plug 1760'-1860' - TA9 ASSUMING csq. has been pulled below this depth.  
★ 100' plug 1589'-1689' (Glorieta) ASSUMING csq. has been pulled below this depth.