District I 1625 N. French Dr., Hobbs, NM 88240 District II 1301 W. Grand Avenue, Artesia, NM 88210 District III 1000 Rio Brazos Road, Aztec, NM 87410 District IV 1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico **Energy Minerals and Natural Resources** RECEIVED

Form C-101 May 27, 2004

Oil Conservation Division DEC 3 0 7004

☐ AMENDED REPORT

Submit to appropriate District Office 1220 South St. Francis Dr. Santa Fe, NM 87505 COLUMN TEST

APPLICATION FOR PERMIT TO DRILL, RE-ENTER, DEEPEN, PLUGBACK, OR ADD A ZONE OGRID Number Operator Name and Addres CHI OPERATING, INC P.O. BOX 1799 API Number MIDLAND, TEXAS 79702 5.33 Property Name Well No. Property Code ALLEN 10 Proposed Pool 2 9 Proposed Pool 1 ⁷ Surface Location Feet from the North/South line Feet from the East/West line UL or lot no. Section Township Lot Idn County Range 660 NORTH 1980 **EAST EDDY** В 31 **22S** 27E ⁸ Proposed Bottom Hole Location If Different From Surface Feet from the UL or lot no. Section Township Range Lot Idn North/South line Feet from the East/West line County Additional Well Information 12 Well Type Code 13 Cable/Rotary 14 Lease Type Code 15 Ground Level Elevation 11 Work Type Code R P 3176 N 16 Multiple Proposed Depth 19 Contractor 18 Formation 20 Spud Date DELAWARE 5400° 2/1/05 Depth to Groundwater Distance from nearest fresh water well Distance from nearest surface water GREATER THAN 1000' **GREATER THAN 660'** Liner: Synthetic ☑ 12 MIL OR BETTER IF WARRANTED Clay ☐ Pit Volume: bbls Drilling Method: Fresh Water Brine Diesel/Oil-based Gas/Air Closed-Loop System ²¹ Proposed Casing and Cement Program Hole Size Casing weight/foot Setting Depth Sacks of Cement Estimated TOC Casing Size 8 5/8" 12 1/4" 32# 300 CIRC 350 7 7/8" 5 1/2" 15.5# 5400 500 CIRC/TIE DACK d+f507 ²² Describe the proposed program. If this application is to DEEPEN or PLUG BACK, give the data on the present productive zone and proposed new productive zone. Describe the blowout prevention program, if any. Use additional sheets if necessary. MIRU, DRILL SURFACE HOLE W/FRESH WTR. SET CSG & CEMENT TO SURFACE. WHILE WOC 18 HRS. SET WELLHEAD & TST. INSTALL BOP/MANIFOLD & TST. TST CSG. DRILL PROD. HOLE TO TD W/BRINE WTR. LOG WELL & EVALUATE. SET CSG & CEMENT TO SURFACE/TIE BACK INTO SURFACE. BOP PIPE RAMS WILL BE FUNCTION TSTD DAILY. BLIND RAMS WILL BE FUNCTION TSTD ON ALL TRIPS. CLOSEST STRUCTURE IS +700'. THERE IS NO H28 EXPECTED. WILL HAVE MONITORING EQUIPMENTEMPLOYED REGUARDLESS. ²³ I hereby certify that the information given above is true and complete to the best OIL CONSERVATION DIVISION of my knowledge and belief. I further certify that the drilling pit will be constructed according to NMOCD guidelines , a general permit , or an Approved by: (attached) alternative QCD approved plan . TIM W. GUM DISTRICT IT SUPERVISOR Printed name: JOHN W. WOLF Title: 0 3 2005 JAN Expiration Date: IAN 03 2006 Title: Approval Date: E-mail Address: Date: 12/28/04 Phone: 432-685-5001 Conditions of Approval Attached

NOTIFY OCD OF SPUD & TIME TO WITNESS CEMENTING OF SURFACE & INTERMEDIATE CASING Production

<u>District I</u> 1625 N. Franch Dr. Hobba, NM 88240

District II 811 South First, Artesia, NM 88210

District III 1000 Rio Brazos Rd., Aztec NM 87410

District IV 2040 South Pacheco, Santa Fe, NM 87505 State of New Mexico Energy, Minerals & Natural Resources

OIL CONSERVATION DIVISION

2040 South Pacheco Santa Fe, N M 87505 Revised March 17, 1999
Submit to Appropriate District Office
State Lease — 4 Copies
Fee Lease — 3 Copies

____ AMENDED REPORT

WELL LOCATION AND ACREAGE DEDICATION PLAT

VV CLL LU API Number				Pool Code	AIND		NLAGE	DEDICE	Name		
AFI NUMDER		'	-001 0000				1001	Marilo			
Property Code		Property Name ALLEN						Well N	Well Number		
OGRID No.					•	sration N				Elevati	
004378							'ING, INC	•		3176	6
(III)					Surface			T. 11 25 11 11		1 = .40.45	
UL or Lot No.	Section 31	- 1	vnship 2-S	Range 27—1	Lotk	in.	Feet from the 660	North/South line NORTH	1980	East/West fine EAST	County $EDDY$
	37	-	······································				<u> </u>	1	1300	LASI	EDD1
UL or Lot No.	Section		Bottom mahip	Hole Range	Location		Different	From Suit North/South North		East/West line	Acombi
UL OF LOC NO.	Section	104	rnanip	Kunge	L57 K	ir.	reat nom the	North/South line	reaction the	Edet/West line	County
Dedicated Acres	s Joint or	Infill C	consolidatio	ri Code	Order No.		L	<u> </u>			
L	MADI F	14/11 1		CIONED	TO TU	iic Ot	DAIDLETION	I LINITH A	I INTERE	ST HAVE	DEEN
								PPROVED			DEEN
				<i>\f</i> '	, , , , ,				OPERA*	FOR CERTI	FICATION
				<i>\</i>	.099	1	+		I HEREDT C	TRUT AND CORRE	NPORMATION
		1		1	40		*		BEST OF M	TRUE AND CORRECT KNOWLEDGE AND	BELIEF.
				· }		Φ	1980	,			
		!			I.A T	N 3	221 15.1				
İ		4		1			04'13'36				:
ļ								· ·			r
				į			į			\mathcal{N}	
									5ignature	drite	144
							į		Printed Nar	WHEL OU	N. WOVE
							† 6 8		Title	Ent	/ · ·
		<u> </u>							Date	12/28/	14
									SURVE		FICATION
				į			i		SHOWN ON 1	ERSTPY THAT THE THS PLAT WAS PL TOP ACTUAL SUR	OTTED FROM
	4			1					ME OR UNDA	R MT SUPERVISIONS TRUB AND CORE KNOWLEDGE AND	IN, AND THAT
				į			į		BEST OF MT	KNOWLEDGE AND	RELIEF.
		į]					חהרהי	VBER 14.	2004
									Date of Su	NOR. RED	2004
		 -							Signgtune Dang	NOW. REDO	had Sunyayor
				į						En Co	\ \
					•					5412	25
				-							
		Î 1 1								I s Will	
				İ					NM	ESCPS:SWS	46 2
		1					<u> </u>		Certifica	to Number	

PECEIVED
DEC 8 0 2004

CHI OPERATING, INC HYDROGEN SULFIDE (H2S) CONTINGENCY PLAN FOR DRILLING/COMPLETING/WORKOVER/FACILITY WITH THE EXPECTATION OF H2S IN EXCESS OF 100 PPM

30-015-33788

WELL/FACILITY IN QUESTION

ALLEN #3

660' FNL & 1980' FEL

SECTION 31-T22S-R27E

EDDY COUNTY, N.M.

This well/facility is not expected to have H2S, but due to the sensitive location,

The following is submitted as requested

TABLE OF CONTENTS

GENERAL EMERGENCY PLAN	Page 1
EMERGENCY PROCEDURE FOR UNCONTROLLED RELEASE OF H2S	Page 1
EMERBENCY NUMBERS OF NOTIFICATION	Page 2
PROTECTION OF THE GENERAL (ROE) RADIUS OF EXPOSURE	Page 3
PUBLIC EVACUATION PLAN	Page 3
PROCEDURE FOR IGNITING AN UNCONTROLABLE CONDITION:	
INSTRUCTIONS FOR IGNITION:	Page 4
REQUIRED EMERGENCY EQUIPMENT	Page 4-5
USING SELF-CONTAINED BREATHING AIR EQUIPMENT (SCBA):	Page 5
RESCUE & FIRST AID FOR VICTOMS OF HYDROGEN SULFIDE (H2S) POISONING:	Page 6
H2S TOXIC EFFECTS	Page 7
H2S PHYSICAL EFFECTS	Page 7
LOCATION MAP	Page 8

In the event of an H2S emergency, the following plan will be initiated.

- 1) All personnel will immediately evacuate to an up-wind and if possible up-hill "safe area".
- 2) If for any reason a person must enter the hazardous area, they must wear a SCBA (Self contained breathing apparatus)
- 3) Always use the "buddy system"
- 4) Isolate the well/problem if possible
- 5) Account for all personnel
- 6) Display the proper colors warning all unsuspecting personnel of the danger at hand.
- 7) Contact the Company personnel as soon as possible if not at the location. (use the enclosed call list as instructed)

At this point the company representative will evaluate the situation and co-ordinate the necessary duties to bring the situation under control, and if necessary, the notification of emergency response agencies and residents.

EMERGENCY PROCEDURES FOR AN UNCONTROLLABLE RELEASE OF H2S

- 1) All personnel will don the self-contained breathing apparatus.
- 2) Remove all personnel to the "safe area". (always use the "buddy system"
- 3) Contact company personnel if not on location.
- 4) Set in motion the steps to protect and or remove the general public to an upwind "safe area". Maintain strict security & safety procedures while dealing with the source.
- 5) No entry to any unauthorized personnel.
- Notify the appropriate agencies: City Police-City street(s)
 State Police-State Rd
 Count Sheriff-County Rd.
 (will assist in general public evacuation/safety while maintaining roadblocks)

7) Call the NMOCD

If at this time the supervising person determines the release of H2S cannot be contained to the site location and the general public is in arms way he will take the necessary steps to protect the workers & the public.

Page 2

EMERGENCY CALL LIST: (Start and continue until ONE of these people have been reached)

	OFFICE	MOBILE		<u>HOME</u>		
Chi Operating, Inc.	432-685-5001					
Sonny Mann	505-365-2338	432-694-7062		505-365-2722		
John Wolf	432-685-5001 432-634-7061			432-682-4905		
Bill Bergman	432-685-5001	432-557-8773		432-689-4011		
EMERGENCY RESI	PONSE NUMBERS: 1	Eddy County, N	lew Me	xico		
State Police	Eddy County Lea County	505-748-9718 505-392-5588				
Sheriff	Eddy County Lea County		505-746-2701 505-			
Emergency Medical S	,		911 or 505-746-2701			
Eddy County Emerge	ency Management (Har	ту Burgess)	505-88	87-9511		
State Emergency Res	ponse Center (SERC)		505-47	76-9620		
Police Department - Fire Department - A		505-746-5001 505-746-5001				
Police Department - Carlsbad Fire Department - Carlsbad				505-885-2111 505-885-3125		
Fire Department - Loco Hills				505-677-2349		
(NMOCD) New Mexico Oil Conservation Division, District I (Lea, Roosevelt, Chavez, Curry) District II (Eddy, Chavez)				505-393-6161 505-748-1283		
Callaway Safety Indian Fire & Safety American Safety	505-392-2973 800-530-8693 505-746-1096					
BJ Services Schlumberger				505-746-3146 505-748-1392		

800-990-2833

Cudd Pressure Control

In the event greater than 100 ppm H2S is present, the ROE (Radius Of Exposure) calculations will be done to determine if the following is warranted:

- 100 ppm at any public area (any place not associated with this site)
- 500 ppm at any public road (any road which the general public may travel)
- 100 ppm radius of 3000' will be assumed if there is insufficient data to do the calculations, and there is a reasonable expectation that H2S could be present in concentrations greater than 100 ppm in the gas mixture.

Calculation for the 100 ppm ROE:

(H2S concentrations in decimal form:)

X = [(1.589) (concentration) (Q)] (0.6258)

10,000 ppm += .011,000 ppm += .001

Calculation for the 500 ppm ROE:

100 ppm + = .0001

10 ppm += .00001

X = [(0.4546) (concentration) (Q)] (.06258)

EXAMPLE: If a well/facility has been determined to have 100 ppm H2S in the gas mixture and the well/facility is producing at a gas rate of 200 MCFPD then:

ROE for 100 PPM

X=[(1.589)(.0001)(200,000)] (0.6258)

X = 8.8

ROE for 500 PPM

X=[(.4546)(.0005)(200,000)](0.6258)

X = 10.9'

(These calculations will be forwarded to the appropriate District NMOCD office when applicable)

PUBLIC EVACUATION PLAN:

(When the supervisor has determined that the General Public will be involved, the following plan will be implemented)

- 1) Notification of the emergency response agencies of the hazardous condition and Implement evacuation procedures.
- 2) A trained person in H2S safety, shall monitor with detection equipment the H2S Concentration, wind and area of exposure (ROE). This person will determine the outer perimeter of the hazardous area. The extent of the evacuation area will be determined from the data being collected. Monitoring shall continue until the situation has been resolved. (All monitoring equipment shall be UL approved, for use in class I groups A,B,C, & D, Division I, hazardous locations. All monitors will have a minimum capability of measuring H2S, oxygen, and flammable values.)
- 3) Law enforcement shall be notified to set up necessary barriers and maintain such for the duration of the situation as well as aid in the evacuation procedure.
- 4) The company supervising personnel shall stay in communication with all agencies through out the duration of the situation and inform such agencies when the situation has been contained and the effected area(s) is safe to enter.

PROCEDURE FOR IGNITING AN UNCONTROLABLE CONDITION:

The decision to ignite a well should be a last resort and one if not both of the following pertain.

- 1) Human life and/or property are in danger.
- 2) There is no hope of bring the situation under control with the prevailing conditions at the site.

INSTRUCTIONS FOR IGNITION:

- 1) Two people are required. They must be equipped with positive pressure; self contained breathing apparatus and a "D"-ring style, full body, OSHA approved safety harness. Non-flammable rope will be attached.
- 2) One of the people will be a qualified safety person who will test the atmosphere for H2S, Oxygen, & LFL. The other person will be the company supervisor; he is responsible for igniting the well.
- 3) Ignite up-wind from a distance no closer than necessary. Make sure that where you ignite from has the maximum escape avenue available. A 25mm flare gun shall be used, with a ±500' range to ignite the gas.
- 4) Prior to ignition, make a final check for combustible gases.
- 5) Following ignition, continue with the emergency actions & procedures as before.

REQUIRED EMERGENCY EQUIPMENT:

- 1) Breathing Apparatus:
 - Rescue Packs (SCBA) 1 unit shall be placed at each breathing area, 2 shall be stored in the safety trailer.
 - Work/Escape Packs 4 packs shall be stored on the rig floor with sufficient air hose not to restrict work activity.
 - Emergency Escape Packs 4 packs shall be stored in the doghouse for emergency evacuation.
- 2) Signage & Flagging:
 - One Color Code Condition Sign will be placed at the entrance to the site reflecting the possible conditions at the site.
 - A Colored Condition flag will be on display, reflecting the condition at the site at that time.
- 3) Briefing Area: Two, perpendicular areas will be designated by signs and readily accessible.

- 4) Wind Socks: Two windsocks will be placed in strategic locations, visible from all angles.
- 5) H2S Detectors and Alarm: The stationary detector with three (3) sensors will be placed in the upper dog house if equipped, set to visually alarm @ 10 ppm and audible @ 15 ppm. Calibrate a minimum of every 30 days or as needed. The 3 sensors will be placed in the following places: (Gas sample tubes will be stored in the safety trailer)
 - Rig Floor
 - Bell Nipple
 - End of Flow line or where well bore fluid are being discharged.
- 6) Auxiliary Rescue Equipment:
 - Stretcher
 - Two OSHA full body harness
 - 100' of 5/8" OSHA approved rope
 - 1 20# Class ABC fire extinguisher
 - Communication via cell phones on location and vehicles on location.

USING SELF-CONTAINED BREATHING AIR EQUIPMENT (SCBA):

SCBA should be worn when any of the following are performed:

- Working near the top or on top of a tank.
- Disconnecting any line where H2S can reasonably be expected.
- Sampling air in the area to determine if toxic concentrations of H2S exist.
- Working in areas where over 10 ppm on H2S has been detected.
- At any time there is a doubt as the level of H2S in the area.

All personnel shall be trained in the use of SCBA prior to working in a potentially hazardous location.

Facial hair and standard eyeglasses are not allowed with SCBA.

Contact lenses are never allowed with SCBA.

Air quality shall continuously be checked during the entire operation.

After each use, the SCBA unit shall be cleaned, disinfected, serviced and inspected.

All SCBA shall be inspected monthly.

RESCUE & FIRST AID FOR VICTOMS OF HYDROGEN SULFIDE (H2S) POISONING:

Do not panic.

Remain calm & think.

Get on the breathing apparatus.

Remove the victim to the safe breathing area as quickly as possible. Upwind an uphill from source or cross wind to achieve upwind.

Notify emergency response personnel.

Provide artificial respiration and /or CPR, as necessary.

Remove all contaminated clothing to avoid further exposure.

A minimum of two (2) personnel on location shall be trained in CPR and First Aid.

H2S is extremely toxic. The acceptable ceiling for eight hours of exposure is 10 ppm, which is .001% by volume. H2S is approximately 20% heavier than air (Sp.Gr=1.19 / Air=1) and color less. It forms an explosive mixture with air between 4.3% and 46.0%. By volume hydrogen sulfide (H2S) is almost as toxic as hydrogen cyanide and is 5-6 times more toxic than carbon monoxide.

Various Gases

Common	Chemical	Sp. Gr.	Threshold	Hazardous	Lethal
Name	Abbrev.		Limits	Limits	Concentration
Hydrogen Sulfide	H2S	1.19	10 ppm 15 ppm	100 ppm/ hr	600 ppm
Hydrogen Cyanide	HCN	0.94	10 ppm	150 ppm/ hr	300 ppm
Sulfur Dioxide	SO2	2.21	2 ppm	N/A	1000 ppm
Chlorine	CL2	2.45	1 ppm	4 ppm / hr	1000 ppm
Carbon Monoxide	СО	0.97	50 ppm	400 ppm / hr	1000 ppm
Carbon Dioxide	CO2	1.52	5000 ppm	5 %	10 %
Methane	CH4	0.55	90,000	Combustible @ 5%	N/A

- 1 Threshold limit Concentrations at which it is believed that all workers may be repeatedly exposed, day after day without Adverse effects.
- 2 Hazardous limit Concentration that may cause death
- 3 Lethal concentration Concentration that will cause death with short-term exposure.
- 4 Threshold limit 10 ppm NIOSH guide to chemical hazards
- 5 Short-term threshold limit.

PHYSICAL EFFECTS OF HYDROGEN SULFIDE:

CONCENTRATIONS		PYSICAL EFFECTS			
.001%	10 ppm	Obvious and unpleasant odor. Safe for 8hr exposure			
.005%	50 ppm	Can cause some flu-like symptoms and can cause pneumonia			
.01%	100 ppm	Kills the sense of smell in $3-15$ minutes. May irritate eyes and throat.			
.02%	200 ppm	Kills the sense of smell rapidy. Severly irritates eyes and throat. Severe flu-like symptoms after 4 or more hours. May cause lung damage and/or death.			
.06%	600 ppm	Loss of consciousness quickly, death will result in not rescued promptly.			

ALLEN #3 660' FNL & 1980' FEL SEC.31-T22S-R27E EDDY COUNTY, NM

