
d Otfice	State of New Mexico Energy, Minerals and Natural Resources		Form C-103 Revised August 1, 2011		
1625 N. French Dr., Hobbs, NM 88240	OIL CONSERVATION DIVISION 1220 South St. Francis Dr.		WELL API NO.		
District II - (575) 748-1283 811 S. First St., Artesia, NM 88210 OIL CO			30-015-205095. Indicate Type of Lease		
<u>District III</u> – (505) 334-6178 122			STATE FEE		
1000 Rio Brazos Rd., Aztec, NM 87410 <u>District IV</u> – (505) 476-3460	Santa Fe, NM 87505		6. State Oil & Gas Lease No.		
1220 S. St. Francis Dr., Santa Fe, NM 87505					
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)			 Lease Name or Unit Agreement Name Morris Estate CC Well Number 		
1. Type of Well: Oil Well 🛛 Gas Well 🗌 Other					
2. Name of Operator Votes Patroloum Composition			9. OGRID Number 025575		
Yates Petroleum Corporation 3. Address of Operator			10. Pool name or Wildcat		
105 South Fourth Street, Artesia, NM 88210			Eagle Creek; San Andres		
4. Well Location Unit Letter M : 330 feet from	m the South	line and	990 feet from the West line		
Section 14 Townsh	nip 17S Range	e 25E	NMPM Eddy County		
11. Elevation	(Show whether DR, R				
	3499'GI	<u> </u>			
12. Check Appropriate B	ox to Indicate Nati	ure of Notice,	Report or Other Data		
NOTICE OF INTENTION T	O:	SUB	SEQUENT REPORT OF:		
	PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WOR PERFORM REMEDIAL WOR COMMENCE DR				
PULL OR ALTER CASING DOWNHOLE COMMINGLE		CASING/CEMEN			
			v.emnrd.state.nm.us		
OTHER:		THER:	v.emnrd.se available when filling		
DOWNHOLE COMMINGLE Image: Complete completion. OTHER: Common complete completion. OTHER: Common complete co					
proposed completion or recompletion.	E 19.15.7.14 NIVIAC.	For Multip	bsite and documents.		
		re	bsite and should be date gulatory documents.		
Yates Petroleum Corporation plans to plug and aban	don this well as follow				
1. MIRU any safety equipment as needed. NU BOF 2. RIH with bit and scraper to just below perfs at 14 you are unable to get below the perfs then TOH and	30' and circulate Clas	s "C" cement to f			
sx).3. Cut off wellhead and verify that there is cement b	ehind all casing string	s at surface. If so	b, cement to surface with 60 sx. If not then		
RU wireline unit, perforate and circulate cement to s					
casing.		-			
4. Install dry hole marker and clean location.			RECEIVED		
Wellbore schematics attached	;		IVED		
NOTE: Votes Database Comparison will see shall					
NOTE: Yates Petroleum Corporation will use steel	pits and no earth pits	CONDITIONS C	F APPROVAL ATTACHED		
[]			DARTESIA		
Spud Date:	Rig Release Date:		nted providing work is		
		Completed by	Aug 2,2014		
I have be contify that the information above is true an	d				
I hereby certify that the information above is true and	a complete to the best	of my knowledge	e and belief.		
SIGNATURE (Lena) Juente	TITLE <u>Regula</u>	tory Reporting Su	pervisor DATE July 26, 2013		
	-mail address: <u>tinah</u>	@yatespetroleun	n.com PHONE: <u>575-748-4168 6</u>		
For State Use Only	\wedge		<u>^</u>		
APPROVED BY: Conditions of Approval (if any):	TITLE / 157	H Yper	UD DATE Ango, 2013		
#SEE A	HACNed (DAS	- -		


Well Name:Morris Estate CC #1Field:Eagle CreekLocation:330' FSL & 990' FWL Sec 14-17S-25ECounty:EddyState:New MexicoGL:3,499'Zero:KB:Spud Date:10/6/1971Completion Date:10/19/1971Comments:API # 30-015-205090000



Casing Program		
Size/Wt/Grade	Depth Set	
10 ¾" 32# K-55	439'	
7" 23# K-55	1,150'	
4 ½" 9.5# & 5 ½" 14# K-55	1,470'	

SKETCH NOT TO SCALE

Well Name:Morris Estate CC #1Field: Eagle CreekLocation:330' FSL & 990' FWL Sec 14-17S-25ECounty:EddyState:New MexicoGL:3,499'Zero:KB:Spud Date:10/6/1971Comments:API # 30-015-205090000



Casing Program		
Size/Wt/Grade	Depth Set	
10 ¾" 32# K-55	439'	
7* 23# K-55	1,150'	
4 ½" 9.5# & 5 ½" 14# K-55	1,470'	
	1	

SKETCH NOT TO SCALE

NEW MEXICO OIL CONSERVATION DIVISION DISTRICT 2 OFFICE 811 S. FIRST STREET ARTESIA, NM 88210 (575)748-1283

CONDITIONS OF APPROVAL FOR PLUGGING & ABANDONMENT
Operator: Vates Actualized Corp
Well Name & Number: Morris Estete CC #1
API #: 30 - 015 - 20509

- 1. Produced water <u>will not</u> be used during any part of the plugging & abandonment operation.
- 2. Notify NMOCD Dist. 2 office at least 24 hrs before beginning work.
- **3.** Closed Loop System is to be used for entire plugging operation. Upon completion, contents of steel pit are to be hauled to a permitted disposal location.
- 4. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used-to haul-waste products. It is the responsibility of the operator, as well as the contractor, to verify that this permit is place prior to performing work. Drivers shall produce a copy upon request of NMOCD Field Inspectors.
- 5. A subsequent C-103 will serve as notification that the well bore has been plugged ONLY. A C-103 FINAL shall be filed before any bonding can be released on the well. Upon receipt of the Final, an inspection will be performed to verify that the location has been satisfactorily cleaned to NMOCD standards.
- 6. If work has not begun within 90 days of the approval of this procedure, an extension request must be filed, stating reason that well has not been plugged.
- 7. Every attempt must be made to clean the well bore out to below the perfs, before any plugs can be set, by whatever means possible.

.

8. Cement Retainers may not be used.

- 9. Squeeze pressures are not to exceed 500 PSI, unless approval is given by NMOCD.
- 10. Plugs may be combined after consulting with and getting approval from NMOCD.
- 11. Minimum WOC time for tag plugs will be 4 Hrs.

DATE: Aug 2, 2013

· .4.

APPROVED BY: ADudo

e genalines,

GUIDELINES FOR PLUGGING AND ABANDONMENT

DISTRICT II / ARTESIA

- All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater.
- Mud laden fluids must be placed between all cement plugs.
- Mud laden fluids must be mixed at 25 sacks of gel per 100 bbls of water.
- A cement plug is required to be set 50' below and 50' above all casing shoes and casing stub plugs. These plugs must be tagged.
- A CIBP with 35' of cement on top may be set in lieu of 100' cement plug.
- A plug as indicated above must be placed within 100' of top perforation. This plug must be tagged.
- Plugs set below and above salt zones must be tagged.
- No more than 2000' is to be allowed between cement plugs in open hole and no more than 3000' in cased hole.
- DV tools are required to have a 100' cement plug set 50' above and below the tool and must be tagged.
- Formations to be isolated with plugs placed at the top of each formation are:
 - o Fusselman
 - o Devonian
 - o Morrow

1002.2 Mar 12.2

- o Wolfcamp
- o Bone Spring
- o Delaware
- Any Salt Section (Plug at top and bottom)
- o Abo
- o Glorieta
- Yates (this plus is usually at base of salt section)
- If cement does not exist behind casing strings at recommended formation depths, the casing must be cut and pulled with plugs set at these depths or casing must be perforated and cement squeezed behind casing at the formation depths.
- In the R-111-P area (Potash Mine area) a solid cement plug must be set across the salt section.
 Fluid used to mix the cement shall be saturated with the salts common to the section penetrated and in suitable proportions, but not more than a 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible (50' below and 50' above).