Submit 3 Copies To Appropriate District Office	State of New Mexico Energy, Minerals and Natural Resources		*****	Form C-103 May 27, 2004	
<u>District I</u> 1625 N. French Dr., Hobbs, NM 88240	Energy, winterars a	inu maturai Kesoui	WELL API		
District II	OIL CONSERV	ATION DIVISIO	11V ———	5-34261	
1301 W. Grand Ave., Artesia, NM 8821 <u>District III</u> 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Francis Dr.		5. Indicate STA	Type of Lease TE ⊠ FEE □	
District IV	Santa Fe,	NM 87505		& Gas Lease No.	
1220 S. St. Francis Dr., Santa Fe, NM 87505				B-2178	
(DO NOT USE THIS FORM FOR PRO		N OR PLUG BACK TO	A	ame or Unit Agreement Name	
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)			QUAIL ST COM 8. Well Number 1		
1. Type of Well: Oil Well Gas Well Other					
Name of Operator MURCHISON OIL & GAS, INC.		9. OGRID	Number 015363		
Address of Operator 1100 MIRA VISTA BLVD.			10. Pool name or Wildcat		
4. Well Location	ANO, TX. 75093-4698		CROW F	LATS; MORROW, SE	
Unit Letter P	: <u>1250</u> feet from the	SOUTH line	e and 660 fe	eet from the <u>EAST</u> line	
Section 8	Township 17-S		NMPM	County EDDY	
5001011	11. Elevation (Show whe			County LDD1	
Pit or Below-grade Tank Application	or Closure	····			
Pit type Depth to Groun		est fresh water well	Distance from neare:	st surface water	
Pit Liner Thickness:	il Below-Grade Tank: Volum		 ols; Construction Materi	al	
12 Check	Appropriate Box to Ind				
		leate Nature of 1	-		
	INTENTION TO:	DEMEDIA	SUBSEQUENT		
PERFORM REMEDIAL WORK TEMPORARILY ABANDON	☐ PLUG AND ABANDON☐ CHANGE PLANS		AL WORK ICE DRILLING OPNS	☐ ALTERING CASING ☐ .□ P AND A □	
	☐ MULTIPLE COMPL		CEMENT JOB		
				_	
OTHER:		OTHER:			
OTHER: 13. Describe proposed or corof starting any proposed	mpleted operations. (Clearly	OTHER:	tails, and give pertine	nt dates, including estimated date diagram of proposed completion	
OTHER: 13. Describe proposed or cor of starting any proposed or recompletion.	mpleted operations. (Clearly work). SEE RULE 1103. For	OTHER: state all pertinent de or Multiple Complet	tails, and give pertine ions: Attach wellbore	nt dates, including estimated date	
OTHER: 13. Describe proposed or corof starting any proposed or recompletion. Drill 8-1/2" hole from base of	mpleted operations. (Clearly swork). SEE RULE 1103. For 9-5/8" casing set @ 2051' to Float Shoe	OTHER: state all pertinent de or Multiple Complet	tails, and give pertine ions: Attach wellbore	nt dates, including estimated date	
OTHER: 13. Describe proposed or cor of starting any proposed or recompletion.	mpleted operations. (Clearly swork). SEE RULE 1103. For 9-5/8" casing set @ 2051' to Float Shoe 5-1/2" 17#/FT P-110	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42'	tails, and give pertine ions: Attach wellbore	nt dates, including estimated date diagram of proposed completion	
OTHER: 13. Describe proposed or correction of starting any proposed or recompletion. Drill 8-1/2" hole from base of	mpleted operations. (Clearly swork). SEE RULE 1103. For 9-5/8" casing set @ 2051' to Float Shoe 5-1/2" 17#/FT P-110 Float Collar	other: Other:	tails, and give pertine ions: Attach wellbore	nt dates, including estimated date diagram of proposed completion	
OTHER: 13. Describe proposed or cor of starting any proposed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS	mpleted operations. (Clearly swork). SEE RULE 1103. For 9-5/8" casing set @ 2051' to Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42'	tails, and give pertine ions: Attach wellbore " csg as follows: RECE!	nt dates, including estimated date diagram of proposed completion	
OTHER: 13. Describe proposed or correct of starting any proposed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS 32 JTS	mpleted operations. (Clearly swork). SEE RULE 1103. For 9-5/8" casing set @ 2051' to Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool 5-1/2" 17#/FT P-110	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42' 1' 2896' 2' 1368'	tails, and give pertine ions: Attach wellbore " csg as follows: RECE!	nt dates, including estimated date diagram of proposed completion	
OTHER: 13. Describe proposed or cor of starting any proposed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS 32 JTS 112 JTS	mpleted operations. (Clearly swork). SEE RULE 1103. For 19-5/8" casing set @ 2051' to Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool 5-1/2" 17#/FT P-110 5-1/2" 17#/FT L-80	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42' 1' 2896' 2' 1368' 4557'	tails, and give pertine ions: Attach wellbore "csg as follows:	nt dates, including estimated date diagram of proposed completion	
OTHER: 13. Describe proposed or correct of starting any proposed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS 32 JTS	mpleted operations. (Clearly swork). SEE RULE 1103. For 19-5/8" casing set @ 2051' to Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool 5-1/2" 17#/FT P-110 5-1/2" 17#/FT L-80	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42' 1' 2896' 2' 1368'	tails, and give pertine ions: Attach wellbore " csg as follows: RECE!	nt dates, including estimated date diagram of proposed completion	
OTHER: 13. Describe proposed or cord of starting any proposed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS 32 JTS 112 JTS 28 JTS Set casing @ 10017'. Cement	mpleted operations. (Clearly swork). SEE RULE 1103. For 19-5/8" casing set @ 2051' to Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool 5-1/2" 17#/FT P-110 5-1/2" 17#/FT L-80 5-1/2" 17#/FT P-110 tw/ 1000 SXS 50/50 "H" + 5	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42' 1' 2896' 2' 1368' 4557' 1153' 10021' /10% FL52 + 5/10%	tails, and give pertine ions: Attach wellbore?" csg as follows: RECE! MAR 1 0 OD-AH 6 FL25 + 3/10% SMS	nt dates, including estimated date diagram of proposed completion VED 2006 1581A + 5/10% Salt. Bump plug w/	
OTHER: 13. Describe proposed or corof starting any proposed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS 32 JTS 112 JTS 28 JTS Set casing @ 10017'. Cement 1730 PSI. Circulate 216 SXS	mpleted operations. (Clearly swork). SEE RULE 1103. For 19-5/8" casing set @ 2051' to Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool 5-1/2" 17#/FT P-110 5-1/2" 17#/FT L-80 5-1/2" 17#/FT P-110 tw/ 1000 SXS 50/50 "H" + 5 to reserve pit. WOC 4 HRS.	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42' 1' 2896' 2' 1368' 4557' 1153' 10021' /10% FL52 + 5/10% Pump 950 SXS 50	tails, and give pertine ions: Attach wellbore " csg as follows: RECE! MAR 1 0 QOD-AH 6 FL25 + 3/10% SMS 750/10 POZ "H" + .35	nt dates, including estimated date diagram of proposed completion VED 2006 1581 + 5/10% Salt. Bump plug w/ % FL52 + 5/10% salt + 1/4 #/SX	
OTHER: 13. Describe proposed or corof starting any proposed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS 32 JTS 112 JTS 28 JTS Set casing @ 10017'. Cement 1730 PSI. Circulate 216 SXS Celloflake followed w/ 350 SX	mpleted operations. (Clearly swork). SEE RULE 1103. For Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 t w/ 1000 SXS 50/50 "H" + 5 to reserve pit. WOC 4 HRS. SS 50/50 POZ "H" + 5/10% F	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42' 1' 2896'. 2' 1368'. 4557'. 1153'. 10021'. /10% FL52 + 5/10% Pump 950 SXS 50. L52 + 5/10% FL25	tails, and give pertine ions: Attach wellbore "csg as follows: RECF! MAR 1 0 OD-AH "FL25 + 3/10% SMS (50/10 POZ "H" + .35 + 3/10% SMS + 5/10	nt dates, including estimated date diagram of proposed completion 2006 + 5/10% Salt. Bump plug w/ % FL52 + 5/10% salt + 1/4 #/SX % Salt. Bump plug w/ 3200 PSI.	
OTHER: 13. Describe proposed or corof starting any proposed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS 32 JTS 112 JTS 28 JTS Set casing @ 10017'. Cement 1730 PSI. Circulate 216 SXS Celloflake followed w/ 350 SX Plug down @ 0300 HRS 1/31/2	mpleted operations. (Clearly swork). SEE RULE 1103. For Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 t w/ 1000 SXS 50/50 "H" + 5 to reserve pit. WOC 4 HRS. SS 50/50 POZ "H" + 5/10% F	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42' 1' 2896'. 2' 1368'. 4557'. 1153'. 10021'. /10% FL52 + 5/10% Pump 950 SXS 50. L52 + 5/10% FL25	tails, and give pertine ions: Attach wellbore "csg as follows: RECF! MAR 1 0 OD-AH "FL25 + 3/10% SMS (50/10 POZ "H" + .35 + 3/10% SMS + 5/10	nt dates, including estimated date diagram of proposed completion VED 2006 1581 + 5/10% Salt. Bump plug w/ % FL52 + 5/10% salt + 1/4 #/SX	
OTHER: 13. Describe proposed or corof starting any proposed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS 32 JTS 112 JTS 28 JTS Set casing @ 10017'. Cement 1730 PSI. Circulate 216 SXS Celloflake followed w/ 350 SX	mpleted operations. (Clearly swork). SEE RULE 1103. For Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 t w/ 1000 SXS 50/50 "H" + 5 to reserve pit. WOC 4 HRS. SS 50/50 POZ "H" + 5/10% F	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42' 1' 2896'. 2' 1368'. 4557'. 1153'. 10021'. /10% FL52 + 5/10% Pump 950 SXS 50. L52 + 5/10% FL25	tails, and give pertine ions: Attach wellbore "csg as follows: RECF! MAR 1 0 OD-AH "FL25 + 3/10% SMS (50/10 POZ "H" + .35 + 3/10% SMS + 5/10	nt dates, including estimated date diagram of proposed completion 2006 + 5/10% Salt. Bump plug w/ % FL52 + 5/10% salt + 1/4 #/SX % Salt. Bump plug w/ 3200 PSI.	
OTHER: 13. Describe proposed or corof starting any proposed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS 32 JTS 112 JTS 28 JTS Set casing @ 10017'. Cement 1730 PSI. Circulate 216 SXS Celloflake followed w/ 350 SX Plug down @ 0300 HRS 1/31/2	mpleted operations. (Clearly swork). SEE RULE 1103. For Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 t w/ 1000 SXS 50/50 "H" + 5 to reserve pit. WOC 4 HRS. SS 50/50 POZ "H" + 5/10% F	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42' 1' 2896'. 2' 1368'. 4557'. 1153'. 10021'. /10% FL52 + 5/10% Pump 950 SXS 50. L52 + 5/10% FL25	tails, and give pertine ions: Attach wellbore "csg as follows: RECF! MAR 1 0 OD-AH "FL25 + 3/10% SMS (50/10 POZ "H" + .35 + 3/10% SMS + 5/10	nt dates, including estimated date diagram of proposed completion 2006 + 5/10% Salt. Bump plug w/ % FL52 + 5/10% salt + 1/4 #/SX % Salt. Bump plug w/ 3200 PSI.	
OTHER: 13. Describe proposed or corof starting any proposed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS 32 JTS 112 JTS 28 JTS Set casing @ 10017'. Cement 1730 PSI. Circulate 216 SXS Celloflake followed w/ 350 SX Plug down @ 0300 HRS 1/31/tbg head. Release rig @ 1500	mpleted operations. (Clearly swork). SEE RULE 1103. For Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 tw/ 1000 SXS 50/50 "H" + 5 to reserve pit. WOC 4 HRS. (SS 50/50 POZ "H" + 5/10% F/06. Floats held. Circulated 20 HRS 1/31/06.	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42' 1' 2896'. 2' 1368'. 4557'. 1153'. 10021'. /10% FL52 + 5/10% Pump 950 SXS 50 L52 + 5/10% FL25 216 SXS to reserve.	tails, and give pertine ions: Attach wellbore. " csg as follows: RECF! MAR 1 0 OD-AH " FL25 + 3/10% SMS /50/10 POZ "H" + .35 + 3/10% SMS + 5/10 Nipple down BOP, S	nt dates, including estimated date diagram of proposed completion 2006 + 5/10% Salt. Bump plug w/ % FL52 + 5/10% salt + 1/4 #/SX % Salt. Bump plug w/ 3200 PSI. et slips, cut off casing and install	
OTHER: 13. Describe proposed or corof starting any proposed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS 32 JTS 112 JTS 28 JTS Set casing @ 10017'. Cement 1730 PSI. Circulate 216 SXS Celloflake followed w/ 350 SX Plug down @ 0300 HRS 1/31/2	mpleted operations. (Clearly swork). SEE RULE 1103. For a set @ 2051' to Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 for a serve pit. WOC 4 HRS. SEC 50/50 POZ "H" + 5/10% For a serve pit. WOC 4 HRS. SEC 50/50 P	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42' 1' 2896' 2' 1368' 4557' 1153' 10021' /10% FL52 + 5/10% Pump 950 SXS 50 L52 + 5/10% FL25 216 SXS to reserve.	tails, and give pertine ions: Attach wellbore. " csg as follows: RECE! MAR 1 0 OD-AH " FL25 + 3/10% SMS /50/10 POZ "H" + .35 + 3/10% SMS + 5/10 Nipple down BOP, S	nt dates, including estimated date diagram of proposed completion 750 7006 7510% Salt. Bump plug w/ % FL52 + 5/10% salt + 1/4 #/SX % Salt. Bump plug w/ 3200 PSI. et slips, cut off casing and install	
OTHER: 13. Describe proposed or corof starting any proposed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS 32 JTS 112 JTS 28 JTS Set casing @ 10017'. Cement 1730 PSI. Circulate 216 SXS Celloflake followed w/ 350 SX Plug down @ 0300 HRS 1/31/tbg head. Release rig @ 1500	mpleted operations. (Clearly swork). SEE RULE 1103. For Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 t w/ 1000 SXS 50/50 "H" + 5 to reserve pit. WOC 4 HRS. (S 50/50 POZ "H" + 5/10% F/06. Floats held. Circulated 2 HRS 1/31/06.	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42' 1' 2896' 2' 1368' 4557' 1153' 10021' /10% FL52 + 5/10% Pump 950 SXS 50 L52 + 5/10% FL25 216 SXS to reserve.	tails, and give pertine ions: Attach wellbore. " csg as follows: RECE! MAR 1 0 OD-AH " FL25 + 3/10% SMS /50/10 POZ "H" + .35 + 3/10% SMS + 5/10 Nipple down BOP, S	nt dates, including estimated date diagram of proposed completion 750 7006 7510% Salt. Bump plug w/ % FL52 + 5/10% salt + 1/4 #/SX % Salt. Bump plug w/ 3200 PSI. et slips, cut off casing and install	
OTHER: 13. Describe proposed or composed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS 32 JTS 112 JTS 28 JTS Set casing @ 10017'. Cement 1730 PSI. Circulate 216 SXS Celloflake followed w/ 350 SX Plug down @ 0300 HRS 1/31/tbg head. Release rig @ 1500 I hereby certify that the informating rade tank has been/will be constructed of the stank has been will be constructed of the stank has been	mpleted operations. (Clearly swork). SEE RULE 1103. For some set @ 2051' to Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 tw/ 1000 SXS 50/50 "H" + 5 to reserve pit. WOC 4 HRS. (S 50/50 POZ "H" + 5/10% F/06. Floats held. Circulated 2 HRS 1/31/06.	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42' 1' 2896' 2' 1368' 4557' 1153' 10021' /10% FL52 + 5/10% Pump 950 SXS 50 L52 + 5/10% FL25 216 SXS to reserve.	tails, and give pertine ions: Attach wellbore 2" csg as follows: RECF! MAR 1 0 ODD-AIT 6 FL25 + 3/10% SMS /50/10 POZ "H" + .35 + 3/10% SMS + 5/10 Nipple down BOP, S nowledge and belief. rmit or an (attached) at ident Operations	Int dates, including estimated date diagram of proposed completion of diagram of proposed completion of the diagram of the d	
OTHER: 13. Describe proposed or composed or recompletion. Drill 8-1/2" hole from base of 1 JT 70 JTS 32 JTS 112 JTS 28 JTS Set casing @ 10017'. Cement 1730 PSI. Circulate 216 SXS Celloflake followed w/ 350 SX Plug down @ 0300 HRS 1/31/4 tbg head. Release rig @ 1500 I hereby certify that the informating rade tank has been/will be constructed as SIGNATURE	mpleted operations. (Clearly swork). SEE RULE 1103. For some set @ 2051' to Float Shoe 5-1/2" 17#/FT P-110 Float Collar 5-1/2" 17#/FT P-110 DV Tool 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 5-1/2" 17#/FT P-110 tw/ 1000 SXS 50/50 "H" + 5/10" to reserve pit. WOC 4 HRS. (S 50/50 POZ "H" + 5/10% F/06. Floats held. Circulated 2 HRS 1/31/06.	OTHER: state all pertinent de or Multiple Complet 10,025'. Ran 5-1/2 1' 42' 1' 2896' 2' 1368' 4557' 1153' 10021' /10% FL52 + 5/10% Pump 950 SXS 50 L52 + 5/10% FL25 216 SXS to reserve.	tails, and give pertine ions: Attach wellbore 2" csg as follows: RECF! MAR 1 0 ODD-AIT 6 FL25 + 3/10% SMS /50/10 POZ "H" + .35 + 3/10% SMS + 5/10 Nipple down BOP, S nowledge and belief. rmit or an (attached) at ident Operations	nt dates, including estimated date diagram of proposed completion 2006 FSIA + 5/10% Salt. Bump plug w/ % FL52 + 5/10% salt + 1/4 #/SX % Salt. Bump plug w/ 3200 PSI. et slips, cut off casing and install I further certify that any pit or below- lternative OCD-approved plan DATE 3/2/2006	