
Submit 1 Copy To Appropriate District State of New Mexico	Form C-103			
Office, District I = (575) 393-6161 Energy, Minerals and Natural Resources	Revised August 1, 2011			
Office, District I – (575) 393-6161 Listrict II – (575) 748-1283 District II – (575) 748-1283	WELL API NO.			
SILS Error St. Artesia NM 82210 OIL CONSERVATION DIVISION	30-015-32862			
$\frac{District III}{District III} = (505) 334-6178 MAR 0 6 2017 1220 \text{ South St. Francis Dr.}$	5. Indicate Type of Lease			
1000 Rio Brazos Rd., Aztec, NM 87410 <u>District IV – (505) 476-3460</u> Santa Fe, NM 87505	STATE FEE 6. State Oil & Gas Lease No.			
1220 S. St. Francis Dr., Santa Fe, NKECEIVED	o. State on te Gas Lease No.			
87505 SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name			
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A				
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	STATE 2			
1. Type of Well: Oil Well 🛛 Gas Well 🗌 Other	8. Well Number: 8			
2. Name of Operator Chevron U.S.A. INC.	9. OGRID Number 4323			
3. Address of Operator	10. Pool name or Wildcat			
6301 DEAUVILLE BLVD, MIDLAND, TX 79706 RM.N3002	BENSON; DELAWARE			
4. Well Location				
	1980 feet from the <u>WEST</u> line			
Section 2 Township 19S Range 30E	NMPM County EDDY			
11. Elevation (Show whether DR, RKB, RT, GR, etc. 3427' GR				
3427 UK	an a			
12. Check Appropriate Box to Indicate Nature of Notice,	Report or Other Data			
	*			
	SEQUENT REPORT OF:			
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WOR				
PULL OR ALTER CASING	I JOB			
	_			
OTHER: OTHER: OTHER: OTHER: OTHER: OTHER:				
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of				
proposed completion or recompletion.				
1. Call and notify NMOCD 24 hrs. before operations begin.				
2. MIRU. NDWH. NUBOPE. WOLDTHG-CMT				
3. Set CIBP@4,750', circulate well w/9.5 ppg mud and spot 25sx of cmt. on top. Pressure test casing.				
4. Perf and squeeze 55sx of Class "C" cement from 3,278'-3,078', WOC&Tag. (Shoe)				
5. Perf and squeeze 55sx of Class "C" cement from 1,850'-1,650', WOC&Tag. (Yates)				
6. Perf and squeeze 175sx of Class "C" cement from 698' to surface. (Shoe/FW/surface)				
7. Verify cement to surface on all casings. Cut off wellhead and anchors 3' below grade. Welchon				
Closed loop above ground tank system will be used for fluids.				
Crosed roop above ground tank system will be used for fluids.				
WELL MUST BE PLUCOED BY 3/6/2018	e and bold churr will me on we have			
I hereby certify that the information above is true and complete to the best of my knowledge and be hereby certify that the information above is true and complete to the best of my knowledge and be hereby certify that the information above is true and complete to the best of my knowledge and be hereby certify that the information above is true and complete to the best of my knowledge and be hereby certify that the information above is true and complete to the best of my knowledge and be hereby certify that the information above is true and complete to the best of my knowledge and be hereby certify that the information above is true and complete to the best of my knowledge and be hereby certify that the information above is true and complete to the best of my knowledge and be hereby certify that the information above is true and complete to the best of my knowledge and be hereby certify that the information above is true and complete to the best of my knowledge and be hereby certify that the information above is true and complete to the best of my knowledge and be hereby certify the information above is true and complete to the best of my knowledge and be hereby certify the information above is true and complete to the best of my knowledge and the information above is true and certify the information above is true above is tr				
dryhole marker and clean location. Closed loop above ground tank system will be used for fluids. <u>WELL MUST BE PLUCOB</u> BY 3/6/20/P I hereby certify that the information above is true and complete to the best of my knowledge and toffective summer at 000 Web page under SIGNATURE <u>M. Jack Presed</u> TITLE Project Manager				
SIGNATURE <u>M. Jus Krack</u> TITLE Project Manager	LICE DATE OD OT 117			
SIGNATURE	e and the first pure with a record of the parts e and the first pure with a record of the parts APP of fight in a record of the formation of the parts APP of the first parts of the formation of the parts of the formation of the formation of the parts of the formation of the parts of the			
Type or print name <u>M. Lee Reark</u> E-mail address: <u>LRoark@Chevro</u>	on.com PHONE: _(432)-687-7279			
For State Use Only				
APPROVED BY Alefut J by TITLE COMPLIANCE OFFICER DATE 3/6/2016				
Conditions of Approval (if any):				

-

^

X	SEE	ATTACHED	COA-S
~ ~		•	

۰ ب



CURRENT

۰.

Chevron U.S.A. Inc. Wellbore Diagram : STATE 2 8



[Lease] OHO HOBBS FMT [Well No.] STATE 2 8 8 [Field] HACKBERRY NORTH [Location] 660FSL1980FWL [Sec.] N/A [Blk] [Survey] N/A [County] Eddy [St.] New Mexico [Refno] HL5623 [API] 3001532862 [Cost Center] UCRD70400 [Section] E030 [Township] 2 [Range] S019 [Current Status] Hole Abandoned - Gene [Dead Man Anchors Test Date] NONE [Directions]
 Tubing String Quantity (Top-Bottom Depth) Desc

 146 @(22-4621) J-55
 2.375 OD/ 4.70# T&C External Upset 1.995 ID 1.901

 1 @(4621-4625) J-55
 2.375 OD/ 4.70# T&C External Upset 1.995 ID 1.901

 2 @(4625-4690) J-55
 2.375 OD/ 4.70# T&C External Upset 1.995 ID 1.901

 2 @(4626-4690) J-55
 2.375 OD/ 4.70# T&C External Upset 1.995 ID 1.901

 1 @(4690-4692) Tubing Anchor/Catcher 2.375
 2.375 OD/ 4.70# T&C External Upset 1.995 ID 1.901 Drift - Internal Plastic

 1 @(4754-4758) Seat Nipple/Shoe - (2.375) Unknown Type 1.904 T/358 Action 1.905 (2.375 OD/ 4.70# T&C External Upset 1.995 ID 1.901

 1 @(4782-4782) Sand Screen 2.375 x 23 5 15 Stot 1.904 T/368-4812) Bull Puol Mud Anchor 2.375 165 Ē 1 @(4782-4786) 3-55 2.375 OD/ 4.70# T&C External Upset 1.995 ID 1.901 (@(4786-4812) Bull Pug Mud Anchor 2.375-<u>Rod String Quantity (Top-Bottom Depth) Desc</u> 1 @(22-48) 1.500 (1 1/2 in.) D stray Metal x 26-1 @(48-50) 0.875 (7/8 in.) D x 4 Rod Sub-1 @(54-62) 0.875 (7/8 in.) D x 4 Rod Sub-1 @(463-02) 0.875 (7/8 in.) D x 25 Rod-1 @(4632-4862) 1.500 (1 1/2 in.) K x 25 Rod-9 @(4632-4862) 1.500 (1 1/2 in.) K x 4 Rod Sub-1 @(4686-4860) 0.875 (7/8 in.) D x 4 Rod Sub-1 @(4686-4860) 0 2331 Surface Casing (Top-Bottom Depth) Desc @(22.673) H-40 13 375 OD/48 00# Unknown Thread 12.715 ID 12.559 Drift-@(22.673) Cement (behind Casing)-@(22.673) Wellbore Hole OD-17.5000-3108 @(22-3228) J-55 8 625 OD/ 32 00# Unknown Thread 7 921 ID 7 796 Dnft @(22-3228) J-55 8 625 OD/ 32 00# Unknown @(22-3228) Cement (behind Casing)-@(673-3228) Wellbore Hole OD-11 0000-Production Casing (Top-Bottom Depth) Desc @(4817-4819) Perforations-Open @(4954-4947) Perforations-Open @(4962-4967) Perforations-Open @(4978-4995) Perforations-Open @(4978-4995) Perforations-Open @(4978-4995) Perforations-Open @(5101-5119) Perforations-Open @(5134-5143) Cement-3842 4576 F @(5144-5153) Perforations-Open @(5904-6205) Plug - Cement-@(6205-6702) Plug - Cement-@(8730-8732) Bridge Plug Cast Iron 5.500-@(49690-10102) Plug - Cement-@(11310-1152) Bridge Plug (Unknown Type) 5.500-@(11350-11552) Bridge Plug (Unknown Type) 5.500-@(11550-11552) Bridge Plug (Unknown Type) 5.500-@(11589-11552) Bridge Plug Cast Iron 5.500-@(11589-11552) Bridge Plug Cast Iron 5.500-@(11589-11652) Bridge Plug Cast Iron 5.500-@(11589-11978) Perforations-Closed-Abandoned @(41969-11978) Perforations-Closed-Abandoned @(212-12234) J-55 5.500 ODJ 14.00# Unknown Thread 5.012 ID 4.887 Drift-@(12024-12234) Wellbore Hole OD-7.8750-@(10004-112234) Cement (behind Casing)-5536 6669 @(10004-12234) Cement (behind Casing)-8955

[Ground Elevation (MSL)] 3427.00 [Spud Date] 08/10/2003 [Compl. Date] 01/01/1800 [Well Depth Datum] Kelly Bushing [Elevation (MSL)] 3449.00 [Correction Factor] 22.00 [Last Updated by] kswa [Date] 10/22/2015 [null] null [null] null

142.24.22

10867

2234

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 7. Produced water will not be used during any part of the plugging operation.
- 8. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 9. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 10. Class 'C' cement will be used above 7500 feet.

١

- 11. Class 'H' cement will be used below 7500 feet.
- 12. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 13. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing
- 14. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 15. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.

- 16. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 17. No more than **3000' is allowed between cement plugs in cased hole and 2000' in open** hole.
- 18. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow

٠

- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- I) Glorieta
- J) Yates.
- K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 19. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3. API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County

(SPECIAL CASES)

AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)