

## Roadster State Com 808H

### Casing and Cement

<u>String</u>	<u>Hole Size</u>	<u>Csg OD</u>	<u>PPF</u>	<u>Depth</u>	<u>Sx Cement</u>	<u>TOC</u>
Surface	24"	20"	57#	120'	100	0'
Intermediate 1	17 1/2"	13 3/8"	54.5#	2000'	1400	0'
Intermediate 2	12-1/4"	9-5/8"	40#	8925'	2000	0'
Production	8-3/4"	5-1/2"	20#	19652'	2600	8425'

### Well Plan

Drill 24" hole to 120' into the Rustler (Preset). Run 20" 57# conductor pipe to TD and cement to surface.

Drill 17-1/2" hole to ~2,000' w/ 10# brine mud. Run 13-3/8" 54.5# J-55 BTC casing to TD and cement to surface in one stage.

Drill 12-1/4" hole to ~8,925' with cut brine. Run 9-5/8 40# L-80 BTC to TD and cement to surface in one stage.

Drill 8-3/4" vertical hole, curve & lateral to 19652' with OBM. Run 5-1/2" 20# P110 BTC casing from TD to surface and cement to 8425' in one stage.

### Well Control

<u>Type</u>	<u>Working Pressure</u>	<u>Test Pressure</u>	<u>Manufacture</u>
Double Ram	5000 psi	5000 psi	Cameron