Submit 3 Copies To Appropriate District	State of New	v Mexico	Form C-103	
Office District I	Energy, Minerals and	Natural Resources	May 27, 200-	1
1625 N. French Dr., Hobbs, NM 88240	30 ·		WELL API NO.	
District II	OIL CONSERVAT	ION DIVISION	30-015-29806	
1301 W. Grand Ave., Artesia, NM 88210 District III	1220 South St.		5. Indicate Type of Lease	
1000 Rio Brazos Rd., Aztec, NM 87410			STATE FEE	_
District IV	Santa re, in	M 87505 RECEIVED	6. State Oil & Gas Lease No.	
1220 S. St. Francis Dr., Santa Fe, NM 87505		THE CHILD	BLM LC-29548-A	
SUNDRY NOTIC	CES AND REPORTS ON WI	ELLSUL 17 7006	7. Lease Name or Unit Agreement Name	_
			7. Boase Traine of Chit rigidomont Traine	
(DO NOT USE THIS FORM FOR PROPOSE DIFFERENT RESERVOIR. USE "APPLIC."	ATION FOR PERMIT" (FORM C-1	of For Such Provide	Russell, C. A.	
PROPOSALS.)	о w и 🗆 ол		8. Well Number 022	
	Gas Well Other			_
2. Name of Operator			9. OGRID Number	
Merit Energy Company			14591	_
3. Address of Operator	T 75240		10. Pool name or Wildcat	
13727 Noel Road, Suite 500, Dallas	, 1exas /3240		Grayburg-Jackson	
4. Well Location				
Unit Letter :	380feet from the	north line and50	0feet from the _westline	
Section 18	Township 17-S	Range 31-E	NMPM Eddy County	
1882年5月12日1日18月至12日末日	11. Elevation (Show whethe			X Q
图4代表现4所4的计划60分别	(****	,,.,.,.,,,,		
Pit or Below-grade Tank Application or	Closure			22500
Pit type Depth to Groundwa	ter Distance from nearest f	resh water well Dist	tance from nearest surface water	
Pit Liner Thickness: mil	Below-Grade Tank: Volume		onstruction Material	
Tit Liner Thickness.	Below-Grade Tank. Volume			
		Nature of Notice,	Report or Other Data	
	i	1 0115		
Approved as to plugging of			SEQUENT REPORT OF:	
Approved as to plugging of the well bore. Liability under		REMEDIAL WOR	K ☐ ALTERING CASING ☐	
Approved as to plugging of the well bore. Liability under bondlish etained until surface		REMEDIAL WOR		
rill well bore. Liability under		REMEDIAL WOR	K ☐ ALTERING CASING ☐ LLING OPNS.☐ P AND A X ☐	
rile well bore. Liability under hondlist etained until surface	/	REMEDIAL WOR COMMENCE DRI CASING/CEMEN	K ☐ ALTERING CASING ☐ LLING OPNS.☐ P AND A X ☐	
resturation, environmental	/ ion	REMEDIAL WOR COMMENCE DRI CASING/CEMENT	K ☐ ALTERING CASING ☐ ILLING OPNS.☐ P AND A X ☐ T JOB ☐ ☐	
resturation, environmental	/ ion	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and	K ☐ ALTERING CASING ☐ ILLING OPNS.☐ P AND A X ☐ T JOB ☐ ☐ d give pertinent dates, including estimated da	te
resturation, environmental	/ ion	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and	K ☐ ALTERING CASING ☐ ILLING OPNS.☐ P AND A X ☐ T JOB ☐ ☐	te
resturation, environmental	/ ion	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and	K ☐ ALTERING CASING ☐ ILLING OPNS.☐ P AND A X ☐ T JOB ☐ ☐ d give pertinent dates, including estimated da	te
iffe well bore. Liability under bondlist etained until surface resturation, environmental remediation and final inspect is completed.	ion NELL	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: At	ALTERING CASING ILLING OPNS. P AND A X T JOB d give pertinent dates, including estimated datach wellbore diagram of proposed completion	te
iffe well bore. Linbility under nondlist etained until surface resturation, environmental remediation and final inspect is completed. 06/29/2006 – Road Rig & P&A Equi	ion L to location. Hold tailgate sa	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: At	ALTERING CASING LLING OPNS. PAND A X T JOB d give pertinent dates, including estimated datach wellbore diagram of proposed completion by alty Well Service. SDFN.	te
iffe well bore. Linbritty under hondlist etained until surface restunation, environmental remediation and final inspect is completed. 06/29/2006 – Road Rig & P&A Equi 06/30/2006 – ND Wellhead & NU BO	to location. Hold tailgate sa OP> TIH w/tbg & tag top of	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: At afety meeting. MIRU Ro existing CIBP & Cmt @	ALTERING CASING LLING OPNS. PAND A X T JOB d give pertinent dates, including estimated datach wellbore diagram of proposed completion by alty Well Service. SDFN. 2665'. Received approval to spot cmt plug	te
ond is retained until surface restunation, environmental requestion and final inspect is completed. 06/29/2006 – Road Rig & P&A Equipo6/30/2006 – ND Wellhead & NU Bobelow 2315'. Mix and pump 20 sx ci	to location. Hold tailgate sactory TIH w/tbg & tag top of the poug @ 2315'. POOH. CV	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: At afety meeting. MIRU Ro existing CIBP & Cmt @ WI & pressure up to hold	ALTERING CASING ILLING OPNS. PAND A X T JOB d give pertinent dates, including estimated datach wellbore diagram of proposed completion by alty Well Service. SDFN. 2665'. Received approval to spot cmt plug I plug in place. SD For holiday weekend.	te
of/29/2006 – Road Rig & P&A Equipof/30/2006 – ND Wellhead & NU Bobelow 2315'. Mix and pump 20 sx cr 07/05/2006 – Open & Bled down well	to location. Hold tailgate sactory TIH w/tbg & tag top of the poug @ 2315'. POOH. CV	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: At afety meeting. MIRU Ro existing CIBP & Cmt @ WI & pressure up to hold	ALTERING CASING LLING OPNS. PAND A X T JOB d give pertinent dates, including estimated datach wellbore diagram of proposed completion by alty Well Service. SDFN. 2665'. Received approval to spot cmt plug	te
of/29/2006 – Road Rig & P&A Equipof/30/2006 – ND Wellhead & NU Bobelow 2315'. Mix and pump 20 sx cr 07/05/2006 – Open & Bled down well plug @ 2315'. SDFN.	tion to location. Hold tailgate sa DP> TIH w/tbg & tag top of the poug @ 2315'. POOH. CV I with slight trickle of water.	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Roexisting CIBP & Cmt @:WI & pressure up to hold RIH w/tbg. Did not tag	ALTERING CASING ALLING OPNS. PAND A X TOB TOB PAND A X TOB TOB TOB PAND A X TOB PAN	te
of/29/2006 – Road Rig & P&A Equipof/30/2006 – ND Wellhead & NU Bobelow 2315'. Mix and pump 20 sx cr 07/05/2006 – Open & Bled down wellplug @ 2315'. SDFN. 07/06/2006 – Open & bled down well	tion to location. Hold tailgate sa DP> TIH w/tbg & tag top of the poug @ 2315'. POOH. CV I with slight trickle of water. I with slight trickle of water.	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Ro existing CIBP & Cmt @ WI & pressure up to hold RIH w/tbg. Did not tag RIH w/tbg & tag top of other comments.	ALTERING CASING LILLING OPNS. PAND A X TOBE TOBE TOBE TOBE TOBE TOBE TOBE TOBE	te
of/29/2006 – Road Rig & P&A Equi 06/30/2006 – ND Wellhead & NU Bobelow 2315'. Mix and pump 20 sx cr 07/05/2006 – Open & Bled down well pump 20 sx cmt plug @ 2315'. SDFN.	to to location. Hold tailgate sa DP> TIH w/tbg & tag top of ent poug @ 2315'. POOH. CV I with slight trickle of water. I with slight trickle of water. H w/tbg, WCI & WOC. Ope	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Ro existing CIBP & Cmt @ WI & pressure up to hold RIH w/tbg. Did not tag RIH w/tbg & tag top of on well and RIH w/tbg & and RIH	ALTERING CASING LLING OPNS. PAND A X T JOB d give pertinent dates, including estimated datach wellbore diagram of proposed completion yealty Well Service. SDFN. 2665'. Received approval to spot cmt plug I plug in place. SD For holiday weekend. cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug @ 2120'. POOH to 1560', mix 7 tag top of cmt plug @ 1322'. Shut off sight	te
of/29/2006 – Road Rig & P&A Equi 06/30/2006 – ND Wellhead & NU Bobelow 2315'. Mix and pump 20 sx cr 07/05/2006 – Open & Bled down well pump 20 sx cmt plug @ 2315'. SDFN. 07/06/2006 – Open & bled down well pump 20 sx cmt plug @ 1560'. POO water flow. POOH w/tbg to 520'. M	to location. Hold tailgate sa DP> TIH w/tbg & tag top of ant poug @ 2315'. POOH. CV I with slight trickle of water. I with slight trickle of water. IH w/tbg, WCI & WOC. Ope ix & pump 20 sx cmt lug @ 25 cm.	REMEDIAL WOR COMMENCE DRI CASING/CEMENTO OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Rolexisting CIBP & Cmt @ WI & pressure up to hold RIH w/tbg. Did not tag RIH w/tbg & tag top of on well and RIH w/tbg & With the wide with th	ALTERING CASING ALLING OPNS. PAND A X TODE TO A NOT SHEET TO A NOT	te
ob/29/2006 – Road Rig & P&A Equi 06/30/2006 – ND Wellhead & NU Bobelow 2315'. Mix and pump 20 sx cr 07/05/2006 – Open & Bled down well pump 20 sx cmt plug @ 2315'. SDFN. 07/06/2006 – Open & bled down well pump 20 sx cmt plug @ 1560'. POO water flow. POOH w/tbg to 520'. M 07/07/2006 – Open well, had slight w	to location. Hold tailgate sand to location. Hold tailgate sand to provide the pour office of the pour offic	REMEDIAL WOR COMMENCE DRI CASING/CEMENTO OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Roexisting CIBP & Cmt @ WI & pressure up to hold RIH w/tbg. Did not tag RIH w/tbg & tag top of on well and RIH w/tbg & W top of cmt plug 2 250°.	ALTERING CASING LLING OPNS. PAND A X T JOB d give pertinent dates, including estimated datach wellbore diagram of proposed completion yealty Well Service. SDFN. 2665'. Received approval to spot cmt plug la plug in place. SD For holiday weekend. cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug @ 2120'. POOH to 1560', mix 7 tag top of cmt plug @ 1322'. Shut off sight OC. CWI & SDFN. Wait on procedure from BLM. Open well &	te
ob/29/2006 – Road Rig & P&A Equi 06/30/2006 – ND Wellhead & NU Bobelow 2315'. Mix and pump 20 sx cr 07/05/2006 – Open & Bled down well pump 20 sx cmt plug @ 2315'. SDFN. 07/06/2006 – Open & bled down well pump 20 sx cmt plug @ 1560'. POO water flow. POOH w/tbg to 520'. M 07/07/2006 – Open well, had slight w bled off pressure, installed 200# pressure.	to location. Hold tailgate sand tailga	REMEDIAL WOR COMMENCE DRI CASING/CEMENTO OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Rolexisting CIBP & Cmt @ WI & pressure up to hold RIH w/tbg. Did not tag RIH w/tbg & tag top of on well and RIH w/tbg & W top of cmt plug 2 250°. Monitor well over the well and results of the well and resu	ALTERING CASING ALLING OPNS. PAND A X TODE TO JOB TO JOB TO JOB PAND A X TODE TO JOB PAND A X TODE TO JOB PAND A X PAND A X TODE TO JOB	te
object of the complete of the	to location. Hold tailgate sand to location. Hold tailgate sand to possible the possible trickle of water. I with slight trick	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: At a serior and the completions of the completion	ALTERING CASING LILLING OPNS. PAND A X TODE d give pertinent dates, including estimated datach wellbore diagram of proposed completion by alty Well Service. SDFN. 2665'. Received approval to spot cmt plug plug in place. SD For holiday weekend. cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug @ 2120'. POOH to 1560', mix 7 tag top of cmt plug @ 1322'. Shut off sight OC. CWI & SDFN. Wait on procedure from BLM. Open well & eekend. Ing well to surface. RIH w/tbg to 60', mix &	te
ob/29/2006 – Road Rig & P&A Equipoble 2315'. Mix and pump 20 sx cm o7/05/2006 – Open & Bled down well pump 20 sx cm thug @ 2315'. SDFN. o7/06/2006 – Open & bled down well pump 20 sx cm thug @ 1560'. POO water flow. POOH w/tbg to 520'. M o7/07/2006 – Open well, had slight w bled off pressure, installed 200# pressure, pump 10 sx cmt plug – surface. ND 1	to location. Hold tailgate sand to location. Hold tailgate sand to possible the possible trickle of water. I with slight trick	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: At a serior and the completions of the completion	ALTERING CASING ALLING OPNS. PAND A X TODE TO JOB TO JOB TO JOB PAND A X TODE TO JOB PAND A X TODE TO JOB PAND A X PAND A X TODE TO JOB	te
object of the complete of the	to location. Hold tailgate sand to location. Hold tailgate sand to possible the possible trickle of water. I with slight trick	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: At a serior and the completions of the completion	ALTERING CASING LILLING OPNS. PAND A X TODE d give pertinent dates, including estimated datach wellbore diagram of proposed completion by alty Well Service. SDFN. 2665'. Received approval to spot cmt plug plug in place. SD For holiday weekend. cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug @ 2120'. POOH to 1560', mix 7 tag top of cmt plug @ 1322'. Shut off sight OC. CWI & SDFN. Wait on procedure from BLM. Open well & eekend. Ing well to surface. RIH w/tbg to 60', mix &	te
ob/29/2006 – Road Rig & P&A Equipoble 2315'. Mix and pump 20 sx croprofile 2315'. SDFN. 07/05/2006 – Open & Bled down well pump 20 sx cnt plug @ 2315'. SDFN. 07/06/2006 – Open & bled down well pump 20 sx cnt plug @ 1560'. POO water flow. POOH w/tbg to 520'. M 07/07/2006 – Open well, had slight whele off pressure, installed 200# pressure, pump 10 sx cmt plug – surface. ND I location. Job complete.	to location. Hold tailgate sand of the location of the location. Hold tailgate sand of the location of the location. Hold tailgate sand of the location of the loc	REMEDIAL WOR COMMENCE DRI CASING/CEMENT OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Roexisting CIBP & Cmt @ WI & pressure up to hold RIH w/tbg. Did not tag RIH w/tbg & tag top of on well and RIH w/tbg & W top of cmt plug 2 250°. The monitor well over the word to preseed with pluggiead, RDMO. Weld on Driver and Comments of the word of th	ALTERING CASING LILLING OPNS. PAND A X TODE d give pertinent dates, including estimated datach wellbore diagram of proposed completion by alty Well Service. SDFN. 2665'. Received approval to spot cmt plug liplug in place. SD For holiday weekend. cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. PU to 2315', spix 7 pump 25 cmt cmt plug. POOH to 1560', mix 7 tag top of cmt plug. 1322'. Shut off sight OC. CWI & SDFN. Wait on procedure from BLM. Open well & eekend. Ing well to surface. RIH w/tbg to 60', mix & ry Hole Marker. Remove rig anchors & clear	n
objective of the complete of t	to location. Hold tailgate sand to location. With slight trickle of water. How water should be water flow. RIH w/tbg & tag water guage, CWI & SD. Will Received approval from BLI BOP, dig out & cut off wellhed bove is true and complete toward.	REMEDIAL WOR COMMENCE DRI CASING/CEMENTO OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Roexisting CIBP & Cmt @ WI & pressure up to hold RIH w/tbg. Did not tag RIH w/tbg & tag top of an well and RIH w/tbg & W top of cmt plug 2 250°. Monitor well over the word to preseed with pluggicad, RDMO. Weld on Drive the best of my knowledge.	ALTERING CASING LILLING OPNS. PAND A X TODE d give pertinent dates, including estimated datach wellbore diagram of proposed completion by alty Well Service. SDFN. 2665'. Received approval to spot cmt plug liplug in place. SD For holiday weekend. cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. POOH to 1560', mix 7 tag top of cmt plug. 1322'. Shut off sight OC. CWI & SDFN. Wait on procedure from BLM. Open well & eekend. Ing well to surface. RIH w/tbg to 60', mix & ry Hole Marker. Remove rig anchors & clear	n
objective of the complete of t	to location. Hold tailgate sand to location. With slight trickle of water. How water should be water flow. RIH w/tbg & tag water guage, CWI & SD. Will Received approval from BLI BOP, dig out & cut off wellhed bove is true and complete toward.	REMEDIAL WOR COMMENCE DRI CASING/CEMENTO OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Roexisting CIBP & Cmt @ WI & pressure up to hold RIH w/tbg. Did not tag RIH w/tbg & tag top of an well and RIH w/tbg & W top of cmt plug 2 250°. Monitor well over the word to preseed with pluggicad, RDMO. Weld on Drive the best of my knowledge.	ALTERING CASING LILLING OPNS. PAND A X TODE d give pertinent dates, including estimated datach wellbore diagram of proposed completion by alty Well Service. SDFN. 2665'. Received approval to spot cmt plug liplug in place. SD For holiday weekend. cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. PU to 2315', spix 7 pump 25 cmt cmt plug. POOH to 1560', mix 7 tag top of cmt plug. 1322'. Shut off sight OC. CWI & SDFN. Wait on procedure from BLM. Open well & eekend. Ing well to surface. RIH w/tbg to 60', mix & ry Hole Marker. Remove rig anchors & clear	n
objection of the control of the cont	to location. Hold tailgate sa OP> TIH w/tbg & tag top of ont poug @ 2315'. POOH. CVI with slight trickle of water. I with slight trickle of water. I w/tbg, WCI & WOC. Ope ix & pump 20 sx cmt lug @ swater flow. RIH w/tbg & tag sure guage, CWI & SD. Will Received approval from BLI BOP, dig out & cut off wellhed bove is true and complete to closed according to NMOCD guide	REMEDIAL WOR COMMENCE DRI CASING/CEMENTO OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Rosexisting CIBP & Cmt @ WI & pressure up to hold RIH w/tbg. Did not tag RIH w/tbg. Did not tag RIH w/tbg & tag top of cm well and RIH w/tbg & Wood top of cmt plug 2 250°. The monitor well over the word to preserve with plugging ad, RDMO. Weld on Displaced, RDMO. Weld on Displaced in a general permit in the comment of the comm	ALTERING CASING LILLING OPNS. PAND A X TODE d give pertinent dates, including estimated datach wellbore diagram of proposed completion by alty Well Service. SDFN. 2665'. Received approval to spot cmt plug liplug in place. SD For holiday weekend. cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. POOH to 1560', mix 7 tag top of cmt plug. 1322'. Shut off sight OC. CWI & SDFN. Wait on procedure from BLM. Open well & eekend. Ing well to surface. RIH w/tbg to 60', mix & ry Hole Marker. Remove rig anchors & clear e and belief. I further certify that any pit or below or an (attached) alternative OCD-approved plan.	n
objection of the complete of t	to location. Hold tailgate sa OP> TIH w/tbg & tag top of ont poug @ 2315'. POOH. CVI with slight trickle of water. I with slight trickle of water. I w/tbg, WCI & WOC. Ope ix & pump 20 sx cmt lug @ swater flow. RIH w/tbg & tag sure guage, CWI & SD. Will Received approval from BLI BOP, dig out & cut off wellhed bove is true and complete to closed according to NMOCD guide	REMEDIAL WOR COMMENCE DRI CASING/CEMENTO OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Rosexisting CIBP & Cmt @ WI & pressure up to hold RIH w/tbg. Did not tag RIH w/tbg. Did not tag RIH w/tbg & tag top of an well and RIH w/tbg & Wood top of cmt plug 2 250°. The monitor well over the word to preserve with plugging ad, RDMO. Weld on Displace of my knowledgines , a general permit	ALTERING CASING LILLING OPNS. PAND A X TODE d give pertinent dates, including estimated datach wellbore diagram of proposed completion by alty Well Service. SDFN. 2665'. Received approval to spot cmt plug liplug in place. SD For holiday weekend. cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. POOH to 1560', mix 7 tag top of cmt plug. 1322'. Shut off sight OC. CWI & SDFN. Wait on procedure from BLM. Open well & eekend. Ing well to surface. RIH w/tbg to 60', mix & ry Hole Marker. Remove rig anchors & clear	n
objection of the complete of t	to location. Hold tailgate sand to location. Hold tailgate sand top of the poug @ 2315'. POOH. CV I with slight trickle of water. It	REMEDIAL WOR COMMENCE DRI CASING/CEMENTO OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Role existing CIBP & Cmt @ WI & pressure up to hold RIH w/tbg. Did not tag RIH w/tbg. Did not tag RIH w/tbg & tag top of on well and RIH w/tbg & W top of cmt plug 2 250°. Monitor wall over the word to present with plugging ad, RDMO. Weld on Did the best of my knowledgines , a general permit . E_Sr. Regulatory Analysis	ALTERING CASING LLING OPNS.	n
objection of the control of the cont	to location. Hold tailgate sand to location. Hold tailgate sand top of the poug @ 2315'. POOH. CV I with slight trickle of water. It	REMEDIAL WOR COMMENCE DRI CASING/CEMENTO OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Role existing CIBP & Cmt @ WI & pressure up to hold RIH w/tbg. Did not tag RIH w/tbg. Did not tag RIH w/tbg & tag top of on well and RIH w/tbg & W top of cmt plug 2 250°. Monitor wall over the word to present with plugging ad, RDMO. Weld on Did the best of my knowledgines , a general permit . E_Sr. Regulatory Analysis	ALTERING CASING LILLING OPNS. PAND A X TODE d give pertinent dates, including estimated datach wellbore diagram of proposed completion by alty Well Service. SDFN. 2665'. Received approval to spot cmt plug liplug in place. SD For holiday weekend. cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. PU to 2315', mix 7 pump 25 cmt cmt plug. POOH to 1560', mix 7 tag top of cmt plug. 1322'. Shut off sight OC. CWI & SDFN. Wait on procedure from BLM. Open well & eekend. Ing well to surface. RIH w/tbg to 60', mix & ry Hole Marker. Remove rig anchors & clear e and belief. I further certify that any pit or below or an (attached) alternative OCD-approved plan.	n
objective of the control of the cont	to location. Hold tailgate sand to location. Hold tailgate sand top of the poug @ 2315'. POOH. CV I with slight trickle of water. It	REMEDIAL WOR COMMENCE DRI CASING/CEMENTO OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Role existing CIBP & Cmt @ WI & pressure up to hold RIH w/tbg. Did not tag RIH w/tbg. Did not tag RIH w/tbg & tag top of on well and RIH w/tbg & W top of cmt plug 2 250°. Monitor wall over the word to present with plugging ad, RDMO. Weld on Did the best of my knowledgines , a general permit . E_Sr. Regulatory Analysis	ALTERING CASING LLING OPNS.	n
objection of the control of the cont	to location. Hold tailgate sand to location. Hold tailgate sand top of the poug @ 2315'. POOH. CV I with slight trickle of water. It	REMEDIAL WOR COMMENCE DRI CASING/CEMENTO OTHER: pertinent details, and ple Completions: At affety meeting. MIRU Rosexisting CIBP & Cmt @ WI & pressure up to hold RIH w/tbg. Did not tag RIH w/tbg & tag top of on well and RIH w/tbg & W top of cmt plug 2 250°. Monitor well over the word to present with plugging and, RDMO. Weld on Drive and RIH w/top and RIH w/top and RIH w/tbg & W top of cmt plug 2 250°. Monitor well over the word to present with plugging and, RDMO. Weld on Drive and RIH w/top and RIH w/top and RIH w/top and RIH w/tbg & W top of cmt plug 2 250°. Monitor well over the word top and RIH w/top and RIH w/tbg & W top of cmt plug 2 250°. Monitor well and RIH w/tbg & W top of cmt plug 2 250	ALTERING CASING LLING OPNS.	n